CASIO.

CASIO COMPUTER CO., LTD.

6-2, Hon-machi 1-chome Shibuya-ku, Tokyo 151-8543, Japan

			Sec.		
6 C C C C	· · · · · · · · · · · · · · · · · · ·	o o o c c			70
	-74('s Gui				ん
	• • • • • • • • • • • • • •		ငငငငင	С	
••••					
				C. A. S. S. S. S.	
		and Angu			
E .					36

SA9905-A Printed in Malaysia A341641-52X GUIDELINES LAID DOWN BY FCC RULES FOR USE OF THE UNIT IN THE U.S.A. (not applicable to other areas).

NOTICE

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- · Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- · Consult the dealer or an experienced radio/TV technician for help.

FCC WARNING

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Proper connectors must be used for connection to host computer and/or peripherals in order to meet FCC emission limits.

Connector SB-62 Power Graphic Unit to Power Graphic Unit Connector FA-123 Power Graphic Unit to PC for IBM/Macintosh Machine

> CASIO ELECTRONICS CO., LTD. Unit 6, 1000 North Circular Road, London NW2 7JD, U.K.

Important!

Please keep your manual and all information handy for future reference.

IBM is a registered trademark of International Business Machines Corporation. Macintosh is a registered trademark of Apple Computer, Inc.

BEFORE USING THE CALCULATOR FOR THE FIRST TIME ONLY...

This calculator does not contain any main batteries when you purchase it. Be sure to perform the following procedure to load batteries, reset the calculator, and adjust the contrast before trying to use the calculator for the first time.


1. Making sure that you do not accidently press the III key, slide the case onto the calculator and then turn the calculator over. Remove the back cover from the unit by pulling with your finger at the point marked ☆.



the batteries are facing correctly.








 Remove the insulating sheet at the location marked "BACK UP" by pulling in the direction indicated by the arrow.

2. Load the two batteries that come with calculator.
Make sure that the positive (+) and negative (-) ends of




 Replace the back cover and turn the calculator front side up, which should automatically turn on power and perform the memory reset operation.



1	kakaka ka	*****
	MEM	CLEARED!
1	kakakaka	*****





iii

ij

Be sure to keep physical records of all important data!

The large memory capacity of the unit makes it possible to store large amounts of data. You should note, however, that low battery power or incorrect replacement of the batteries that power the unit can cause the data stored in memory to be corrupted or even lost entirely. Stored data can also be affected by strong electrostatic charge or strong impact.

fx-7400G PLUS

In no event shall CASIO Computer Co., Ltd. be liable to anyone for special, collateral, incidental, or consequential damages in connection with or arising out of the purchase or use of these materials. Moreover, CASIO Computer Co., Ltd. shall not be liable for any claim of any kind whatsoever against the use of these materials by any other party.

The contents of this manual are subject to change without notice.

iv

- No part of this manual may be reproduced in any form without the express written consent of the manufacturer.
- The options described in Chapter 9 of this manual may not be available in certain geographic areas.
 For full details on availability in your area, contact your nearest CASIO dealer or distributor.

Contents

vi

pter 1 Getting Acquainted 1. Using the Main Menu	
2. Key Table	
3. Key Markings	
4. Selecting Modes	
Using the Set Up Screen Set Up Screen Function Key Menus	••••••
5. Display	
About the Display Screen	*******
About Menu Item Types	
Exponential Display	••••••
Special Display Formats	
Calculation Execution Screen	••••••••••
6. Contrast Adjustment	
7. When you keep having problems	******
Out the out of the out	
Get the Calculator Back to its Original Mode Settinge	
Get the Calculator Back to its Original Mode Settings Low Battery Message	
Diter 2 Basic Calculations	
Diter 2 Basic Calculations 1. Addition and Subtraction 2. Multiplication	
Diter 2 Basic Calculations 1. Addition and Subtraction 2. Multiplication	
Low Battery Message Dter 2 Basic Calculations 1. Addition and Subtraction 2. Multiplication 3. Division	
Low Battery Message oter 2 Basic Calculations 1. Addition and Subtraction 2. Multiplication 3. Division 4. Quotient and Remainder Division	
Low Battery Message Dter 2 Basic Calculations 1. Addition and Subtraction 2. Multiplication 3. Division 4. Quotient and Remainder Division 5. Mixed Calculations	
Division Di	
Division Di	
Division Di	
Low Battery Message Deter 2 Basic Calculations 1. Addition and Subtraction 2. Multiplication 3. Division 4. Quotient and Remainder Division 5. Mixed Calculations (1) Mixed Arithmetic Calculation Priority Sequence (2) Parentheses Calculation Priority Sequence (3) Negative Values (4) Exponential Expressions (5) Rounding	
Low Battery Message Deter 2 Basic Calculations 1. Addition and Subtraction 2. Multiplication 3. Division 4. Quotient and Remainder Division 5. Mixed Calculations (1) Mixed Arithmetic Calculation Priority Sequence (2) Parentheses Calculation Priority Sequence (3) Negative Values (4) Exponential Expressions (5) Rounding	
Low Battery Message Deter 2 Basic Calculations 1. Addition and Subtraction 2. Multiplication 3. Division 4. Quotient and Remainder Division 5. Mixed Calculations (1) Mixed Arithmetic Calculation Priority Sequence (2) Parentheses Calculation Priority Sequence (3) Negative Values (4) Exponential Expressions (5) Rounding (6) Other Useful Calculation Features (1) Answer Memory (Ans)	
 Low Battery Message	
Low Battery Message Deter 2 Basic Calculations 1. Addition and Subtraction 2. Multiplication 3. Division 4. Quotient and Remainder Division 5. Mixed Calculations (1) Mixed Arithmetic Calculation Priority Sequence (2) Parentheses Calculation Priority Sequence (3) Negative Values (4) Exponential Expressions (5) Rounding (1) Answer Memory (Ans) (2) Consecutive Calculations (3) Replay	
 Low Battery Message	

2

Contents

8. Fraction Calculations	
(1) Fraction Display and Input	
(2) Performing Fraction Calculations	
(3) Changing the Fraction Simplification Mode	
9. Selecting Value Display Modes	
10. Scientific Function Calculations	
(1) Trigonometric Functions	28
Setting the Default Angle Unit	
Converting Between Angle Units	
Trigonometric Function Calculations	
(2) Logarithmic and Exponential Function Calculations	
(3) Other Functions	31
(4) Coordinate Conversion	
(5) Permutation and Combination	
(6) Other Things to Remember	33
Multiplication Sign	33
Calculation Priority Sequence	34
Using Multistatements	34
Stacks	
Errors	
How to Calculate Memory Usage	36
Memory Status (MEM)	37
Clearing Memory Contents	37
Variable Data (VARS) Menu	38
Chapter 3 Differential Calculations	
Chapter 4 Graphing	
1. Before Trying to Draw a Graph	48
Entering the Graph Mode	
2. View Window (V-Window) Settings	
Initializing and Standardizing the View Window	
View Window Memory	
3. Graph Function Operations	
Specifying the Graph Type	
Storing Graph Functions	
Editing Functions in Memory	
Drawing a Graph	

4. Drawing Graphs Manually 55

Vİİ

5. 01	ther Graphing Functions	5
	Connect Type and Plot Type Graphs (D-Type)	E
	Trace	F
	Scroll	
	Overwrite	
	Zoom	
	Sketch Function	

Chapter 5 Table & Graph		7;
1. Storing a Function		
2. Deleting a Function		
3. Assigning Values to a Variable		
4. Generating a Numeric Table		
5. Editing a Table		77
6. Graphing a Function		
7. Assigning Numeric Table Content	s to a List	78

80
01
82
87
91
01
93
93
93
94
95

Co	n	te	n	t

Plotting D	Data	07
Plotting a	Scatter Diagram	09
Changing	Graph Parameters	09
1. Graph o	draw/non-draw status (SELECT)	90
2. Genera	a graph settings (SET)	90
Drawing a	an xy Line Graph	105
Selecting	the Regression Type	105
Displaying	g Statistical Calculation Results	106
Graphing	statistical calculation results	106
3. Calculating	and Graphing Single-Variable Statistical	Data 107
Histogram		107
Box Graph	٦	107
Normal Dis	stribution Curve	108
Displaying	Single-Variable Statistical Results	
Pie Chart		100
Stacked B	ar Chart	
Bar Graph		
Line Graph	1	
Bar Graph	and Line Graph	
4. Calculating a	and Graphing Paired-Variable Statistical	Data 114
Linear Reg	ression Graph	114
Med-Med C	Graph	115
Quadratic I	Regression Graph	
Logarithmic	c Regression Graph	116
Exponentia	al Regression Graph	
Power Reg	ression Graph	
Displaying	Paired-Variable Statistical Results	
Copying a l	Regression Graph Formula to the Graph Mode	
Multiple Gra	aphs	
5. Manual Grap	hing	120
Setting the	Width of a Histogram	120
6. Performina S	Statistical Calculations	101
Single-Varia	able Statistical Calculations	100
Paired-Varia	able Statistical Calculations	
Regression	Calculation	122
Estimated V	Value Calculation (\hat{x},\hat{y})	100
	······································	

vi

х

Chapter 8 Programming	
1. Before Programming	126
2. Programming Examples	127
3. Debugging a Program	120
4. Calculating the Number of Bytes Used by a Program	120
5. Secret Function	104
6. Searching for a File	
7. Editing Program Contents	
8. Deleting a Program	
8. Deleting a Program	
9. Useful Program Commands	
10. Command Reference	143
Command Index	143
Basic Operation Commands Program Commands (COM)	
Program Control Commands (CTL)	
Jump Commands (JUMP)	
Clear Commands (CLR)	151
Display Commands (DISP)	
Input / Output Commands (I/O)	
Conditional Jump Relational Operators (REL)	155
11. Text Display	156
12. Using Calculator Functions in Programs	
Using Graph Functions in a Program	156
Using Table & Graph Functions in a Program	157
Using List Sort Functions in a Program	158
Using Statistical Calculations and Graphs in a Program	158
Performing Statistical Calculations	160
Chapter 9 Data Communications	162
1. Connecting Two Units	
2. Connecting the Unit with a Personal Computer	
3. Connecting the Unit with a CASIO Label Printer	166
4. Before Performing a Data Communication Operation	167
5. Performing a Data Transfer Operation	168
6. Screen Send Function	
7. Data Communications Precautions	

1. Prime Factor Analysis	17
2. Greatest Common Measure	17
3. <i>t</i> -Test Value	18
4. Circle and Tangents	18
5. Rotating a Figure	18
그릇은 사람은 것은	
Appendix	19
Appendix A Resetting the Calculator	

Appendix A Resetting the Calculator	194
Appendix B Power Supply	196
Replacing Batteries	196
About the Auto Power Off Function	198
Appendix C Error Message Table	199
Appendix D Input Ranges	201
Appendix E Specifications	203

Chapter

Getting Acquainted — Read This First!

statements and a second as merely as a second and

2

1. Using the Main Menu

The main menu appears on the display whenever you turn on the calculator. It contains a number of icons that let you select the mode (work area) for the type of operation you want to perform. You can also make the Main Menu appear at any time by pressing IERN.

The following explains the meaning of each icon.

lcon	Meaning		
<u>⁸ні +п</u>	Use this mode for arithmetic calculations and func- tion calculations.		
STAT	Use this mode to perform single-variable (stand- ard deviation) and paired-variable (regression) sta- tistical calculations, and to draw statistical graphs.		
	Use this mode for storing and editing numeric data.		
GRAPH CH/C	Use this mode to store graph functions and to draw graphs using the functions.		
TABLE Ŭ <u>++</u> IG	Use this mode to store functions, to generate a numeric table of different solutions as the values assigned to variables in a function change, and to draw graphs.		
PRGM	Use this mode to store programs in the program area and to run programs.		
	Use this mode to transfer memory contents or back-up data to another unit.		
	Use this mode to adjust the contrast of the display.		
MEM ART F	Use this mode to check how much memory is used and remaining, to delete data from memory, and to initialize (reset) the calculator.		

Getting Acquainted Chapter 1

•To enter a mode

Example To enter the RUN Mode from the Main Menu

- 1. Press MENU to display the Main Menu.
- 2. Use (1), (2), (2), and (1) to move the highlighting to the RUN icon.
- 3. Press Exe to enter the RUN Mode.




 You can also enter a mode without highlighting an icon in the Main Menu by inputting the number marked in the lower right corner of the icon.

 When you enter a mode, up to four function key menu items appear at the bottom of the display. Each menu item corresponds to the function key (F], F2, F3, F4) that is below the item. Some function menus have multiple pages. When this happens, you should press ▷ to advance to the next menu page.


Example Menus

Simpl	int=	(md	3	
F1	F2	F3	1.00	ł


	CHLC	SIE	PROP
F1	F2	F3	F4



2. Key Table







Alpha Lock


4

Normally, once you press (AFM) and then a key to input an alphabetic character, the keyboard reverts to its primary functions immediately. If you press (SHFT) and then (AFM), the keyboard locks in alpha input until you press (AFM) again.

Chapter 1 Getting Acquainted

3. Key Markings

Many of the calculator's keys are used to perform more than one function. The functions marked on the keyboard are color coded to help you find the one you need quickly and easily.



	Function	Key Operation
1	log	
2	10 ^x	[SHIFT] (log)
3	В	Alfha log

The following describes the color coding used for key markings.

Color	Key Operation
Orange	Press (IIIF) and then the key to perform the marked function.
Red	Press IMM and then the key to perform the marked function.

4. Selecting Modes

Using the Set Up Screen

The first thing that appears when you enter a mode is the mode's set up screen, which shows the current status of settings for the mode. The following procedure shows how to change a set up.

•To change a mode set up

1. Select the icon you want and press 🕮 enter a mode and display its initial screen. Here we will enter the RUN Mode.

- Getting Acquainted Chapter 1
- 2. Press SHIFT STUP to display the mode's set up screen.
- This set up screen is just one possible example. Actual set up screen contents will differ according to the mode you are in and that mode's current settings.




- 3. Use the and cursor keys to move the highlighting to the item whose setting you want to change.
- 4. Press the function key (F1 to F4) that is marked with the setting you want to make.
- 5. After you are finished making any changes you want, press (a) to return to the initial screen of the mode.

Set Up Screen Function Key Menus

This section details the settings you can make using the function keys in the set up display.

•Graph Function Type (F-Type)




Press D to return to the previous menu.


• The setting you make for F-Type determines the variable name that is input when you press [I].

•Graph Draw Type (D-Type)

F1 (Con)	Connection of points plot-	D=
	ted on graph.	
F2 (Plot)	Plotting of points on graph	
	without connection.	E



Chapter 1 **Getting Acquainted**



	Var	:Ranse
그는 것 같은 것 같은 것 같은 것 같은 것 같은 것 같은 것 같은 것 같		
F1 (List4) –	1	
F2 (List5) Table generation and graph drawing using list data.	List4 List	SLISt6
F3 (List6) _ drawing using list data.	(F1) (F2)	(F3)

Getting Acquainted Chapter 1

Press [>] to return to the previous menu.

Other menus for set up (Display, Simplfy, Frac) are described in each applicable section of this manual as they come up.


Abbreviations

STAT	Statistics
PRGM	Program
CONT	Contrast
MEM	Memory


5. Display

About the Display Screen

This calculator uses two types of display: a text display and a graphic display. The text display can show 13 columns and six lines of characters, with the bottom line used for the function key menu, while the graph display uses an area that measures 79 (W) × 47 (H) dots.







About Menu Item Types

This calculator uses certain conventions to indicate the type of result you can expect when you press a function key.

Next Menu

Example:

Selecting III displays a menu of list functions.

Command Input

Example: List. Selecting List inputs the "List" command.

P.75

⊳

Chapter 1 Getting Acquainted

Direct Command Execution

Example: DRAW Selecting DRAW executes the DRAW command.

Exponential Display

The calculator normally displays values up to 10 digits long. Values that exceed this limit are automatically converted to and displayed in exponential format. You can specify one of two different ranges for automatic changeover to exponential display.


Norm 1 $10^{-2} (0.01) > |x|, |x| \ge 10^{10}$ Norm 2 $10^{-9} (0.000000001) > |x|, |x| \ge 10^{10}$

To change the exponential display range

- 1. Press SHIFT SETUP to display the Set Up Screen.
- 2. Use (and () to move the highlighting to "Display".

3. Press F3 (Norm).

The exponential display range switches between Norm 1 and Norm 2 each time you perform the above operation. There is no display indicator to show you which exponential display range is currently in effect, but you can always check it by seeing what results the following calculation produces.



All of the examples in this manual show calculation results using Norm 1. For full details about the "Display", see "Selecting Value Display Modes".

How to interpret exponential format

1.2E12 1.2+12

 1.2^{+12} indicates that the result is equivalent to 1.2×10^{12} . This means that you should move the decimal point in 1.2 twelve places to the right, because the exponent is positive. This results in the value 1,200,000,000,000.

 1.2^{-03} indicates that the result is equivalent to 1.2×10^{-3} . This means that you should move the decimal point in 1.2 three places to the left, because the exponent is negative. This results in the value 0.0012.

Getting Acquainted Chapter 1

Special Display Formats

This calculator uses special display formats to indicate fractions, and sexagesimal values.


Fractions

•Sexagesimal Values

 In addition to the above, this calculator also uses other indicators or symbols, which are described in each applicable section of this manual as they come up.

Calculation Execution Screen

Whenever the calculator is busy drawing a graph or executing a long, complex calculation or program, a black box (\blacksquare) flashes in the upper right corner of the display. This black box tells you that the calculator is performing an internal operation.




6. Contrast Adjustment

Adjust the contrast whenever objects on the display appear dim or difficult to see.

•To display the contrast adjustment screen

Highlight the **CONT** icon in the Main Menu and then press **E**.



Press (1) to make the figures on the screen lighter or (1) to make them darker. After getting the contrast the way you want it, press (19) to return to the main menu.

P.27

Chapter 1 Getting Acquainted

7. When you keep having problems...

If you keep having problems when you are trying to perform operations, try the following before assuming that there is something wrong with the calculator.


Get the Calculator Back to its Original Mode Settings

- 1. In the Main Menu, select the RUN icon and press EXE.
- 2. Press SHFT STUP to display the Set Up Screen.
- 3. Highlight "Angle" and press F2 (Rad).
- 4. Highlight "Display" and press F3 (Norm) to select the exponential display range (Norm 1 or Norm 2) that you want to use.
- 5. Now enter the correct mode and perform your calculation again, monitoring the results on the display.

Low Battery Message

The low battery message appears while the main battery power is below a certain level whenever you press from to turn power on or from to display the Main Menu.

AC/ON Or MENU



P.196

P.6


If you continue using the calculator without replacing batteries, power will automatically turn off to protect memory contents. Once this happens, you will not be able to turn power back on, and there is the danger that memory contents will be corrupted or lost entirely.

Chapter 222


Basic Calculations

In the RUN Mode you can perform arithmetic calculations (addition, subtraction, multiplication, division) as well as calculations involving scientific functions.

- 1. Addition and Subtraction
- 2. Multiplication
- 3. Division
- 4. Quotient and Remainder Division
- 5. Mixed Calculations
- 6. Other Useful Calculation Features
- 7. Using Variables
- 8. Fraction Calculations
- 9. Selecting Value Display Modes
- **10. Scientific Function Calculations**



Basic Calculations Chapter 2



4. Quotient and Remainder Division

This calculator can produce either the quotient or the quotient and remainder of division operations involving two integers. Use (PTM) to display the Option Menu for the function key menu you need to perform quotient and remainder division.

Operation

Use the RUN Mode for quotient and remainder division.


Quotient Division <integer> OPTN F2 (CALC) F2 (Int+)<integer> EXE

Reminder Division <integer> (PTN) F2 (CALC) F3 (Rmdr)<integer> [2]


•To perform quotient division

Example To display the quotient produced by 61 + 7

AC 6 1 000 F2 (CALC)



P.17



Basic Calculations Chapter 2

(5) Rounding

Example 74 ÷ 3

AC 7 4 🕂 3 🛤

74÷3 24.66666667

The actual result of the above calculation is 24.66666666... (and so on to infinity), which the calculator rounds off. The calculator's internal capacity is 15 digits for the values it uses for calculations, which avoids precision problems with consecutive operations that use the result of the previous operation.

6. Other Useful Calculation Features

(1) Answer Memory (Ans)


Calculation results are automatically stored in the Answer Memory, which means you can recall the results of the last calculation you performed at any time.

•To recall Answer Memory contents

Press SHET and then Ans (which is the shifted function of the (-) key). This operation is represented as SHET Ans throughout this manual.

Example To perform 3.56 + 8.41 and then divide 65.38 by the result

AC 3 • 5 6 + 8 • 4 1 EX 6 5 • 3 8 + 907 Ans EX



(2) Consecutive Calculations

If the result of the last calculation is the first term of the next calculation, you can use the result as it is on the display without recalling Answer Memory contents.

To perform a consecutive calculation

Example To perform 0.57×0.27 , and then add 4.9672 to the results

AC 0 • 5 7 X 0 • 2 7 E

0.57×0.27 0<u>.1</u>539 Ans+4.9672

(3) Replay

While the result of a calculation is on the display, you can use () and () to move the cursor to any position within the expression used to produce the result. This means you can back up and correct mistakes without having to input the entire calculation. You can also recall past calculations you have already cleared by pressing ().

Operation

The first press of () displays the cursor at the beginning of the expression, while) displays the cursor at the end. Once the cursor is displayed, use () to move it right and () to move it left.

•To use Replay to change an expression

Example To calculate 4.12 ×	6.4 and then change the calculation to 4.12×7
æ 4 • 1 2 X 6	●④◎
۲	4.12×6.4_
●●●7・1 ∞	4.12×7.1 29.252

Multi-Replay

Pressing AC and then (a) or (c) sequentially recalls and displays past calculations.


(4) Error Recovery


Whenever an error message appears on the display, press ④ or to re-display the expression with the cursor located just past the part of the expression that caused the error. You can then move the cursor and make necessary corrections before executing the calculation again.

To correct an expression that causes an error

Example To recover from the error generated by performing 148 + 0. × 3.37 instead of 148 + 0.3 × 3.37

AC 1 4 8 ÷ 0 • X 3 • 3 7 ¤





2.362 [2], 36ª

Basic Calculations Chapter 2

sin [2] 36ª

• When you press [SHIFT [INS] a space is indicated by the symbol "[]". The next function or value you input is inserted at the location of "[]". To abort the insert operation without inputting anything, move the cursor, press [SHF] [INS] again, or press Or EXE.

7. Using Variables

SHIFT (INS)

sin

A total of 26 variables, named A through Z, are available for assignment of numeric values. Variable contents are retained even when you turn the calculator off. Note that when you assign a value to a variable, the calculator assigns its 15-digit internal value.

To assign a value to a variable


Operation

<value or expression> - (UPR) <variable name: A to Z>

Example 1 To assign 1024 to variable A 1024→A 1024 Example 2 To display the contents of variable A AC ALPHA A EXE A 1024 Example 3 To clear the contents of variable A To clear a variable, simply assign 0 to it. 0+A 0


3.4


3,1,4



13_20







(3) Changing the Fraction Simplification Mode

The initial default of the calculator is automatic simplification of fractions produced by fraction calculations. You can use the following operation to change the fraction simplification mode to manual.

•To change the fraction simplification mode

Example

To change the fraction simplification mode to manual

SHIFT SETUP (Displays the Set Up Screen.)



• • • • • F2 (Man)

		:Y= :Conct
1	Angle Display	Rad Nrm1
	Simplfy Auto Man	:Man
	(F2)	

When the fraction simplification is set to manual, you have to use the Option Menu to simplify fractions. You can let the calculator select the divisor to use for simplification or you can specify a divisor.

To simplify using the calculator's divisor

Operation


Perform calculations after selecting the RUN icon in the Main Menu to enter the RUN Mode.

To display the simplification menu: OPTN F2 (CALC)


To select automatic simplification: F1 (Simp) EXE

To specify the divisor for simplification*: F1(Simp) <Divisor>EXE

* You can specify only a positive integer as the divisor.




(The result that appears when using manual simplification is the least common multiple of the fractions used in the calculation.)



- F = 3 indicates that 3 is the divisor.
- The calculator automatically selects the smallest possible divisor for simplification.


Repeat the above operation to simplify again.

F1 (Simp) EVE



Try once again.

F1 (Simp) EXE




This display indicates that further simplification is impossible.

•To simplify using your own divisor

Example To perform the above calculation and then specify 9 as the divisor to use for simplification

F1 (Simp) 9 🕮



 If the value you specify is invalid as a divisor for simplification, the calculator automatically uses the lowest possible divisor.

Basic Calculations Chapter 2

9. Selecting Value Display Modes

You can make specifications for three value display modes.

Fix Mode

This mode lets you specify the number of decimal places to be displayed.

Sci Mode

This mode lets you specify the number of significant digits to be displayed.

Norm 1/Norm 2 Mode

This mode determines at what point the display changes over to exponential display format.

Display the Set Up Screen and use the (a) and (keys to highlight "Display".

	Dis	Play	2 : NI	~m1
e .		SCI		
. .	[]	F2		

- To specify the number of decimal places (Fix)
- 1. While the set-up screen is on the display, press F1 (Fix).
- 2. Press the function key that corresponds to the number of decimal places you want to set (0 to 9).
- Press D to display the next menu of numbers.

Example To specify two decimal places

Fiz Sci Norm

F1 (Fix)



F3 (2)

Display:Fix2

Press the function key that corresponds to the number of decimal places you want to specify.

· Displayed values are rounded off to the number of decimal places you specify.

• A number of decimal place specification remains in effect until you change the Norm Mode setting.

- To specify the number of significant digits (Sci)
- 1. While the set-up screen is on the display, press F2 (Sci).
- 2. Press the function key that corresponds to the number of significant digits you want to set (0 to 9).
- Press D to display the next menu of numbers.

To specify three significant digits Example



F4 (3)

F2 (Sci)

Press the function key that corresponds to the number of significant digits you want to specify.

- · Displayed values are rounded off to the number of significant digits you specify.
- Specifying 0 makes the number of significant digits 10.
- · A number of significant digit specification remains in effect until you change the Norm Mode setting.
- To specify the exponential display range (Norm 1/Norm 2)
 - Press F3 (Norm) to switch between Norm 1 and Norm 2. Norm 1: $10^{-2}(0.01) > |x|, |x| \ge 10^{10}$ Norm 2: $10^{-9}(0.00000001) > |x|, |x| \ge 10^{10}$

10. Scientific Function Calculations

Use the RUN Mode to perform calculations that involve trigonometric functions and other types of scientific functions.

(1) Trigonometric Functions

Before performing a calculations that involves trigonometric functions, you should first specify the default angle unit as degrees (°), radians (r), or grads (g).

Setting the Default Angle Unit

The default angle unit for input values can be set using the set up screen. If you set degrees (°) for example, inputting a value of 90 is automatically assumed to be 90° The following shows the relationship between degrees, radians, and grads.

 $90^\circ = \pi/2$ radians = 100 grads

•To set the default angle unit

Example To change the angle unit from radians to degrees

SHIFT SET UP

-Туре :Ү= D-Type :Conct Angle :Rad Display:Nrm1 Simplfy:Auto

Basic Calculations Chapter 2

(Deg)





· Once you change the angle unit setting, it remains in effect until you change it again using the set up screen. You also should check the set up screen to find out what the current angle unit setting is.

Converting Between Angle Units

You can use the following procedure to input a value using an angle unit that is not the current default angle unit. Then when you press ERE, the value will be converted to the default angle unit.

To convert between angle units





Note that certain publications use "log" to refer to base e logarithms, so you must take care to watch for what type of notation is being used in the publications you are working with. This calculator and manual use "log" to mean base 10 and "ln" for base e.

Example 1	log1.23	
log	1 • 2 3 🛤	
		Result: 0.0899051114
Example 2	in90	
In	90 🕮	
		Result: 4.49980967
Example 3	To calculate the anti-logarithm of	common logarithm 1.23 (10 ^{1.23})
SHIFT	101 • 2 3 00	
		Result: 16.98243652
Example 4	To calculate the anti-logarithm of	natural logarithm 4.5 (e ^{4.5})
SHIFT] @ 4 • 5	
		Result: 90.0171313
Example 5	$(-3)^4 = (-3) \times (-3) \times (-3) \times (-3)$	
C	@ 3) ∧ 4 ∞	
		Result: 81
· · · · · · · · · · · · · · · · · · ·	7. 192	


Result: 1.988647795

Example	Operation	Display		
$\sqrt{2} + \sqrt{5} = 3.65028154$	\$	3.65028154		
$(-3)^2 = (-3) \times (-3) = 9$	() (□) 3() 27 02	9		
$-3^2 = -(3 \times 3) = -9$	[−] 3 <u>2</u> ? EE	- 9		
$\frac{1}{\frac{1}{3} - \frac{1}{4}} = 12$	(3907 21 — 4907 21) 907 21 EE	12		
8! (= 1 × 2 × 3 × × 8) = 40320	8@M F4(PROB)F1(x!)E	40320		
$\sqrt[3]{36 \times 42 \times 49} = 42$	SHFT 🐨 (36 🗙 42 🗙 49)) EXE	42		
Random number generation (pseudo random number between 0 and 1.)	@TN F4 (PROB) F4 (Ran#)@2	(Ex.) 0.4810497011		

Example	Operation	Display
What is the absolute value of the common logarithm of $\frac{3}{4}$?		
$ \log \frac{3}{4} = 0.1249387366$	@711 ▷ F1 (NUM) F1 (Abs) (3 - 4)	0.1249387366
What is the integer part of $\frac{7800}{96}$?	@7N) [>[F] (NUM) [F2 (Int) (] 7800 (-) 96 ()] [E2	81
What is the decimal part of 7800 ?	@711 [> [F1 (NUM) [F3 (Frac) (7800 - 96)	0.25
200 ÷ 6 = × 3 = Round the value used for internal calculations to 11 digits*	200 급 6 年 又 3 年 200 급 6 年 6 年 6 年 (NUM) 伊 (Rnd) 年 又 3 年	33.33333333 100 33.33333333 33.33333333 99.999999999
What is the nearest integer not exceeding – 3.5?	@TN ▷ F1 (NUM) ▷ F1 (Intg) ○ 3.5 EE	- 4

* When a Fix (number of decimal places) or Sci (number of significant digits) is in effect, Rnd rounds the value used for internal calculations in accordance with the current Fix or Sci specification. In effect, this makes the internal value match the displayed value.

(4) Coordinate Conversion



• With polar coordinates, θ can be calculated and displayed within a range of $-180^{\circ} < \theta \le 180^{\circ}$ (radians and grads have same range).

Display
Ans $1 \begin{bmatrix} 24.989\\ 55.928 \end{bmatrix} \rightarrow 24.98979792 (r)$ $2 \begin{bmatrix} 55.928 \end{bmatrix} \rightarrow 55.92839019 (\theta)$

Basic Calculations Chapter 2

Opera	ntion		Display
907 90 € € (ANGL) 979 ▷ 72 (ANGL) 72 (Rec()25 € 56	DD	Ans 1 [<u>13.979</u>] 2 _20.725.] → 13.97982259 (x)→ 20.72593931 (y)
······································			
5) Permutation • Permutation		ation nbination	
	• Cor		
$n\Pr = \frac{n!}{(n-r)!}$ Example To cal	• Cor <i>n</i> Cr culate the possil	nbination	

Formula	Operation	Display	
10P4 = 5040	10 (PROB) F2 (nPr)4 EXE		
		<u> </u>	

Example To calculate the possible number of different combinations of 4 items that can be selected from among 10 items

Formula	Operation	Display
10C4 = 210	10 @FN F4 (PROB) F3 (nCr)4 EXE	210

(6) Other Things to Remember

Multiplication Sign

You can leave out the multiplication sign in any of the following cases.


- · In front of the following scientific functions:
- sin, cos, tan, sin⁻¹, cos⁻¹, tan⁻¹, log, In, 10^r, e^r , $\sqrt{-}$, $\sqrt{-}$, Pol(x, y), Rec(r, θ), d/dx, Seq, Min, Max, Mean, Median, List, Dim, Sum
- Examples: 2 sin30, 10log1.2, 2 √3, etc.
- · In front of constants, variable names, Ans memory contents.
- Examples: 2n, 2AB, 3Ans, 6X, etc.
- · In front of an open parenthesis.
- Examples: 3(5 + 6), (A + 1)(B 1)

Basic Calculations Chapter 2

Calculation Priority Sequence

The calculation priority sequence is the order that the calculator performs operations. Note the following rules about calculation priority sequence.

- Expressions contained in parentheses are performed first.
- When two or more expressions have the same priority, they are executed from right to left.



The following is a complete list of operations in the sequence they are performed.

- Coordinate transformation: (Pol (x, y), Rec (r, θ); differential calculations: d/dx(; List: Fill, Seq, Min, Max, Mean, Median, SortA, SortD
- Type A functions (value input followed by function): x², x⁻¹, x! sexagesimal input: ° ' "

4

5

6

- 3. Powers: (x^y) ; roots: $\sqrt{}$
- 4. Fraction input: a^b/c
- 5. Multiplication operations where the multiplication sign before π or a variable is omitted: 2π ; 5A; $3\sin x$; etc.
- 6. Type B functions (function followed by value input):

 $\sqrt{}$, $\sqrt{}$, log, ln, e^x , 10^x, sin, cos, tan, sin⁻¹, cos⁻¹, tan⁻¹, (-), Dim, Sum

- Multiplication operations where the multiplication sign before a scientific function is omitted: 2√3; Alog2; etc.
- 8. Permutation: nPr; combination: nCr
- 9. Multiplication; division; integer division; remainder division
- 10. Addition; subtraction
- 11. Relational operators: =, \pm , >, <, ≥, ≤

Using Multistatements

Multistatements are formed by connecting a number of individual statements for sequential execution. You can use multistatements in manual calculations and in programmed calculations. There are two different ways that you can use to connect statements to form multistatements.


• Colon (:)

Statements that are connected with colons are executed from left to right, without stopping.

Display Result Command (A)

When execution reaches the end of a statement followed by a display result command, execution stops and the result up to that point appears on the display. You can resume execution by pressing the \mathbb{E} key.

To use multistatements



 Note that the final result of a multistatement is always displayed, regardless of whether it ends with a display result command.

 You cannot construct a multistatement in which one statement directly uses the result of the previous statement.

Example 123 × 456: × 5

Stacks

When the calculator performs a calculation, it temporarily stores certain information in memory areas called a "stacks" where it can later recall the information when it is necessary.

There are actually two stacks: a 10-level numeric stack and a 26-level command stack. The following example shows how data is stored in the stacks.

 $2 \times ((3+4 \times (5+4) \div 3) \div 5) + 8 =$ 2 3 — Numeric stack নিহার্ট্র 🖪 🗕 - Command stack



A calculation can become so complex that it requires too much stack memory and cause a stack error (Stk ERROR) when you try to execute it. If this happens, try simplifying your calculation or breaking it down into separate parts. See "How to Calculate Memory Usage" for details on how much memory is taken up by various commands.

Basic Calculations Chapter 2

Errors

An error message appears on the display and calculation stops whenever the calculator detects some problem. Press AC to clear the error message.

The following is a list of all the error messages and what they mean.

Ma ERROR - (Mathematical Error)

- A value outside the range of $\pm 9.99999999 \times 10^{99}$ was generated during a calculation, or an attempt was made to store such a value in memory.
- An attempt was made to input a value that exceeds the range of the scientific function being used.
- · An attempt was made to perform an illegal statistical operation.

Stk ERROR - (Stack Error)

 The calculation being performed caused the capacity of one of the stacks to be exceeded.

Syn ERROR - (Syntax Error)

An attempt to use an illegal syntax.

Arg ERROR - (Argument Error)

An attempt to use an illegal argument with a scientific function.

Dim ERROR - (Dimension Error)

 An attempt to perform an operation with two or more lists when the dimensions of the lists do not match.

In addition to the above, there are also a Mem ERROR and Go ERROR. See "Error Message Table" for details.

How to Calculate Memory Usage

Some key operations take up one byte of memory each, while others take up two bytes.

1-byte operations: 1, 2, 3, ..., sin, cos, tan, log, ln, $\sqrt{-}$, π , etc.


2-byte operations: d/dx(, Xmin, If, For, Return, DrawGraph, SortA(, Sum, etc.

Memory Status (MEM)

You can check how much memory is used for storage for each type of data. You can also see how many bytes of memory are still available for storage.

To check the memory status

1. In the Main Menu, select the MEM icon and press Exe.







 Use and to move the highlighting and view the amount of memory (in bytes) used for storage of each type of data.

The following table shows all of the data types that appear on the memory status screen.


Data type	Meaning
Program	Program data
Stat	Statistical calculations and graphs
List	List data
Y=	Graph functions
Draw	Graph drawing conditions (View Window, enlargement/reduction factor, graph screen)
V-Win	View Window memory data
Table	Table & Graph data
Alpha	Alpha memory data


Clearing Memory Contents

•To clear all data within a specific data type

1. In the memory status screen, use () and () to move the highlighting to the data type whose data you want to clear.

P.199





The following menu appears whenever you press F3 (GRPH) while the statistical data menu is on the display. F3 (GRPH) Ű, F1 F4 F1(a)-F3(c)... Statistical graph regression coefficient and multinomial coefficients [F4] (r) Statistical graph correlation coefficient \triangleright Q1 Med Moe · 🖸 🖛 F4 FI (F3) F1 (Q1) First quartile F2 (Med) Median of input data F3 (Q3) Third quartile F4 (Mod) Mode of input data Press D to return to the previous menu. The following menu appears whenever you press [F4] (PTS) while the statistical data menu is on the display. F4 (PTS) 211 F4 FI F2 F3 [F1](x1)-[F4](y2) Coordinates of summary points \square X3 X3 (F1) [F2] [F1] (x3)- [F2] (y3) Coordinates of summary points Press D to return to the previous menu. To recall graph functions Pressing [>] and then [F2] (GRPH) while the variable data menu is on the screen displays a graph function menu. F2 (GRPH)

Basic Calculations Chapter 2

F3

F1 F2


Input a storage area number and then press one of the following function keys to recall the corresponding graph function stored in that storage area.

- F1 (Y) Rectangular coordinate or inequality function
- F2 (Xt) Parametric graph function Xt
- F3 (Yt) Parametric graph function Yt

•To recall Table & Graph table range and table content data

Pressing \triangleright and then F3 (TABL) while the variable data menu is on the screen displays a Table & Graph data menu.

F3(TABL)



F1 (Strt) Table range start value (F Start command)

F2 (End) Table range end value (F End command)

F3 (Pitch) Table value increment (F Pitch command)



Differential Calculations


Chapter 3 **Differential Calculations**

d/dx(X^3+4X2+

 $d/dx(X^3+4X^2+$

d/dx(X^3+4X²+ X-6,3,1E-5)_

d/dx(X^3+4X²+ X-6,3,1E-5)__



term.

difference. To calculate derivatives, the unit takes the average between the value of $\Delta y/\Delta x$ and $\nabla y/\nabla x$, thereby providing higher precision for derivatives.

0

y = f(x) are as follows:

Chapter 3 Differential Calculations



- Pressing C during calculation of a differential (while the cursor is not shown on the display) interrupts the calculation.
- Always perform trigonometric differentials using radians (Rad Mode) as the angle unit.





Graphing

A collection of versatile graphing tools plus a large 79×47 -dot display makes it easy to draw a variety of function graphs quickly and easily. This calculator is capable of drawing the following types of graphs.

- Rectangular coordinate (Y =) graphs
- Parametric graphs
- Inequality graphs
- A selection of graph commands also makes it possible to incorporate graphing into programs.
- 1. Before Trying to Draw a Graph
- 2. View Window (V-Window) Settings
- 3. Graph Function Operations
- 4. Drawing Graphs Manually
- 5. Other Graphing Functions

Graphing Chapter 4

1. Before Trying to Draw a Graph

Entering the Graph Mode

On the Main Menu, select the GRAPH icon and enter the GRAPH Mode. When you do, the Graph Function (G-Func) menu appears on the display. You can use this menu to store, edit, and recall functions and to draw their graphs.

G-Func :Y= Y1: Memory area Υ<u>2</u> Use (and () to change selection. Y4: SEL UEL DRAW F2

- F1 (SEL) Draw/non-draw status
- F2 (DEL) Graph delete
- F4 (DRAW) Draws graph

2. View Window (V-Window) Settings

Use the View Window to specify the range of the x-and y-axes, and to set the spacing between the increments on each axis. You should always set the View Window parameters you want to use before drawing a graph. Press [317] F3 to display the View Window.

1. Press SHFT F3 to display the View Window.

SHFT F3 (V-Window)

V-W: ma: sc.	χ:	ιW -	8 9 3.9 1
INIT	TRIG	Sto	Rcl


F4

F1 (INIT) View Window initial settings


- F2 (TRIG) View Window initial settings using specified angle unit
- F3 (Sto) Store View Window settings to View Window memory.
- F4 (Rcl) Recall View Window settings from View Window memory.
- Xmin Minimum x-axis value
- Xmax Maximum x-axis value
- Xscl Spacing of x-axis increments

- 2. Input a value for a parameter and press EXE. The calculator automatically selects the next parameter for input.
 - You can also select a parameter using the 🕤 and 🛆 keys. .

	V-Window	
	Ymin: -:	2.3
20	max	Z. Ş.
	scl:	1
ł.		
	INIT TRIG Sto	Rcl




The following illustration shows the meaning of each of these parameters.




- 3. Input a value for a parameter and press EXE. The calculator automatically selects the next parameter for input.
- There are actually nine View Window parameters. The remaining three parameters appear on the display when you move the highlighting down past the Y scale parameter by inputting values and pressing (.





The following illustration shows the meaning of each of these parameters.



Graphing Chapter 4

Chapter 4 Graphing

Ø

- 4. To exit the View Window, press QUIT
- Pressing x without inputting any value also exits the View Window.
- The following is the input range for View Window parameters. -9.99E+97 to 9.999E+97
- You can input parameter values up to 7 digits long. Values greater than 10⁶ or less than 10⁻¹, are automatically converted to a 4-digit mantissa (including negative sign) plus a 2-digit exponent.
- The existing value remains unchanged if you input a value outside the allowable range or in the case of illegal input (negative sign only without a value).
- Inputting a View Window range so the min value is greater than the max value, causes the axis to be inverted.
- You can input expressions (such as 2π) as View Window parameters.
- When the View Window setting does not allow display of the axes, the scale for the y-axis is indicated on either the left or right edge of the display, while that for the x-axis is indicated on either the top or bottom edge.
- When View Window values are changed, the graph display is cleared and the newly set axes only are displayed.
- · View Window setting may cause irregular scale spacing.
- Setting maximum and minimum values that create too where of a View Window range can result in a graph made up of disconnected lines (because portions of the graph run off the screen), or in graphs that are inaccurate.
- The point of deflection sometimes exceeds the capabilities of the display with graphs that change drastically as they approach the point of deflection.
- Setting maximum and minimum values that create to narrow of a View Window range can result in an error (Ma ERROR).

Initializing and Standardizing the View Window

•To initialize the View Window

a. Press SHET F3 (V-Window) F1 (INIT) to initialize the View Window to the following settings.

Xmin	= -3.9	Ymin	= -2.3
Xmax	= 3.9	Ymax	= 2.3
Xscl	= 1	Yscl	= 1

b. Press See F3 (V-Window) F2 (TRIG) to initialize the View Window to the following settings.

Deg Mode

Xmin	=-360	Ymin	=	-1.6
Xmax	= 360	Ymax	=	1.6
Xscl	= 90	Yscl	=	0.5

Rad Mode

Xmin =	-6.28318
Xmax =	6.28318
Xsci =	1.57079

Gra Mode

75

- Xmin = -400
- Xmax = 400
- Xscl = 100
- The settings for Ymin, Ymax, Ypitch, Tmin, Tmax, and Tpitch remain unchanged when you press (F2) (TRIG).

View Window Memory

You can store a set of View Window settings in View Window memory for recall when you need them.

•To save View Window settings

While the View Window setting screen is on the display, press 🛐 (Sto) to save the current settings.

Whenever you save View Window settings, any settings previously stored in memory are replaced.

To recall View Window settings

While the View Window setting screen is on the display, press (F4) (Rcl) to recall the View Window settings stored in memory.


 Whenever you recall View Window settings, the settings on the View Window are replaced by the recalled settings.

You can change View Window settings in a program using the following syntax.

View Window [Xmin value], [Xmax value], [Xscl value], [Ymin value], [Ymax value], [Yscl value], [Tmin value], [Tmax value], [Tptch value]

Chapter 4 Graphing

Graphing Chapter 4




 You will not be able to store the expression in an area that already contains a parametric function. Select another area to store your expression or delete the existing parametric function first. This also applies when storing inequalities.

•To store a parametric function

Example To store the following functions in memory areas Xt2 and Yt2:

x = 3 sin T y = 3 cos T


(Specifies parametric expression.)



Xt2**0**3sin T

3 sin X.1 EXE (Inputs and stores x expression.)

3 (Inputs and stores y expression.)



 You will not be able to store the expression in an area that already contains a rectangular coordinate expression or inequality. Select another area to store your expression or delete the existing expression first.

•To store an inequality

EXE

Example To store the following inequality in memory area Y3: $y > x^2 - 2x - 6$

 Image: Specifies an inequality.)


 Image

(Stores expression.)



G-Func :Y> Y30X2-2X-6 W1 Y5: Y6: [SEL DEL DRAW

Chapter 4 Graphing



You can specify which functions out of those stored in memory should be used for a draw operation.

Graphs for which there is no draw/non-draw status specification are not drawn.

Example To select the following functions for drawing:

> $Y1: y = 2x^2 - 5$ Xt2: $x = 3 \sin T$ Yt2: $y = 3 \cos T$

Use the following View Window parameters.

Xmin	=5	Ymin	= -	-5
Xmax	= 5	Ymax	=	5
Xscl	= 1	Yscl	=	1

(Select a memory area that contains a

function for which you want to specify

-Func :Y> 1<u>82X</u>2-5 .283sin .283cos /SDX2-2X-6 SEL DE DRAW

F1

F1(SEL) (Specify non-draw.)

 $\odot \odot \odot$

non-draw.)



Unhighlights -

F4 (DRAW) or EXE (Draws graphs.)

Ø


Pressing G-T or AC returns to the Graph Function Menu.

 A parametric graph will appear coarse if the settings you make in the View Window cause the pitch value to be too large, relative to the differential between the min and max settings. If the settings you make cause the pitch value to be too small relative to the differential between the min and max settings, on the other hand, the graph will take a very long time to draw.

4. Drawing Graphs Manually


After you select the RUN icon in the Main Menu and enter the RUN Mode, you can draw graphs manually. First press (MF) F4 (SKTCH) F2 (GRPH) to recall the Graph Command Menu, and then input the graph function.


SHIFT F4 (SKTCH) F2 (GRPH)



F1 (Y =) Rectangular coordinate graph [F2] (Parm) Parametric graph

55





Use the following View Window parameters. Xmin = -20 Ymin = -12Xmax = 20 Ymax = 12 5 Xsci = 5 Yscl = Tmin = * * 0 Tmax = 2π Totch $= \pi \div 36$

1. In the set-up screen, specify the appropriate graph type for F-Type.


SHFT SETUP F2 (Parm)

2. Set the default angle unit to radians (Rad).

▼ ▼ F2 (Rad) @UT

3. Input the parametric functions.


AG Sem [F4] (SKTCH) [F1] (CIS) [522 [F2] (GRPH) [F2] (Parm) [7] [668 [K]] — [2] [668 [3] [K]] • [7] [668 [K]] — [2] [668 [3] [K]] •



Graphing Chapter 4

4. Press EXE to draw the graph.

EXE



To graph inequalities

You can graph inequalities that can be expressed in the following four formats.

• y > f(x)• y < f(x)• $y \ge f(x)$ • $y \ge f(x)$

ExampleTo graph the inequality $y > x^2 - 2x - 6$ Use the following View Window parameters.Xmin = -6Ymin = -10

Kmax	=	6		Ymax	=	10
(scl	=	1		Ysci	=	5

1. In the set-up screen, specify the appropriate graph type for F-Type.


SHIFT SETUP 🕞 F1 (Y>) QUIT

2. Input the inequality.

3


-

AC SHIT F4(SKTCH)F1(Cls) EE F2(GRPH) ▷ F1(Y>) KT 52 - 2 KT - 6



3. Press EXE to draw the graph.

EXE



5. Other Graphing Functions

The functions described in this section tell you how to read the *x*- and *y*-coordinates at a given point, and how to zoom in and zoom out on a graph.

• These functions can be used with rectangular coordinate, parametric, and inequality graphs only.



Connect Type and Plot Type Graphs (D-Type)


You can use the D-Type setting of the set-up screen to specify one of two graph types.

· Connect type (Conct)

Points are plotted and connected by lines to create a curve.


• Plot

Points are plotted without being connected.




1. After drawing the graphs, press F1 (TRCE) to display the pointer in the center of the graph.





• The pointer may not be visible on the graph when you press F1 (TRCE).

2. Use (to move the pointer to the first intersection.




Graphing Chapter 4

Graphing Chapter 4

- Pressing (and) moves the pointer along the graph. Holding down either key moves the pointer at high speed.
- 3. Use (and () to move the pointer between the two graphs.
- 4. Use () to move the pointer to the other intersection.

۵ ~ ک



• To guit the trace operation, press [F1] (TRCE) again.

Scrolling

When the graph you are tracing runs off the display along either the x- or y-axis, pressing the () or () cursor key causes the screen to scroll in the corresponding direction eight dots.

- · You can scroll only rectangular coordinate and inequality graphs while tracing. You cannot scroll parametric function graphs.
- Trace can be used only immediately after a graph is drawn. It cannot be used after changing the settings of a graph.
- You cannot incorporate trace into a program.
- · You can use trace on a graph that was drawn as the result of an output command (\blacktriangle), which is indicated by the "-Disp-" indicator on the screen.

Scroll

You can scroll a graph along its x- or y-axis. Each time you press $(\mathbf{O}, \mathbf{O}, \mathbf{O})$, or (E), the graph scrolls 12 dots in the corresponding direction.


Overwrite

Using the following syntax to input a graph causes multiple versions of the graph to be drawn using the specified values. All versions of the graph appear on the display at the same time.

> <function with one variable> • SHET [<variable name> SHET = <value> • <value> • <value> MFT] EXE

Use the following View	Window	parame	eters.	
Xmin = -5	Ymin	=-10		
Xmax = 5	Ymax	= 10		
Xscl = 1	Yscl	= 2		
≥ F1(Y =)			G-Func : Y1BAX2-3	Y=
(Specifies graph type.)			Y18AX2-3	, [A=
APHA A K.T 22 - 3 •			SEL DEL	DRAW
SHIFT [] ALPHA (A) SHIFT (=) (3) (4)	כ			(F4)
1 • 🖂 1 SHFT] EXE				ب
(Stores expression.)				
F4 (DRAW) or EXE			1 1	/ •

To graph $y = Ax^2 - 3$, substituting 3, 1, and -1 for the value of A



- The function that is input using the above syntax can have only one variable.
- You cannot use X, Y or T as the variable name.

P8

Example

(Draws graph.)

- · You cannot assign a variable to the variable in the function.
- . When the set-up screen's Simul-G item is set to "On," the graphs for all the variables are drawn simultaneously.



Zoom

The zoom feature lets you enlarge and reduce a graph on the display.

Before using zoom

Immediately after drawing a graph, press [SHF] [F2] (ZOOM) to display the Zoom Menu.



F1 (BOX) Graph enlargement using box zoom

F2 (FACT) Displays screen for specification of zoom factors

F3 (IN) Enlarges graph using zoom factors

F4 (OUT) Reduces graph using zoom factors

⊵

ORIG F1

F4 D

F1 (ORIG) Original size

Press [>] to return to the previous menu

•To use box zoom

With box zoom, you draw a box on the display to specify a portion of the graph, and then enlarge the contents of the box.


Example To use box zoom to enlarge a portion of the graph y = (x + 5)(x + 4) (x + 3)

Use the following View Window parameters.

Xmin	= -	-8	Ymin	=	-4
Xmax	=	8	Ymax	=	2
Xsci	=	2	Ysci	=	1


1. After graphing the function, press SHFT F2 (ZOOM).

SHFT F2 (ZOOM)



2. Press F1 (BOX), and then use the cursor keys ((3, (), (), ()) to move the pointer to the location of one of the corners of the box you want to draw on the screen. Press EXE to specify the location of the corner.






Graphing Chapter 4


3. Use the cursor keys to move the pointer to the location of the corner that is diagonally across from the first corner.

A ~
 A ~
 A
 A ~
 A
 A ~
 A
 A ~
 A
 A ~
 A
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A ~
 A




4. Press Exe to specify the location of the second corner. When you do, the part of the graph inside the box is immediately enlarged so it fills the entire screen.





• To return to the original graph, press F2 (ZOOM) [> F1 (ORIG).



· You can use box zoom for any type of graph.

To use factor zoom

With factor zoom, you can zoom in or zoom out on the display, with the current pointer location being at the center of the new display.

• Use the cursor keys ((), (), (), () to move the pointer around the display.

Example


Graph the two functions below, and enlarge them five times in order to determine whether or not they are tangential:

Y1: y = (x + 4) (x + 1) (x - 3)Y2: y = 3x + 22


Graphing Chapter 4

- Use the following View Window parameters. Xmin = -8 Ymin = -30 Xmax = 8 Ymax = 30 Xscl = 5 Yscl = 10
- 1. After graphing the functions, press (MIT) (ZOOM), and the pointer appears on the screen.

SHIFT F2 (ZOOM)




- Use the cursor keys (④, ●, ④, ④) to move the pointer to the location that you want to be the center of the new display.




3. Press (E2) (FACT) to display the factor specification screen, and input the factor for the x- and y-axes.

F2(FACT) 5 EE 5 EE



4. Press (UIII) to return to the graphs, and then press F3 (IN) to enlarge them.

QUIT F3 (IN)



This enlarged screen makes it clear that the graphs of the two expressions are not tangential.

• Note that the above procedure can also be used to reduce the size of a graph (zoom out). In step 4, press [F4] (OUT).

- The above procedure automatically converts the *x*-range and *y*-range View Window values to 1/5 of their original settings.
- You can repeat the factor zoom procedure more than once to further enlarge or reduce the graph.

•To initialize the zoom factor

Press (E2) (ZOOM) (E2) (FACT) (F1) (INIT) to initialize the zoom factor to the following settings.

Xfct = 2 Yfct = 2

Ņ

 You can use the following syntax to incorporate a factor zoom operation into a program.

Factor <X factor>, <Y factor>

You can use factor zoom for any type of graph.

Sketch Function

The sketch function lets you draw lines and graphs on an existing graph.

Note that Sketch function operation in the STAT, GRAPH or TABLE Mode is different from Sketch function operation in the RUN or PRGM Mode.

Before using the Sketch Function

Press SHET F4 (SKTCH) to display the sketch menu.

In the STAT, GRAPH or TABLE Mode

	CIS	ſ	PLOT	IRP	
F1 (Cls) Clears drawn line and point F3 (PLOT) Displays plot menu F4 (LINE) Displays line menu	FI		F3	F4	Þ
	Vert	Hzt1			
印 (Vert) Vertical line [1] (Hztl) Horizontal line	F1	F2			Þ
Press 🕞 to return to the previous menu					
In the RUN or PRGM Mode					
आता निये (SKTCH)	<u>C15</u>	GRAH	PLOP	LIHP	
	FI	F2	F3	F4	⊳

wee the

VertHztl F1 F2

• Other menu items are identical to those in the STAT, GRAPH, TABLE Mode menu.

The Sketch function lets you draw lines and plot points on a graph that is already on the screen.

All the examples in this section that show operations in the STAT, GRAPH or TABLE Mode are based on the assumption that the following function has already been graphed in the **GRAPH Mode**.

The following are the View Window parameters used when drawing the graph.

Xmin	= :	-5	Ymin	=	5
Xmax	=	5	Ymax	=	5
Xscl	=	1	Yscl	=	1

To plot points

In the STAT, GRAPH or TABLE Mode


Example To plot a point on the graph of y = x(x + 2)(x - 2)

 After graphing the function, display the sketch menu and perform the following operation to cause the pointer to appear on the graph screen.

SHFT F4 (SKTCH) F3 (PLOT) F1 (Plot)

- Use the cursor keys (♠, ♥, ♥, ♥) to move the pointer the locations of the points you want to plot and press to plot.
- You can plot as many points as you want.

• • • • EXE



 The current x- and y-coordinate values are assigned respectively to variables X and Y. In the RUN or PRGM Mode

The following is the syntax for plotting points in these modes.

Plot <x-coordinate>, <y-coordinate>

Example To plot a point at (2, 2)


Use the following View Window parameters.

Xmin	= -5		Ymin	=-10	
Xmax	= 5		Ymax	= 10	
Xscl	= 1	•	Ysci	= 2	

1. After entering the RUN Mode, display the sketch menu and perform the following operation.


 Image: Fige (SKTCH) Fige (Cls) Exercise

 Fig (PLOT) Fige (Plot) 2 • 2





EXE EXE



• You can use the cursor keys (ⓐ, ⑦, ④, ⑥) to move the pointer around the screen.

- If you do not specify coordinates, the pointer is located in the center of the graph screen when it appears on the display.
- If the coordinates you specify are outside the range of the View Window parameters, the pointer will not be on the graph screen when it appears on the display.

 The current x- and y-coordinate values are assigned respectively to variables X and Y.

Memory Area Y1: y = x(x + 2)(x - 2)

Graphing Chapter 4

•To turn plot points on and off in the STAT, GRAPH and TABLE Modes

• To turn a plot point on

 After drawing a graph, display the sketch menu and then perform the following operation to make the pointer appear at the center of the screen.

SHIFT F4 (SKTCH) F3 (PLOT) F2 (P-On)

 Use the cursor keys (𝔅), 𝔅), 𝔅) to move the pointer to the location where you want to plot a point and then press 𝔅.

. To turn a plot point off

Perform the same procedure as described under "To turn a plot point on" above, except press F3 (P-Off) in place of F2 (P-On).

. To change the on/off status of a plot point

Perform the same procedure as described under "To turn a plot point on" above, except press F4 (P-Chg) in place of F2 (P-On).

•To turn plot points on and off in the RUN or PRGM Mode

The following are the syntax for turning plot points on and off in these modes.

• To turn a plot point on

PlotOn <x-coordinate>, <y-coordinate>

• To turn a plot point off

PlotOff <x-coordinate>, <y-coordinate>

• To change the on/off status of a plot point PlotChg <x-coordinate>, <y-coordinate>

•To draw a line between two plotted points

In the STAT, GRAPH or TABLE Mode

Example To draw a line between the two points of inflection on the graph of y = x(x + 2)(x - 2)


Use the same View Window parameters as in the example on page 66.

1. After graphing the function, display the sketch menu and perform the following operation to cause the pointer to appear on the graph screen.

SHFT F4 (SKTCH) F3 (PLOT) F1 (Plot)


 Use the cursor keys ((3), (7), (8), (8)) to move the pointer to one of the points of inflection and press (19) to plot it.

• • • • •
• • • • •




3. Use the cursor keys to move the pointer to the other point of inflection.

• • • • •



Display the sketch menu and perform the following operation to draw a line between the two points.

SHFT F4 (SKTCH) F4 (LINE) F1 (Line)







- Example To draw a line between two points of inflection on the graph of y = x(x + 2)(x 2)
- After graphing the function, display the sketch menu and perform the following operation to cause the pointer to appear on the graph screen.

SHFT F4 (SKTCH) F4 (LINE) F2 (F-Lin)

- Use the cursor keys (④, ⑦, ④, ⑥) to move the pointer to one of the points of inflection and press .



- 3. Use the cursor keys to move the pointer to the other point of inflection and press E to draw the line.
 - ~ ● ~ EÆ



•To draw a line in the RUN or PRGM Mode

The following is the syntax for drawing lines in these modes.

F-Line <x-coordinate 1>, <y-coordinate 1>, <x-coordinate 2>, <y-coordinate 2>

In the RUN or PRGM Mode


Example To draw a line perpendicular to the x-axis from point (x, y) = (2, 6)on the graph y = 3x

Use the following View Window parameters:

Xmin	= -2	Ymin	=	-2
Xmax	= 5	Ymax	=	10
Xscl	= 1	Ysci	=	2


After drawing the graph, use the procedure under "To plot points" to move the pointer to (x, y) = (2, 0), then use the cursor key (▲) to move the pointer on the graph y = 3x.

8477 F4 (SKTCH) F3 (PLOT) F1 (Plot) 2 ● 0 555 555 € ~ ●



2. Display the sketch menu and perform the following operation to draw a straight line between the two points.

(SKTCH) F4 (LINE) F1 (Line) 5년



 The above draws a straight line between the current pointer location and the previous pointer location.

To draw vertical and horizontal lines

The procedures presented here draw vertical and horizontal lines that pass through a specific coordinate.

In the STAT, GRAPH or TABLE Mode


Example To draw a vertical line on the graph of y = x(x + 2)(x - 2)

 After graphing the function, display the sketch menu and perform the following operation to display the pointer and draw a vertical line through its current location.

SHIFT F4 (SKTCH) F1 (Vert)

Ø

- 2. Use the (1) and (1) cursor keys to move the line left and right, and press [2] to draw the line at the current location.
 - ۵ ~ ک



• To draw a horizontal line, simply press F2 (Hztl) in place of F1 (Vert), and use the () and () cursor keys to move the horizontal line on the display.

In the RUN or PRGM Mode

The following is the syntax for drawing vertical and horizontal lines in these modes.

• To draw a vertical line

Vertical <x-coordinate>

To draw a horizontal line

Horizontal <y-coordinate>

To clear drawn lines and points

The following operation clears all drawn lines and points from the screen.

In the STAT, GRAPH or TABLE Mode

Lines and points drawn using sketch menu functions are temporary. Display the sketch menu and press F1 (CIs) to clear drawn lines and points, leaving only the original graph.

In the RUN or PRGM Mode

The following is the syntax for clearing drawn lines and points, as well as the graph itself.

Cls

Table & Graph

The Table & Graph menu makes it possible to generate numeric tables from functions stored in memory. You can also use multiple functions to generate tables. Since Table & Graph uses the same list of functions that the GRAPH Mode uses for graphing, there is no need to input the same functions in different modes.

Chapter 5

- You can specify the range and increment of values assigned to variables for table value generation.
- You can assign list values to variables.
- In addition to graphing of stored functions, you can also plot table values generated by Table & Graph itself.
- Table values can be assigned to a list.
- 1. Storing a Function
- 2. Deleting a Function
- 3. Assigning Values to a Variable
- 4. Generating a Numeric Table
- 5. Editing a Table
- 6. Graphing a Function
- 7. Assigning Numeric Table Contents to a List

Chapter 5 Table and Graph

P.8

P.52

To enter the Table Mode, press (IIIII) to display the Main Menu, use the cursor keys to select the **TABLE** icon, and then press (IIII).



This is the initial Table Mode screen. To generate a table, you must first specify the variable range.



The menu at the bottom of the display looks like the one shown here when the Var item of the set-up screen is set to a list name (indicating that variable values should be obtained from a list).

1. Storing a Function

Example To store the function $y = 3x^2 - 2$ in memory area Y1

Use A and O to move the highlighting in the TABLE Mode function list to the memory area where you want to store the function. Next, input the function and press IIII to store it.

2. Deleting a Function

Use O and O to move the highlighting to the memory area that contains the function you want to delete.

Press F2 (DEL).

Press F) (YES) to delete the selected function or F4 (NO) to abort the delete operation without deleting anything.

The procedures for storing and deleting functions are identical to those used in the GRAPH Mode.

3. Assigning Values to a Variable

You can use either one of two methods to assign values to a variable: automatic assignment within a specified range, and assignment of values from a list. The standard default method is automatic assignment within a specified range.

Table and Graph Chapter 5


•To assign values automatically within a specified range

Example

To assign values from -3 to 3, in increments of 1 (seven values total)

F3(RANG)

(-) 3 EE 3 EE 1 EE



Strt:	Variable x start value
End:	Variable x end value
ptch:	Variable x value chang

To interrupt automatic assignment of variables and return to the function storage screen, press our.

•To assign values from a list

Press SHIFT STUP to display the set-up screen.





If necessary, you can press b to display a menu of other lists (4, 5, 6). The following shows the operation required to select List 6.

F3(List6)



After making the set-up screen setting you want, press (a) to return to the Function List. Note that the [RANG] item does not appear in the function key menu at the bottom of the screen when a list is selected for assignment of variable values.

Chapter 5 Table and Graph

4. Generating a Numeric Table

Before actually generating a numeric table, you must first select the functions you want to use.

Use the () and () cursor keys to move the highlighting to the function you want to use and then press () (SEL) to select it.

The "=" symbols of selected functions are highlighted on the display. You can select more than one function for table generation.

In this display, Y1 and Y3 are selected.

T-Func	:Y=
Y1E3X	
YZ=X+4 V38X2	
Ý4:	
SEL DEL	SALD TABL
	F 4

Press F4 (TABL) or EXE to generate a numeric table.

	<u>X YI</u>
ſ	e- - 9 -6 - 5-
FORM	-3 2007 G CON G PLT

In this example, values are assigned automatically.

This display shows the generated numeric table. Though this example display shows only the values for function Y1, values for function Y3 were also generated.

Each cell can hold up to six digits (negative sign takes up one digit).

You can move the cursor around the table using the cursor (a, b, b) keys.

The following points apply to cursor position and movement.

- The value contained in the currently selected cell appears at the bottom of the display, with all current display attributes (number of decimal place, number of significant digit, and exponential display range settings) applied.
- Moving the cursor off the screen causes the table to scroll when there are cells off the top, bottom, left, or right.
- When the cursor is located in any function value cell (Y1, Y2, etc.), the function is shown at the top of the display.
- If you change a value in column X, the corresponding function value is automatically updated using the new value for X.

To return to the Function List, press F1 (FORM).

5. Editing a Table

You can use the editing screen to add lines to or delete lines from an existing table. Press F2 (ROW) to display the Table Editing Menu.

F2(ROW)



F1 (DEL) Deletes line where cursor is located.

F2 (INS) Inserts new line where cursor is located.

F3 (ADD) Insert new line below line where cursor is located.

6. Graphing a Function


You can use the two following function keys to produce a graph using the numeric table currently on the screen.

F3 (G-CON) ... Graph with connected plot points

F4 (G-PLT) Graph with plotted points (unconnected)


• Note that you can also produce a G-PLT (F4) graph by pressing E while a numeric table is on the screen.


Example To graph the function Y1 = 2X, whose table of numeric values is currently on the screen



F4 (G-PLT)

F3 (G-CON)





77

Chapter 5 Table and Graph

P.48

Graphing a table whose values were generated using more than one function causes the graphs of all the functions to be drawn at the same time. You can set x- and y-axis parameters using the View Window.

Press (and not not not the numeric table screen from a graph. Pressing (and again goes back to the graph. You can use (and to switch between the graph and its table as long as you do not clear the graph.

7. Assigning Numeric Table Contents to a List

You can assign a column of values from a table into a list. Simply use O and O to move the cursor into the column whose values you want to copy. The cursor can be in any row of the column. The copy operation is performed by pressing O to display the Option Menu, and then pressing \fbox{P} (LMEM).

OPTN F1 (LIST) F2 (LMEM)


Υ1=: [-3 -3 -2		-u] -u_]	
List1	LiSt2	LiSta	LiSt	i
El	F2	F3	F4	

Use the first function menu to copy the column's values to List 1 (F1) to List 4 (F4). To copy to List 5 or List 6, press \triangleright and then F1 (List 5) or F2 (List 6).




List Function

A list is a kind of container that you can use to store multiple data items. This calculator lets you have up to six lists in memory, and their contents can be used in arithmetic calculations, statistical calculations and for graphing.



- 1. List Operations
- 2. Editing and Rearranging Lists
- 3. Manipulating List Data
- 4. Arithmetic Calculations Using Lists

List Data Linking




1. List Operations

Select the LIST icon in the Main Menu and enter the LIST Mode to input data into a list and to manipulate list data.

•To input values one-by-one

Use O and O to move between lists, and O and O to move between cells inside of a list.

The screen automatically scrolls when the cursor is located at the edge of the screen.




For our example, we will start by locating the cursor in Cell 1 of List 1.

List I List 2 I 2 3 SRTA SRTD


1. Input a value and press EXE to store it in the list.

3 EXE



2. The cursor automatically moves down to the next cell for input. Let's continue our example by inputting the values 4 and 5.

4 EXE 5 EXE



To batch input a series of values

 \bigcirc

EXE

1. Use (a) to move the cursor to the list name.

2. Use (or) to move the cursor to another list.

one. Press (SHIT) after inputting the final value.

SHIFT (6 • 7 • 8 SHIFT)

4. Press EXE to store all of the values in your list.

after the final value of the set you are inputting.

2. Editing and Rearranging Lists

List List 2

List I List 2

List I List 2

List il List 2

6

|{6,7,8)_₩

2 a


SRT-A SRT-D


List Function Chapter 6


To delete a cell

1. Use (1), (2), (3), or (2) to move the cursor to the cell you want to delete.

 \odot








3. Press F1 (DEL) to delete the selected cell and cause everything below it to be shifted up.


F1(DEL)



 Note that the above cell delete operation does not affect cells in other lists. If the data in the list whose cell you delete is somehow related to the data in neighboring lists, deleting a cell can cause related values to become misaligned.

•To delete all cells in a list

1. Use (1), (b), (b) or (c) to move the cursor to the name of the list whose cells you want to delete.





Ø



Editing List Values

Right: {34, 53, 78}

Wrong: {34, 53, 78,}

Use (or) to move the cursor to the cell whose value you want to change. Input the new value and press [35] to replace the old data with the new one.

Remember that a comma separates values, so you should not input a comma


3. Press MIT (, and then input the values you want, pressing) between each

- 2. Press D to display the Cell Operation Menu (if it is not already displayed).
 - \square



3. Press (E2) (DEL-A). The function menu changes to confirm whether you really want to delete all the cells in the list.

F2 (DEL-A)



4. Press F1 (YES) to delete all the cells in the selected list or F4 (NO) to abort the delete operation without deleting anything.

F1(YES)


	List I	List 2	-
1	Ξ		
2	5		
-		•	
DEL	DELIA	INS	1

•To insert a new cell

Use O, O, O, O, O, or O to move the cursor to the location where you want to insert the new cell. In this example, we will reinsert a cell containing the value 4, which we deleted above.

- 1. Press D to display the Cell Operation Menu (if it is not already displayed).
- 2. Press F3 (INS) to insert a new cell, which contains a value of 0, causing everything below it to be shifted down.

F3 (INS)



List Function Chapter 6

3. Input the value you want into the new cell (4 in our example) and press EVE.

4 EXE

	List I	List 2
l	3	
Ē		
DEL	DELP	



 Note that the above cell insert operation does not affect cells in other lists. If the data in the list where you insert a cell is somehow related to the data in neighboring lists, inserting a cell can cause related values to become misaligned.

Sorting List Values


You can sort lists into either ascending order or descending order. The current cursor location does not matter in the following procedures.

•To sort a single list

Ascending order


1. While the lists are on the screen, press to display the Operation Menu and then press [F1 (SRT-A).

▶ F1(SRT-A)




The prompt "How Many Lists? (H)" appears to ask how many lists you want to sort. Here we will input 1 to indicate we want to sort only one list.

1 EXE



 In response to the "Select List (L)" prompt, input the number of the list you want to sort. Here we will input 2 to specify sorting of List 2.

2 EXE



The values in List 2 are sorted into ascending order.

Descending order

Use the same procedure as that for the ascending order sort. The only difference is that you should press F2 (SRT-D) in place of F1 (SRT-A).


•To sort multiple lists

You can link multiple lists together for a sort so that all of their cells are rearranged in accordance with the sorting of a base list. The base list is sorted into either ascending order or descending order, while the cells of the linked lists are arranged so that the relative relationship of all the rows is maintained.

Ascending order

1. While the lists are on the screen, press F1 (SRT-A).

F1(SRT-A)



2. The prompt "How Many Lists? (H)" appears to ask how many lists you want to sort. Here we will sort one base list linked to one other list, so we should input 2.

2 EXE


Select Base List(B)

3. In response to the "Select Base List (B)" prompt, input the number of the list you want to sort into ascending order. Here we will specify List 1.

Select Second List(L)

4. In response to the "Select Second List (L)" prompt, input the number of the list you want to link to the base list. Here we will specify List 2.

2 EXE



The values in List 1 are sorted into ascending order, and the cells of List 2 are also rearranged to keep the same relationship with the List 1 cells.

Descending order

Use the same procedure as that for the ascending order sort. The only difference is that you should press F2 (SRT-D) in place of F1 (SRT-A).

3. Manipulating List Data

List data can be used in arithmetic and function calculations. There is also a collection of powerful list data manipulation functions that let you do the following.

- Count the number values (Dim)
- Replace all cell values with the same value (Fill)
- Generate a sequence of numbers (Seq)
- · Find the minimum value in a list (Min)
- Find the maximum value in a list (Max)
- Find which of two lists contains the smallest value (Min)
- · Find which of two lists contains the greatest value (Max)
- · Calculate the mean of list values (Mean)
- Calculate the mean of values of specified frequency (Mean)
- Calculate the median of values in a list (Med)
- · Calculate the median of values of specifies frequency (Med)
- · Calculate the sum of values in a list (Sum)

You can use list data manipulation functions in the RUN, STAT, LIST, TABLE, or PRGM Mode.

Accessing the List Data Manipulation Function Menu

All of the following examples are performed after entering the RUN Mode.

Press OPTH and then F1 (LIST). This menu has three pages and you can advance to the next page by pressing D.

Note that all closing parentheses at the end of the following operations can be omitted.

•To count the number of values (Dim)

@TN F1(LIST)F3(Dim)F1(List) <list number 1-6> EXE


• The number of cells that contain data in a list is called its "dimension."

Example (36, 16, 58, 46, 56)

To enter the RUN Mode and count the number of values in List 1

AC OPTN F1 (LIST) F3 (Dim) F1 (List) 1 EXE

In:	-	1 1 .	st.	1	
101	m		50	; ≜ ;	· .
1.1					
1.1.2					1.1



List Function Chapter 6

•To find the minimum value in a list (Min)

@TN [F1] (LIST) ▷ F2 (Min) ▷ ▷ F1 (List) <list number 1-6>) E

Example To find the minimum value in List 1 (36, 16, 58, 46, 56)

AC @FN F1(LIST) ▷ F2(Min) ▷ ▷ F1(List) 1) 또 Min(List 1) 16

•To find the maximum value in a list (Max)

Use the same procedure as when finding the minimum value, except press (Max) in place of (F2) (Min).

•To find which of two lists contains the smallest value (Min)

「「「(LIST)) 「 2 (Min)) [) 「 (List)


- The two lists must contain the same number of values. If they don't, an error (Dim ERROR) occurs.
- The result of this operation is also stored in Ans Memory.

ExampleTo find whether List 1 (75, 16, 98, 46, 56) or List 2 (36, 89, 58, 72,
67) contains the smallest value

AC 0779 F1 (LIST) [2] (Min) [2] [2] (List) 1 ・ [5] (List) 2 [2]

EXE

Min(List 1,Li st 2)_



•To find which of two lists contains the greatest value (Max)

Use the same procedure as that for the smallest value, except press F3 (Max) in place of F2 (Min).

The two lists must contain the same number of values. If they don't, an error (Dim ERROR) occurs.

•To calculate the mean of list values (Mean)

@TN F1 (LIST) D F4 (Mean) D D F1 (List) <list number 1-6>) EXE

List Function Chapter 6

Example To calculate the mean of values in List 1 (36, 16, 58, 46, 56)

AC (PTN F1 (LIST) [> F4 (Mean) [> [> F1 (List) [1] [> [20]

				1. A. 1. A.
Mea		1	-t	15
l un ex	3613	ا السا		
1.1.1.1			1.1.1	42.4

To calculate the mean of values of specified frequency (Mean)

This procedure uses two lists: one that contains values and one that contains the number of occurrences of each value. The frequency of the data in Cell 1 of the first list is indicated by the value in Cell 1 of the second list, etc.

• The two lists must contain the same number of values. If they don't, an error (Dim ERROR) occurs.

[7] (LIST) ▷ F4 (Mean) ▷ ▷ F1 (List) list number 1-6(data)>
 [7] (List) list number 1-6 (frequency)>)

Example To calculate the mean of values in List 1 (36, 16, 58, 46, 56), whose frequency is indicated by List 2 (75, 89, 98, 72, 67)

▲ @刑 F1 (LIST) ▷ F4 (Mean) ▷ ▷ F1 (List) 1 ・ F1 (List) 2) ஊ

Mean(List 1,L ist 2) 42.07481297

To calculate the median of values in a list (Med)

@FIN F1 (LIST) ▷ ▷ F1 (Med) ▷ F1 (List) listnumber 1-6>) EXE

Example To calculate the median of values in List 1 (36, 16, 58, 46, 56)

AC (PTN F1(LIST) (D) (Med) (D) F1(List) (1) (EE

Med:	ian(l	ist	1
)			
		1	46

•To calculate the median of values of specified frequency (Med)

This procedure uses two lists: one that contains values and one that contains the number of occurrences of each value. The frequency of the data in Cell 1 of the first list is indicated by the value in Cell 1 of the second list, etc.

• The two lists must contain the same number of values. If they don't, an error (Dim ERROR) occurs.

@ 「 (LIST) ▷ ▷ 「 (Med) ▷ 「 (List) < list number 1-6 (data)> 「 「 (List) < list number 1-6 (frequency)> 〕

Example To calculate the median of values in List 1 (36, 16, 58, 46, 56), whose frequency is indicated by List 2 (75, 89, 98, 72, 67)

AC (PTN F1 (LIST) (D) (F1 (Med) (D) F1 (List) (1) (F1 (List) (2) (D) (D)

Median(List 1 List 2) 46

•To calcul	ate the sum of values in a lis	st (Sum)
OPT	🕅 F1 (LIST) 🕞 🕞 F2 (Sum) 🕻	F1 (List) <list 1-6="" number=""> E</list>
Example	To calculate the sum of value	s in List 1 (36, 16, 58, 46, 56)
) @TN [F] (LIST) [D [D [F2 (Sum)] [F] (List) []	Sum List 1

4. Arithmetic Calculations Using Lists

You can perform arithmetic calculations using two lists or one list and a numeric value.

Ans Memory Calculation results are Ξ List Numeric Value Numeric Value stored in Ans Memory.

Error Messages

- A calculation involving two lists performs the operation between corresponding cells. Because of this, a Dim ERROR occurs if the two lists do not have the same number of values (which means they have different "dimensions").
- An Ma ERROR occurs whenever an operation involving any two cells generates
 a mathematical error.

Inputting a List into a Calculation

There are two methods you can use to input a list into a calculation.


•To input a specific list by name

Example To input List 6

- 1. Press OPTN to display the first Operation Menu.
- This is the function key menu that appears in the RUN or PRGM Mode when you press OPTIN.








List Function Cha	pter 6
•To input a value into a specific cell	
You can input a value into a specific cell inside a list. When you do, the was previously stored in the cell is replaced with the new value you input	value that t.
Example To input the value 25 into cell 2 of List 3	
2 5 🗩 (771) F1 (LIST) F1 (List) 3 (9117) [2 (9117)] EXE	
Recalling List Contents	
Example To recall the contents of List 1	
(PTN F1 (LIST) F1 (List) 1 EE	
 The above operation displays the contents of the list you specify and them in Ans Memory. You can then use the Ans Memory contents in tion. 	
•To use list contents in Ans Memory in a calculation	
Example To multiply the list contents in Ans Memory by 36	
(PTN) (F1 (LIST) (F1 (List) (SHIFT) (Ans X 3 6 EXE	
 The operation IFT (LIST) F1 (List) IFT (List)	
Graphing a Function Using a List	
When using the graphing functions of this calculator, you can input a fur as Y1 = List1 X. If List 1 contains the values 1, 2, 3, this function will prod graphs: $Y = X$, $Y = 2X$, $Y = 3X$.	
There are certain limitations on using lists with graphing functions.	
Inputting Scientific Calculations into a List	



You can use the numeric table generation functions in the Table Mode to input values that result from certain scientific function calculations into a list. To do this, first generate a table and then use the list copy function to copy the values from the table to the list.



Statistical Graphs and Calculations

This chapter describes how to input statistical data into lists, and how to calculate the mean, maximum and other statistical values. It also tells you how to perform regression calculations.

Chapter

7

- 1. Before Performing Statistical Calculations
- 2. Statistical Calculation Examples
- 3. Calculating and Graphing Single-Variable Statistical Data
- 4. Calculating and Graphing Paired-Variable Statistical Data
- 5. Manual Graphing
- 6. Performing Statistical Calculations


Important!

This chapter contains a number of graph screen shots. In each case, new data
values were input in order to highlight the particular characteristics of the graph
being drawn. Note that when you try to draw a similar graph, the unit uses data
values that you have input using the List function. Because of this, the graphs
that appears on the screen when you perform a graphing operation will probably differ somewhat from those shown in this manual.

1. Before Performing Statistical Calculations

In the Main Menu, select the STAT icon to enter the STAT Mode and display the statistical data lists.


Use the statistical data lists to input data and to perform statistical calculations.



Inputting Data into Lists

Input the two groups of data into List 1 and List 2.





Once data is input, you can use it for graphing and statistical calculations.

- . Input values can be up to 10 digits long (9-digit mantissa and 2-digit exponent when using exponential format). Values in statistical data table cells are shown only up to six digits.
- You can use the (A), (I), (I) and (I) keys to move the highlighting to any cell in the lists for data input.


Plotting Data

Example To specify Graph 1 as non-draw (OFF) and Graph 3 as draw (ON) and use Graph 3 to plot the data you input into statistical data List 1 and List 2 above

While the statistical data list is on the display, press F1 (GRPH) to display the graph menu.

F1(GRPH)

P.99



Press D to return to the previous menu.

- · You can specify the graph draw/non-draw status, the graph type, and other general settings for each of the graphs in the graph menu (GPH1, GPH2, GPH3).
- You can press any function key ([F1], [F2], [F3]) to draw a graph regardless of the current location of the highlighting in the statistical data list.
- The initial default graph type setting for all the graphs (Graph 1 through Graph 3) is scatter diagram, but you can change to one of a number of other graph types.

Plotting a Scatter Diagram

It is often difficult to spot the relationship between two sets of data (such as height and shoe size) by simply looking at the numbers. Such relationships often become clear however, when we plot the data on a graph, using one set as *x*-values and the other set as *y*-values.

To plot a scatter diagram



e To plot the data we input in statistical data List 1 and List 2

F1(GPH1)

•		•	0	
. ×	- [Mea X^2			

- The default setting automatically uses List 1 data as *x*-axis values and List 2 data as *y*-axis values. Each set of *x*/*y* data is a point on the scatter diagram.
- To return to the statistical data list, press QUIT

Changing Graph Parameters

Use the following procedures to specify the graph draw/non-draw status, the graph type, and other general settings for each of the graphs in the graph menu (GPH1, GPH2, GPH3).

1. Graph draw/non-draw status (SELECT)

The following procedure can be used to specify the draw (On)/non-draw (Off) status of each of the graphs in the graph menu.

•To specify the draw/non-draw status of a graph

1. While the graph menu is on the display, press D F1 (SEL) to display the graph On/Off screen.

FT (GRPH)

S-Greh S-Greh:	iHUn 2:Off
0 n 0ff	DRAW
F1 F2	F4

F1 (On) Graph On (graph draw)

F2 (Off) Graph Off (graph non-draw)

[F4] (DRAW) Draw all On graphs


• Note that the S-Grph1 setting is for Graph 1 (GPH1 of the graph menu), S-Grph2 is for Graph 2, and S-Grph3 is for Graph 3.


Statistical Graphs and Calculations Chapter 7


- Use ▲ and ◆ to move the highlighting to the graph whose draw (On)/non-draw (Off) status you want to change and press F1 (On) or F2 (Off).
- 3. To return to the graph menu, press QUTT.

•To draw a graph

Example To draw a scatter diagram of Graph 3 only







2. General graph settings (SET)

This section describes how to use the general graph settings screen to make the following settings for each graph (GPH1, GPH2, GPH3).

• Graph Type

The initial default graph type setting for all the graphs is scatter graph. You can select one of a variety of other statistical graph types for each graph.

List or Data


The initial default statistical data is List 1 for single-variable data, and List 1 and List 2 for paired-variable data. You can specify which statistical data list you want to use to draw the graph.

• Frequency

Normally, each data item or data pair in the statistical data list is represented on a graph as a point. When you are working with a large number of data items however, this can cause problems because of the number of plot points on the graph. When this happens, you can specify a frequency list that contains values indicating the number of instances (the frequency) of the data items in the corresponding cells of the lists you are using for *x*-data and *y*-data. Once you do this, only one point is plotted for the multiple data items, which makes the graph easier to read.


Mark Type

This setting lets you specify the shape of the plot points on the graph.




F4 101

 \triangleright



Statistical Graphs and Calculations Chapter 7 •To select the frequency data list (Freq) 1. While the general graph settings screen is on the display, use (a) and () to move the highlighting to the Freq item. Free 1 List1 List2 List3 F3 F4 F1 F2 2. Use the function key menu to select the frequency setting you want. F1 (1) Plot all data (1-to-1) [F2] (List1) List 1 data is frequency data. F3 (List2) List 2 data is frequency data. [F4] (List3) List 3 data is frequency data. \triangleright List4 List5 List6 ⊳ FI F2 **F**3 F1 (List4) List 4 data is frequency data. F2 (List5) List 5 data is frequency data. [F3] (List6) List 6 data is frequency data. Press D to return to the previous menu. •To select the plot mark type (M-Type) 1. While the general graph settings screen is on the display, use (a) and () to move the highlighting to the M-Type item. M-Type : • F3 **F1** F2 2. Use the function key menu to select the plot mark you want to select. (F1) (__) Plot using __ F2 (X) Plot using X F3 (•) Plot using •



Statistical Graphs and Calculations Chapter 7

L09	Ezp	Pwr	2VAR	~	
F1	F2	F3	F4		

- F1 (Log) Logarithmic regression
- F2 (Exp) Exponential regression
- F3 (Pwr) Power regression
- F4 (2VAR) Paired-variable statistical results
- Press D to return to the previous menu.

Displaying Statistical Calculation Results

Whenever you perform a regression calculation, the regression formula parameter (such as a and b in the linear regression y = ax + b) calculation results appear on the display. You can use these to obtain statistical calculation results.

Regression parameters are calculated as soon as you press a function key to select a regression type while a graph is on the display.

Example To display logarithmic regression parameter calculation results while a scatter diagram is on the display

▶ F1(Log)

Б= 1.87475 r= 0.98216 у=a+b•lnx [СОРУ[DRAW

COPY DRAW F4

(F3)

Graphing statistical calculation results

You can use the parameter calculation result menu to graph the displayed regression formula.

P.119


F3 (COPY) Stores the displayed regression formula as a graph function F4 (DRAW) Graphs the displayed regression formula

Statistical Graphs and Calculations Chapter 7

Example To graph a logarithmic regression

While logarithmic regression parameter calculation results are on the display, press [F4] (DRAW).

F4 (DRAW)





For details on the meanings of function menu items at the bottom of the display, see "Selecting the Regression Type".

3. Calculating and Graphing Single-Variable Statistical Data


Single-variable data is data with only a single variable. If you are calculating the average height of the members of a class for example, there is only one variable (height).

Single-variable statistics include distribution and sum. The following three types of graphs are available for single-variable statistics.

Histogram

From the statistical data list, press F1 (GRPH) to display the graph menu, press [>] [F4] (SET), and then change the graph type of the graph you want to use (GPH1, GPH2, GPH3) to histogram.

Data should already be input in the statistical data list (see "Inputting Data into Lists"). Draw the graph using the procedure described under "Plotting Data".





(Box)

P.101

P.97


(G-Type) (Hist)

Box Graph

This type of graph lets you see how a large number of data items are grouped within specific ranges. A box encloses all the data in an area from the 25th percentile to the 75th percentile, with a line drawn at the 50th percentile. Lines (called whiskers) extend from either end of the box up to the minimum and maximum of the data.

From the statistical data list, press F1 (GRPH) to display the graph menu, press [E] [F4] (SET), and then change the graph type of the graph you want to use (GPH1, GPH2, GPH3) to box graph.

Statistical Graphs and Calculations Chapter 7




Normal Distribution Curve

The normal distribution curve is graphed using the following normal distribution function.

$$y = \frac{1}{\sqrt{(2\pi)} x \sigma_n} e^{-\frac{(x-\overline{x})}{2x\sigma_n}}$$

The distribution of characteristics of items manufactured according to some fixed standard (such as component length) fall within normal distribution. The more data items there are, the closer the distribution is to normal distribution.

From the statistical data list, press F1 (GRPH) to display the graph menu, press [E] [F4] (SET), and then change the graph type of the graph you want to use (GPH1, GPH2, GPH3) to normal distribution.



Displaying Single-Variable Statistical Results


Single-variable statistics can be expressed as both graphs and parameter values. When these graphs are displayed, the menu at the bottom of the screen appears as below.

> 1VAR F1


F1 (1VAR) Single-variable calculation result menu

Pressing F1 (1VAR) displays the following screen.

F1(1VAR)



Statistical Graphs and Calculations Chapter 7



 \overline{x} Mean of data Σx..... Sum of data Σx^2 Sum of squares xon...... Population standard deviation xon-1 Sample standard deviation n Number of data items minX Minimum Q1 First quartile Med Median Q3 Third quartile maxX Maximum Mod Mode

• Press [F4] (DRAW) to return to the original single-variable statistical graph.

Pie Chart

P.100

(Pie)

(G-Type)

From the statistical data list, press [F1] (GRPH) to display the graph menu, press [] (F4) (SET), and then change the graph type of the graph you want to use (GPH1, GPH2, GPH3) to pie chart. Next, move the highlighting to "Display" and then press [F1] or [F2] to select the pie chart data format.


[F1] (%) Displayed values show what percentage of the total data each pie segment represents.

[F2] (Data) Displayed values show actual data.

Press (QUIT) to draw the chart.

Example To input the following data into List 1 and use it to draw a pie chart: 18.0, 13.5, 4.5, 31.5, 22.5

> [F1 (GRPH)] F4 (SET) (GPH1) F3 (Pie) QUIT FI(GRPH)FI(GPH1)




· A pie chart can have up to eight data items. Attempting to draw a pie chart for a list that has more than eight data items causes an error (Dim ERROR).

- · Only positive data can be included in a pie chart. Attempting to draw a pie chart for a list that includes negative data causes an error (Ma ERROR).
- View Window settings are not applied to pie charts.
- A pie chart cannot be superimposed with another graph.
- Values appearing on a pie chart are automatically assigned to the corresponding variables (A, B, C, etc.)

P.101

(G-Type) (N•Dis)




F1(GRPH) [▷ F4(SET) F1(GPH1) F4(Stck) F1(GRPH) F1(GPH1)

|--|--|--|--|

 A stacked bar chart can have up to eight data items. Attempting to draw a stacked bar chart for a list that has more than eight data items causes an error (Dim ERROR).

Statistical Graphs and Calculations Chapter 7


- Only positive data can be included in a stacked bar chart. Attempting to draw a stacked bar chart for a list that includes negative data causes an error (Ma ER-ROR).
- A stacked bar chart cannot be superimposed with another graph.
- · View Window settings are not applied to stacked bar charts.
- The following display shows what happens if you perform a trace operation (Fig (TRCE)) while a stacked bar chart is on the display.



- Pressing () and () moves the highlighting up and down within the same graph.

Linking the Segments of Stacked Bar Charts with Connecting Lines

While multiple stacked bar charts are on the display, press (BET) (CNCT) to link their segments with connecting lines.



Redraw the stacked bar charts to clear the connecting lines.

Bar Graph

P.101


(Bar)

(G-Type)

From the statistical data list, press F1 (GRPH) to display the graph menu, press D A (SET), and then change the graph type of the graph you want to use (GPH1, GPH2, GPH3) to bar graph.

Press QUIT to draw the graph.





• A line graph can be superimposed with a bar graph only. This is done by selecting F3 (Both) while specifying the graph type.

Statistical Graphs and Calculations Chapter 7

- Pressing SHFT F1 (TRCE) while a line graph is on the display activates the trace operation. Use () and () to move the pointer.
- · You cannot draw multiple line graphs on the same screen.



Bar Graph and Line Graph

From the statistical data list, press F1 (GRPH) to display the graph menu, press [>] [F4] (SET), and then change the graph type of the graph you want to use (GPH1, GPH2, GPH3) to Both.

When Auto is specified for the S-Wind (Statistical Graph View Window Setting) item on the Set Up screen, you can next move the highlighting to the AutoWin item and press F1, F2, or F3 to make one of the following settings.

- [F1] (Sep.G) This setting causes each graph to be drawn in different areas of the display, without superimposing them. The two graphs share the same x-coordinates, however, and the x-axis is displayed for the bar graph only.
- [F2] (O.Lap) This setting superimposes the two graphs on each other. Each graph, however, can have its own independent y-axis values.
- [F3] (Norm) This setting also superimposes the two graphs, with both using the same x- and y-coordinates.

Press (QUIT) to draw the graph.

Example

Draw a graph that shows precipitation in a certain city as a bar graph and average temperature as a line graph. Input the precipitation data into List 1 and the temperature data into List 2. Use the following procedure to draw the graph.

1		List 1	List 2
	1	100	5
	2	150	4
	3	200	11
	4	400	16
	5	300	20
	6	800	24
Ċ.	7	750	31
	8	200	32
	9	350	29
	10	500	24
	11	80	18
	12	80	6

FI(GRPH) F4(SET) (FT)(GPH1) FT(GRPH)FT(GPH1)



• Pressing SHET (TRCE) while the graph is on the display activates the trace operation. Use (and to move the pointer.

You cannot draw multiple bar and line graphs on the same screen.

4. Calculating and Graphing Paired-Variable Statistical Data

Under "Plotting a Scatter Diagram," we displayed a scatter diagram and then performed a logarithmic regression calculation. Let's use the same procedure to look at the six regression functions.

Linear Regression Graph

Linear regression plots a straight line that passes close to as many data points as possible, and returns values for the slope and y-intercept (y-coordinate when x = 0) of the line.


The graphic representation of this relationship is a linear regression graph.

(G-Type) @m F (Scat) F1(Sc (GPH1) @m F (X) F1(X)

P.100

@@ F1 (GRPH) ▷ F4 (SET) ♥ F1 (Scat)

@ FI(GRPH)FI(GPH1)



F4 (DRAW)

_			1.4.1	
	F .			
1.1			- 1	- I
Ι.				
		المعتقرين المستعر		
L	مير: ا	· ·		
li	5	1ed X	~2	
1	$\sim \mu$	vea lv	E	

The following are the meanings of the above parameters.

a Regression coefficient (slope)


b..... Regression constant term (intercept)

r Correlation coefficient


Med-Med Graph

When it is suspected that there are a number of extreme values, a Med-Med graph can be used in place of the least squares method. This is also a type of linear regression, but it minimizes the effects of extreme values. It is especially useful in producing highly reliable linear regression from data that includes irregular fluctuations, such as seasonal surveys.

F2 (Med)



F4 (DRAW)



The following are the meanings of the above parameters.

a Med-Med graph slope

b..... Med-Med graph intercept




P.101

(G-Type)


Quadratic Regression Graph

A quadratic regression graph represents connection of the data points of a scatter diagram. It actually is a scattering of so many points that are close enough together to be connected. The formula that represents this is quadratic regression.

F3 (X^2)



F4



CONTRACTOR AND A CONTRACTOR OF A CONTRACT OF A CONTRACT OF A CONTRACT OF A CONTRACT OF A CONTRACT OF A CONTRACT

F4 (DRAW)

The following are the meanings of the above parameters.

- a Regression second coefficient
- b..... Regression first coefficient
- c Regression constant term (intercept)

Logarithmic Regression Graph

Logarithmic regression expresses y as a logarithmic function of x. The standard logarithmic regression formula is $y = a + b \times \log x$, so if we say that X = logx, the formula corresponds to linear regression formula y = a + bX.

▷ F1(Log)

LogReg a= 1.54097 b= 1.35148 r= 0.98673 y=a+b•lnx [COPY DRAU	5
F4	
× [Med [X^2	

F4 (DRAW)

The following are the meanings of the above parameters.

- a..... Regression constant term (intercept)
- b..... Regression coefficient (slope)
- r Correlation coefficient




P.101

(G-Type)

Exponential Regression Graph


Exponential regression expresses *y* as a proportion of the exponential function of *x*. The standard exponential regression formula is $y = a \times e^{bx}$, so if we take the logarithms of both sides we get $\log y = \log a + bx$. Next, if we say $Y = \log y$, and $a = \log a$, the formula corresponds to linear regression formula Y = a + bx.

▷ F2 (Exp)



Statistical Graphs and Calculations Chapter 7

F4 (DRAW)



The following are the meanings of the above parameters.

- a..... Regression coefficient
- b..... Regression constant term
- r Correlation coefficient


P.101

(G-Type)


Power Regression Graph

Exponential regression expresses *y* as a proportion of the power of *x*. The standard power regression formula is $y = a \times x^b$, so if we take the logarithms of both sides we get $\log y = \log a + b \times \log x$. Next, if we say $X = \log x$, $Y = \log y$, and $a = \log a$, the formula corresponds to linear regression formula Y = a + bX.

▶ **F3**(Pwr)



F4 (DRAW)



The following are the meanings of the above parameters.

- a Regression coefficient
- b..... Regression power
- r Correlation coefficient



Displaying Paired-Variable Statistical Results


Paired-variable statistics can be expressed as both graphs and parameter values. When these graphs are displayed, the menu at the bottom of the screen appears as below.

Log Exp Pwr 2VAR

F4 (2VAR) Paired-variable calculation result menu

Pressing F4 (2VAR) displays the following screen.

F4 (2VAR)



 Use T to scroll the list so you can view the items that run off the bottom of the screen. The following describes the meaning of each of the parameters.

- \overline{x} Mean of xList data
- Σx.....Sum of xList data
- xon Population standard deviation of xList data
- xon-1 Sample standard deviation of xList data
- n Number of xList data items
- \overline{y} Mean of yList data
- Σy Sum of yList data
- Σy^2 Sum of squares of yList data
- yon..... Population standard deviation of yList data
- yon-1 Sample standard deviation of yList data
- Σxy Sum of xList and yList data
- minX..... Minimum of xList data
- maxX Maximum of xList data
- minY Minimum of yList data
- maxY Maximum of yList data

Copying a Regression Graph Formula to the Graph Mode

After you perform a regression calculation, you can copy its formula to the **GRAPH** Mode.

The following are the functions that are available in the function menu at the bottom of the display while regression calculation results are on the screen.


Statistical Graphs and Calculations Chapter 7

LosRes a= 1.54097 b= 1.35148 r= 0.98673 y=a+b.lnz [COPY[DRAW] [7] [7]

(COPY) Stores the displayed regression formula to the GRAPH Mode
 (DRAW) Graphs the displayed regression formula

1. Press F3 (COPY) to copy the regression formula that produced the displayed data to the GRAPH Mode.

F3 (COPY)



Note that you cannot edit regression formulas for graph formulas in the GRAPH Mode.

2. Press 🕮 to save the copied graph formula and return to the previous regression calculation result display.

Multiple Graphs

P.98

P.105

You can draw more than one graph on the same display by using the procedure under "Changing Graph Parameters" to set the graph draw (On)/non-draw (Off) status of two or all three of the graphs to draw (On), and then pressing F4 (DRAW). After drawing the graphs, you can select which graph formula to use when performing single-variable statistic or regression calculations.

S-Grph2:Off S-Grph3:On
On Off DRAW
F4
StatGraph <u>1</u> . • ×
Šelect[↑][↓]


Design of the second second second second second second second second second second second second second second

F4 F1

F4 (DRAW) F1 (X)

- The text at the top of the screen indicates the currently selected graph (STAT Graph 1 = Graph 1, STAT Graph 2 = Graph 2, STAT Graph 3 = Graph 3).
- 1. Use (and () to change the currently selected graph. The graph name at the top of the screen changes when you do.

 \odot



inearReg

y=ax+b

a= 0.66688 b=-2.73392

ř= 0.95611

2. When graph you want to use is selected, press EXE

COPY DRAW Now you can use the procedures under "Displaying Single-Variable Statistical Results" and "Displaying Paired-Variable Statistical Results" to perform statistical cal-

5. Manual Graphing

In all of the graphing examples up to this point, values were calculated in accordance with View Window settings and graphing was performed automatically. This automatic graphing is performed when the S-Wind item of the View Window is set to "Auto" (auto graphing). You can also produce graphs manually, when the automatic graphing capabilities of this calculator cannot produce the results you want.

Setting the Width of a Histogram

When the S-Wind item of the View Window is set to "Man" (manual graphing), a screen appears so you can specify the starting point and spacing of histogram bars. While the statistical data list is on the display, perform the following procedure.

SHIFT SETUP



Statistical Graphs and Calculations Chapter 7

F2 (Man)

(Returns to previous menu.)
 [f1(GRPH)[f1(GPH1)

Here we will illustrate this operation by making histogram settings for Graph 1.



The following are the meanings of the items that appear in this screen.

Strt Histogram start point (x-coordinate)

ptch Bar spacing (specify as scale unit)

Example Strt: 0, ptch: 10

While the statistical data list is on the display, perform the following procedure.

 SHF
 SETUP
 F2) (Man)

 OUT
 (Returns to previous menu.)

 F1
 (GRPH)
 F1
 (GPH1)

 O
 FEI
 (Start value is x = 0.)
 1
 O
 FEI
 (pitch = 10)

6. Performing Statistical Calculations

All of the statistical calculations up to this point were performed after displaying a graph. The following procedures can be used to perform statistical calculations alone.

To specify statistical calculation data lists

You have to input the statistical data for the calculation you want to perform and specify where it is located before you start a calculation. While the statistical data is on the display, perform the following procedure.

F2(CALC)F4(SET)



P.108

P.118

P.8

culations.

The following is the meaning for each item.

- 1VarF Specifies list where single-variable frequency values (Frequency) are located.
- 2VarX Specifies list where paired-variable statistic *x* values (XList) are located.
- 2VarY Specifies list where paired-variable statistic y values (YList) are located.
- 2VarF Specifies list where paired-variable frequency values (Frequency) are located.

· Calculations in this section are performed based on the above specifications.

Single-Variable Statistical Calculations

In the previous examples from "Histogram (Bar Graph)" to "Normal Distribution Curve," statistical calculation results were displayed after the graph was drawn. These were numeric expressions of the characteristics of variables used in the graphic display. The following operation produces the same values directly from the statistical data

list.

P.108

F2(CALC)F1(1VAR)

1-V <u>a</u> ria	able
$x = \frac{\chi}{\Sigma \gamma}$	2.66
Σχ2=	50.49
<u></u>	1.7385
1VAR 2VAR	

Now you can press (and () to view variable characteristics.

For details on the meanings of these statistical values, see "Displaying Single-Variable Statistical Results".

Paired-Variable Statistical Calculations

In the previous examples from "Linear Regression Graph" to "Power Regression Graph," statistical calculation results were displayed after the scatter diagram was drawn. These were numeric expressions of the characteristics of variables used in the graphic display.

The following operation produces the same values directly from the statistical data list.

F2 (CALC) F2 (2VAR)



Statistical Graphs and Calculations Chapter 7

Now you can press () and () to view variable characteristics.

For details on the meanings of these statistical values, see "Displaying Paired-Variable Statistical Results".

Regression Calculation

In the explanations from "Linear Regression Graph" to "Power Regression Graph," regression calculation results were displayed after the graph was drawn. Here, the regression line and regression curve is represented by mathematical expressions.

You can directly determine the same expression from the data input screen.

Perform the following key operation.

F2(CALC)F3(REG) F1(X)



Single variable regression parameters are displayed.

Next, you can use the following.

F1 (X)	Linear regression
F2 (Med)	Med-Med regression
F3 (X^2)	Quadratic regression
\square	
F1 (Log)	Logarithmic regression
F2 (Exp)	Exponential regression
[F3] (Pwr)	Power regression

The meanings of the parameters that appear on this screen are the same as those for "Linear Regression Graph" to "Power Regression Graph".

Estimated Value Calculation (\hat{x}, \hat{y})

After drawing a regression graph with the **STAT Mode**, you can use the **RUN Mode** to calculate estimated values for the regression graph's x and y parameters.



P.118

 Note that you cannot obtain estimated values for Med-Med graph and quadratic regression graph.

	Example			on using the following data and \hat{x} when $xi = 40$ and $yi = 1000$	
		xi (List 1)	yi (List 2)		
		28	2410		
		30	3033		
		33	3895		
		35	4491		
		38	5717		
				and enter the STAT Mode. er regression graph.	
G-Type)	F1(GRPH)	F4(SET)	D	مر	
(Scat)	F1 (Scat)				
(XList)	F1 (List1) 🗨				
(YList)	F2 (List2) 💽)			
(Freq)	F1(1) 🐨			X Med X-2	
M-Type)	F1 (=) QUIT				
(Auto)					
(Pwr)	F3 (Pwr) F4	(DRAW)			
	3. In the Main Menu, select the RUN icon and enter the RUN Mode.				
	4. Press the	keys as follo	ows.		
	and the state of the state of the state of the state of the state of the state of the state of the state of the	0 (value of F3 (STAT) (40\$ 6587.674589	
	The estimate	ed value ŷ is	displayed for $xi = 4$	F1 F2 40.	
) 0 0 0 (v)(<i>î</i>) EE	alue of yi)	400 6587.674589 10002	

The estimated value \hat{x} is displayed for yi = 1000.




Programming

- 1. Before Programming
- 2. Programming Examples
- 3. Debugging a Program
- 4. Calculating the Number of Bytes Used by a Program
- 5. Secret Function
- 6. Searching for a File
- 7. Editing Program Contents
- 8. Deleting a Program
- 9. Useful Program Commands
- 10. Command Reference
- 11. Text Display
- 12. Using Calculator Functions in Programs



1. Before Programming

The programming function helps to make complex, often-repeated calculations quick and easy. Commands and calculations are executed sequentially, just like the manual calculation multistatements. Multiple programs can be stored under file names for easy recall and editing.



Select the **PRGM** icon in the Main Menu and enter the PRGM Mode. When you do, a program list appears on the display.

Program List

UCTH TRIANGLE

OCTONARY

F2

DELL DEL A SRC

F2

F3

(F3)

MEASURE

FI

Selected memory area _____ (use () and () to move)

F1 (EXE)...... Execute program F2 (EDIT)...... Program edit F3 (NEW)...... New program

⊳

P.138 P.138 P.135

F1 (DEL) Specific program delete
F2 (DEL•A) Delete all
F3 (SRC) File name search

Press D to return to the previous menu.

 If there are not programs stored in memory when you enter the PRGM Mode, the message "No Programs" appears on the display and only the NEW item (F3) is shown in the function menu.

2. Programming Examples

Example 1

To calculate the surface area and volume of three regular octahedrons of the dimensions shown in the table below

Store the calculation formula under the file name OCTA.

\wedge	Length of One Side (A)	Surface Area (S)	Volume (V)
1.	7 cm	cm²	Cm ³
(1)	10 cm	cm²	Cm ³
A	15 cm	Cm ²	CM ³

The following are the formulas used for calculating surface area S and volume V of a regular octahedron for which the length of one side is known.

$$S = 2\sqrt{3} A^2$$
, $V = \frac{\sqrt{2}}{3} A^3$

When inputting a new formula, you first register the file name and then input the actual program.


•To register a file name

Example To register the file name OCTA

• Note that a file name can be up to eight characters long.

1. While the program list is on the display, press F3 (NEW).

F3 (NEW)



F3 (n0) Password registration F4 (SYBL) Symbol menu

2. Input the name of the file.

OCTA




• The cursor changes form to indicate alpha character input.

• The following are the characters you can use in a file name:

A through Z, spaces, [,], {, }, ', ", ~, 0 through 9, ., +, -, ×, +

Chapter 8 Programming





To change modes in a program

• Pressing F3 (MENU) while the program input screen is on the display causes a mode change menu to appear. You can use this menu to input mode changes into your programs. For details on each of these modes, see "Using the Main Menu", as well as the sections of this manual that describe what you can do in each mode.

[F3] (MENU)

SHIFT SET UP

 \triangleright


 \triangleright

 \triangleright

 \triangleright

2.1				
	SHEP		<u>GISP</u> i	THEL
	F1	F2	F3	F4

• Pressing SHEFT SETUR displays a menu of commands that can be used to change set up screen settings inside a program. For details on each of these commands, see "To change a mode set up".



Actual program contents are identical to manual calculations. The following shows how the calculation of the surface area and volume of a regular octahedron would be calculated using a manual calculation.

Surface Area S ... 2 🗴 🗺 🗸 3 🗶 <value of A> 🕫 🖾 Volume V 🖩 🗸 2 🕂 3 🗶 <value of A> 🛆 3 🖾

You could also perform this calculation by assigning the value for the length of one side to variable A.

Length of One Side A <value of A> 🕳 💵 🗛 🕰

Press D to return to the previous menu.


P.136

ipier 0	Trogramming			
	Surface Area S (2) 🗙 জ্ঞाন 🕝 (3) 🗶 📖 (2 Volume V জ্ঞाন 👉 (2) 🕂 (3) 🗶 📖 (2			
	If you simply input the manual calculations shown would execute them from beginning to end, withou mands make it possible to interrupt a calculation for intermediate results.	ut stopping. The following com-		
	? : This command pauses program execution and displays a question mark as a prompt for input of a value to assign to a variable. The syntax for this command is: $? \rightarrow \langle variable name \rangle$.			
\sim	▲: This command pauses program execution and displays the last calculation re- sult obtained or text. It is similar to pressing in a manual calculation.			
P.139	 For full details on using these and other commands, see "Useful Program Com- mands". 			
	The following shows examples of how to actually use the ? and \checkmark commands.			
	()) ()) ()) ()) ()) ()) ()) ()) ()) ())	= OCTA = ?+A:2×\J3×A: -		
		FI F2		
	9867 (~ 2 🕂 3 🗙 A.M. A 🛆 3	= OCTA = ?+A:2×J3×A² J2+3×A^3_		
	ount out	Program List DCTA		
	●To run a program			
	 While the program list is on the display, use the program you want to run. 	and $oldsymbol{\overline{O}}$ to highlight the name of		
	2 Press EI (EXE) or EVE to run the program			

2. Press F1 (EXE) or EXE to run the program.

Let's try running the program we input above.

Length of One Side (A)	Surface Area (S)	Volume (V)
7 cm	169.7409791 cm ²	161.6917506 cm ³
10 cm	346.4101615 cm ²	471.4045208 cm ³
15 cm	779.4228634 cm ²	1590.990258 cm ³



• Pressing be while the program's final result is on the display re-executes an program.

• You can also run a program while in the **RUN Mode** by inputting: Prog "<file name>" 📧 .

P.149

 An error (Go ERROR) occurs if the program specified by Prog "<file name>" cannot be found.

130

131

and the second

3. Debugging a Program

A problem in a program that keeps the program from running correctly is called a "bug," and the process of eliminating such problems is called "debugging." Either of the following symptoms indicates that your program contains bugs and that debuging is required.

- Error messages appearing when the program is run
- · Results that are not within your expectations

To eliminate bugs that cause error messages

An error message, like the one shown below, appears whenever something illegal occurs during program execution.

Ma ERROR

When such a message appears, press ④ or to display the location where the error was generated, along with the cursor. Check the "Error Message Table" for steps you should take to correct the situation.



P.135

 Note that pressing
 or
 will not display the location of the error if the program is password protected.

To eliminate bugs that cause bad results

If your program produces results that are not what you normally expect, check the contents of the program and make necessary changes. See "Editing Program Contents" for details on how to change program contents.

4. Calculating the Number of Bytes Used by a Program

This unit comes with 20,000 bytes of memory. A byte is a unit of memory that can be used for storage of data.

There are two types of commands: 1-byte commands and 2-byte commands.

- Examples of 1-byte commands: sin, cos, tan, log, (,), A, B, C, 1, 2, etc.
- Examples of 2-byte commands: Lbl 1, Goto 2, etc.

While the cursor is located inside of a program, each press of or causes the cursor to move one byte.

 You can check how much memory has been used and how much remains at any time by selecting the **MEM** icon in the Main Menu and entering the MEM Mode. See "Memory Status (MEM)" for details.

5. Secret Function

When inputting a program, you can protect it with a password that limits access to the program contents to those who know the password. Password protected programs can be executed by anyone without inputting the password.

To register a password

Example

To create a program file under the name AREA and protect it with the password CASIO

1. While the program list is on the display, press (NEW) and input the file name of the new program file.

F3(NEW)



2. Press F3 (n0) and then input the password.

F3(rr0) CASIO





The password input procedure is identical to that used for file name input.

- 3. Press 💷 to register the file name and password. Now you can input the contents of the program file.
- Registration of a password uses 16 bytes of memory.
- Pressing
 without inputting a password registers the file name only, without a
 password.
- After inputting the program, press OUT to exit the program file and return to the program list. Files that are password protected are indicated by an asterisk to the right of the file name.





The second second second second second second second second second second second second second second second s

P.37

Program Name [OCTAD]]

Search For

Program List


OCTONARY

EXE BOIL NEW

COCTO

UCTH

Program



- •To edit program contents
- 1. Find the file name of the program you want in the program list.

- 2. Re
 - 2. Recall the program.
 - The procedures you use for editing program contents are identical to those used for editing manual calculations. For details, see "Making Corrections".



P.20

The following function keys are also useful when editing program contents.

F1 (TOP) Moves the cursor to the top of the program

= OCTA = 2+A:2×J3×A² J2+3×A^3

F2 (BTM) Moves the cursor to the bottom of the program

= OCTA ?+A:2×J3×Aª J2÷3×A^3_	=
?+A:2×\3×A	i S
√2÷3×A^3_	

Example 2 To use the OCTA program to create a program that calculates the surface area and volume of regular tetrahedrons when the length of one side is known

	Length of One Side (A)	Surface Area (S)	Volume (V)
	7 cm	Cm ²	Cm ³
<>	10 cm	cm²	Cm ³
V	15 cm	cm²	Cm ³

The following are the formulas used for calculating surface area S and volume V of a regular tetrahedron for which the length of one side is known.

$$S = \sqrt{3} A^2$$
, $V = \frac{\sqrt{2}}{12} A^3$

4

Use the following key operations when inputting the program.

Length of One Side A	SHIFT (?) → ALPHA A ▷ F3(:)
Surface Area S	9HFT 🗸 3 🗙 MPA A x² ▷ ▷ F2 (4)
Volume V	Sef 🗸 2 🕂 1 2 🗙 Arma A 🛆 3


Compare this with the program for calculating the surface area and volume of a regular octahedron.

Length of One Side A	SHIFT (?)→	ALPHA 🔺 ▷ 🛛	3(:)
Surface Area S			
Volume V)		3

As you can see, you can produce the TETRA program by making the following changes in the OCTA program.

- Deleting 2 X (underlined using a wavy line above)
- Changing 3 to 1 2 (underlined using a solid line above)


Let's edit the program.



Length of One Side (A)	Surface Area (S)	Volume (V)
7 cm	84.87048957 cm ²	40.42293766 cm ³
10 cm	173.2050808 cm ²	117.8511302 cm ³
15 cm	389.7114317 cm ²	397.7475644 cm ³

F1 (EXE) or EXE

(Value of A)



AND REPORT OF THE OWNER OF THE OWNER OF THE OWNER OF THE OWNER OF THE OWNER OF THE OWNER OF THE OWNER OF THE OWN




EXE

EXE

1 0 EXE

EXE

Programming Chapter 8



Contents" for details.

9. Useful Program Commands


In addition to calculation commands, this calculator also includes a variety of relational and jump commands that can be used to create programs that make repeat calculations quick and easy.

Program Menu

P.37

Press [SHIT] [RGII] to display the program menu.

F2(DEL•A)



8. Deleting a Program

There are two different ways to delete a file name and its program.

- Specific program delete
- All program delete

To delete a specific program

1. While the program list is on the display, use (a) and () to move the highlighting to the name of the program you want to delete.

84.8704895

84.87048957 40.42293766

40.42293766

173.2050808

40.42293766

- Disp -

?

?

? 10

2. Press D F1 (DEL).

D F1(DEL)

3. Press [F1] (YES) to delete the selected program or [F4] (NO) to abort the operation without deleting anything.

To delete all programs

1. While the program list is on the display, press D F2 (DEL•A).

F4

Lbl Goto ⇒

ISZ DSZ

F2 F1


F2

F3

F1

Þ


⊳



1	Text	Grph	List	1
	FI	E2	F3	

F2 (Grph) CirGraph command

While the program menu is on the display, press D F4 (DISP) to display the dis-




F1 (Stat) DrawStat command

[F3] (TABL) Table & Graph command menu

Pressing [3] (TABL) while the display command menu is on the display causes the Table & Graph command menu to appear.

140

Linnigh



Input/Output Commands Menu (I/O)

While the program menu is on the display, press \triangleright \triangleright \models (I/O) to display the input/output command menu.

▶**►F**2(I/O)

SendRecu			1
F1 F2	t s t	2	•

F1 (Send) Send (command F2 (Recv) Receive (command

10. Command Reference

Command Index

Break	
CirGraph	
CIrList	
CirText	
DispTable	154
Do-LpWhile	148
DrawTG-Con, DrawTG-Plt	154
DrawGraph	
DrawStat	153
Dsz	151
For~To~Next	147
For-To-Step-Next	
Goto~Lbl	151
If-Then	145
If~Then~Else	146
If-Then-Else-IfEnd	
If~Then~IfEnd	145
lsz	152
Prog	149
Receive(154
Beturn	150
Send(155
Stop	150
M/bile M/bileEnd	
? (Input Command)	
▲ (Output Command)	144
: (Multi-statement Command)	144
→ (Carriage Return)	144
⇒ (Jump Code)	152
\Rightarrow (out in points)	155

The following are conventions that are used in this section when describing the various commands.

Boldface Text	Actual commands and other items that always must be in-
	put are shown in boldface.
Sector Sector States and Sector	Curly brackets are used to enclose a number of items, one of which must be selected when using a command. Do not input the curly brackets when inputting a command.

[Square Brackets]...... Square brackets are used to enclose items that are optional. Do not input the square brackets when inputting a command.

Numeric Expressions . Numeric expressions (such as 10, 10 + 20, A) indicate constants, calculations, numeric constants, etc.

Alpha Characters Alpha characters indicate literal strings (such as AB).

Basic Operation Commands

? (Input Command)

Function: Prompts for input of values for assignment to variables during program execution.

Syntax: ? \rightarrow <variable name>

Example: $? \rightarrow A \downarrow$

Description:

- This command momentarily interrupts program execution and prompts for input of a value or expression for assignment to a variable. When the input command is executed, "?" to appears on the display and the calculator stands by for input.
- Input in response to the input command must be a value or an expression, and the expression cannot be a multi-statement.

(Output Command)

Function: Displays and intermediate result during program execution.

Description:

- This command momentarily interrupts program execution and displays alpha character text or the result of the calculation immediately before it.
- 2. The output command should be used at locations where you would normally press the EXE key during a manual calculation.

: (Multi-statement Command)

Function: Connects two statements for sequential execution without stopping. Description:

- 1. Unlike the output command (⊿), statements connected with the multi-statement command are executed non-stop.
- The multi-statement command can be used to link two calculation expressions or two commands.

↓ (Carriage Return)

Function: Connects two statements for sequential execution without stopping.

Description:

- 1. Operation of the carriage return is identical to that of the multi-statement command.
- Using a carriage return in place of the multi-statement command makes the displayed program easier to read.

Program Commands (COM)

If~Then Function: The Then-statement is executed only when the If-condition is true (non-zero). Syntax: If <condition> numeric expression Image: Ima

Parameters: condition, numeric expression


Description:

- 1. The Then-statement is executed only when the If-condition is true (non-zero).
- 2. If the condition is false (0), the Then-statement is not executed.
- An If-condition must always be accompanied by a Then-statement. Omitting the Then-statement results in an error (Syn ERROR).

Example: If $A = 0 \nleftrightarrow$ Then "A = 0"

lf~Then~lfEnd

Function: The Then-statement is executed only when the If-condition is true (nonzero). The IfEnd-statement is always executed: after the Then-statement is executed or directly after the If-condition when the If-condition is false (0).



Parameters: condition, numeric expression

Description:

This command is almost identical to If-Then. The only difference is that the IfEndstatement is always executed, regardless of whether the If-condition is true (nonzero) or false (0).

```
Example: If A = 0 ↔
Then "A = 0" ↔
IfEnd ↔
"END"
```

If~Then~Else

Function: The Then-statement is executed only when the If-condition is true (nonzero). The Else-statement is executed when the If-condition is false (0). Syntax:

If
$$\frac{\langle \text{condition} \rangle}{\text{numeric expression}} \left\{ \begin{array}{c} \mathbf{I} \\ \mathbf{I} \\ \mathbf{I} \end{array} \right\}$$
 Then $\langle \text{statement} \rangle \left[\left\{ \begin{array}{c} \mathbf{I} \\ \mathbf{I} \\ \mathbf{I} \end{array} \right\} \langle \text{statement} \rangle \right]$
$$\left\{ \begin{array}{c} \mathbf{I} \\ \mathbf{I} \\ \mathbf{I} \end{array} \right\}$$
 Else $\langle \text{statement} \rangle \left[\left\{ \begin{array}{c} \mathbf{I} \\ \mathbf{I} \\ \mathbf{I} \end{array} \right\} \langle \text{statement} \rangle \right]$

Parameters: condition, numeric expression

Description:

1. The Then-statement is executed when the If-conditions is true (non-zero).

2. The Else-statement is executed when the If-conditions is false (zero).

```
Example: If A = 0 +
```

Then "TRUE" + Else "FALSE"

If~Then~Else~IfEnd

Function: The Then-statement is executed only when the fr-condition is true (nonzero). The Else-statement is executed when the If-condition is false (0). The IfEndstatement is always executed following either the Then-statement or Else-statement.

Syntax:

If
$$\frac{\langle \text{condition} \rangle}{\text{numeric expression}} \left\{ \begin{array}{c} \downarrow \\ \downarrow \\ \downarrow \end{array} \right\}$$
 Then $\langle \text{statement} \rangle \left[\left\{ \begin{array}{c} \downarrow \\ \downarrow \\ \downarrow \end{array} \right\} \langle \text{statement} \rangle \right] \left\{ \begin{array}{c} \downarrow \\ \downarrow \\ \downarrow \end{array} \right\}$ Else $\langle \text{statement} \rangle \left[\left\{ \begin{array}{c} \downarrow \\ \downarrow \\ \downarrow \end{array} \right\} \langle \text{statement} \rangle \right] \left\{ \begin{array}{c} \downarrow \\ \downarrow \\ \downarrow \end{array} \right\}$ IfEnd

Parameters: condition, numeric expression

Description:

This command is almost identical to If~Then~Else. The only difference is that the IfEnd-statement is always executed, regardless of whether the If-condition is true (non-zero) or false (0).

Example: $? \rightarrow A \downarrow$

If A = 0Then "TRUE" Else "FALSE" IfEnd 🚽 "END"

For~To~Next

Function: This command repeats everything between the For-statement and the Next-statement. The starting value is assigned to the control variable with the first execution, and the value of the control variable is incremented by one with each execution. Execution continues until the value of the control variable exceeds the ending value.

Syntax: F

Parameters:

- control variable name: A to Z
- starting value: value or expression that produces a value (i.e. sin x, A, etc.)
- ending value: value or expression that produces a value (i.e. sin x, A, etc.)

Description:

- 1. When the starting value of the control variable is greater than the ending value, execution continues from the statement following Next, without executing the statements between For and Next.
- 2. A For-statement must always have a corresponding Next-statement, and the Nextstatement must always come after its corresponding For-statement.
- 3. The Next-statement defines the end of the loop created by For~Next, and so it must always be included. Failure to do so results in an error (Syn ERROR).

Example: For 1 → A To 10 →

- $A \times 3 \rightarrow B \rightarrow B$ В 🖌
- Next

For~To~Step~Next

Function: This command repeats everything between the For-statement and the Next-statement. The starting value is assigned to the control variable with the first execution, and the value of the control variable is changed according to the step value with each execution. Execution continues until the value of the control variable exceeds the ending value.

Syntax:

For <starting value> \rightarrow <control variable name> To <ending value> Step <step value>

Next

Parameters:

- control variable name: A to Z
- starting value: value or expression that produces a value (i.e. sin x, A, etc.)
- ending value: value or expression that produces a value (i.e. sin x, A, etc.)
- step value: numeric value (omitting this value sets the step to 1)

Programming Chapter 8

Description:

- 1. This command is basically identical to For~To~Next. The only difference is that you can specify the step.
- 2. Omitting the step value automatically sets the step to 1.
- 3. Making the starting value less than the ending value and specifying a positive step value causes the control variable to be incremented with each execution. Making the starting value greater than the ending value and specifying a negative step value causes the control variable to be decremented with each execution.

Example: For 1 → A To 10 Step 0.1 →

 $A \times 3 \rightarrow B \rightarrow$ B 🖌

Next

Do~LpWhile

Function: This command repeats specific commands as long as its condition is true (non-zero).

Syntax:

Do { + Compared to the second

Parameters: expression

Description:

- 1. This command repeats the commands contained in the loop as long as its condition is true (non-zero). When the condition becomes false (0), execution proceeds from the statement following the LpWhile-statement.
- 2. Since the condition comes after the LpWhile-statement, the condition is tested (checked) after all of the commands inside the loop are executed.

Example: Do

 $? \rightarrow A \rightarrow$ $A \times 2 \rightarrow B_{-}$ В 🖌 LpWhile B >10

While~WhileEnd

Function: This command repeats specific commands as long as its condition is true (non-zero).

Svntax:

While <expression> { + } ~ WhileEnd

Parameters: expression



- 1. This command repeats the commands contained in the loop as long as its condition is true (non-zero). When the condition becomes false (0), execution proceeds from the statement following the WhileEnd-statement.
- 2. Since the condition comes after the While-statement, the condition is tested (checked) before the commands inside the loop are executed.

Example: $10 \rightarrow A \rightarrow A$ While A > 0+

 $A - 1 \rightarrow A \rightarrow A$ "GOOD" WhileEnd

Program Control Commands (CTL)

Break

Function: This command breaks execution of a loop and continues from the next command following the loop.

Syntax: Break +

Description:

- 1. This command breaks execution of a loop and continues from the next command following the loop.
- 2. This command can be used to break execution of a For-statement, Do-state-
- ment, and While-statement.

Example: While A>0 -If A > 2+

> Then Break IfEnd -WhileEnd - Executed after Break $A \checkmark \leftarrow$

Prog

Function: This command specifies execution of another program as a subroutine. In the RUN Mode, this command executes a new program.


Syntax: Prog "file name" +

Example: Prog "ABC" +

Description:

- 1. Even when this command is located inside of a loop, its execution immediately breaks the loop and launches the subroutine.
- 2. This command can be used as many times as necessary inside of a main routine to call up independent subroutines to perform specific tasks.

A subroutine can be used in multiple locations in the same main routine, or it can be called up by any number of main routines.



- Calling up a subroutine causes it to be executed from the beginning. After execution of the subroutine is complete, execution returns to the main routine, continuing from the statement following the Prog command.
- A Goto-Lbl command inside of a subroutine is valid inside of that subroutine only. It cannot be used to jump to a label outside of the subroutine.
- If a subroutine with the file name specified by the Prog command does not exist, an error (Go ERROR) occurs.
- 7. In the **RUN Mode**, inputting the Prog command and pressing 🖼 launches the program specified by the command.

Return

Function: This command returns from a subroutine.

Syntax: Return 🚽

Description:

Execution of the Return command inside a main routine causes execution of the program to stop.

Example: Prog "A" 1 → A ↓ Prog "B" ↓ C ↓ Prog "B" For A → B To 10 ↓ B + 1 → C ↓ Next ↓ Return

Executing the program in File A displays the result of the operation (11).

Stop

Function: This command terminates execution of a program.

Syntax: Stop 4

Description:

- 1. This command terminates program execution.
- Execution of this command inside of a loop terminates program execution without an error being generated.

Example: For 2 → I To 10 ↓ If I = 5 ↓ Then "STOP" : Stop ↓ IfEnd ↓ Next


This program counts from 2 to 10. When the count reaches 5, however, it terminates execution and displays the message "STOP."

Jump Commands (JUMP)

Dsz

Function: This command is a count jump that decrements the value of a control variable by 1, and then jumps if the current value of the variable is zero.

Syntax:



Parameters:

Variable Name: A to Z

[Example] Dsz B : Decrements the value assigned to variable B by 1.

Description:

This command decrements the value of a control variable by 1, and then tests (checks) it. If the current value is non-zero, execution continues with the next statement. If the current value is zero, execution jumps to the statement following the multi-statement command (:), display command (\checkmark), or carriage return (\prec).

Example: $10 \rightarrow A : 0 \rightarrow C$:

Lbl 1 : ? \rightarrow B : B+C \rightarrow C : Dsz A : Goto 1 : C + 10 This program prompts for input of 10 values, and then calculates the average of the input values.

Goto~Lbl

Function: This command performs an unconditional jump to a specified location.

Syntax: Goto <value or variable> ~ Lbl <value or variable>

Parameters: Value (from 0 to 9), variable (A to Z)

Description:

- This command consists of two parts: Goto n (where n is a value from 0 to 9) and Lbl n (where n is the value specified for Goto). This command causes program execution to jump to the Lbl-statement whose value matches that specified by the Goto-statement.
- This command can be used to loop back to the beginning of a program or to jump to any location within the program.

- This command can be used in combination with conditional jumps and count jumps.
- If there is no LbI-statement whose value matches that specified by the Gotostatement, an error (Go ERROR) occurs.

Example: $? \rightarrow A : ? \rightarrow B : Lbl 1 :$ $? \rightarrow X : A \times X + B \checkmark$


Goto 1

This program calculates y = AX + B for as many values for each variable that you want to input. To quit execution of this program, press \boxed{AC} .

lsz

Function: This command is a count jump that increments the value of a control variable by 1, and then jumps if the current value of the variable is zero.

Syntax:



Parameters:

Variable Name: A to Z

[Example] Isz A : Increments the value assigned to variable A by 1.


Description:

This command increments the value of a control variable by 1, and then tests (checks) it. If the current value is non-zero, execution continues with the next statement. If the current value is zero, execution jumps to the statement following the multi-statement command (:), display command (\checkmark), or carriage return (\checkmark).

\Rightarrow (Jump Code)

Function: This code is used to set up conditions for a conditional jump. The jump is executed whenever the conditions are false.

Syntax:



Parameters:

left side/right side: variable (A to Z), numeric constant, variable expression (such as: $A\times 2)$



relational operator: =, \neq , >, <, ≥, ≤

Description:

- The conditional jump compares the contents of two variables or the results of two expressions, and a decision is made whether or not to execute the jump based on the results of the comparison.
- If the comparison returns a true result, execution continues with the statement following the ⇒ command. If the comparison returns a false result, execution jumps to the statements following the multi-statement command (:), display command (∠), or carriage return (∠).

Example: Lbl 1 : ? \rightarrow A : A \geq 0 $\Rightarrow \sqrt{-}$ A \checkmark Goto 1

With this program, inputting a value of zero or greater calculates and displays the square root of the input value. Inputting a value less than zero returns to the input prompt without calculating anything.

Clear Commands (CLR)

ClrGraph

Function: This command clears the graph screen.

Syntax: ClrGraph -

Description: This command clears the graph screen during program execution.

CIrList

Function: This command clears list data.

Syntax: ClrList -

Description: This command clears the contents of the currently selected list (List 1 to List 6) during program execution.

CIrText

Function: This command clears the text screen.

Syntax: ClrText

Description:

This command clears text from the screen during program execution.

Display Commands (DISP)

DrawStat

Function: This draws a statistical graph. Syntax: DrawStat

Programming Chapter 8

Description:

This command draws a statistical graph in accordance with conditions defined within the program.

DrawGraph

Function: This command draws a graph.

Syntax: DrawGraph

Description: This command draws a graph in accordance with the drawing conditions defined within the program.

DispTable

Function: These commands display numeric tables.

Syntax:

DispTable 🗸

Description:

These commands generate numeric tables during program execution in accordance with conditions defined within the program.

DrawTG-Con, DrawTG-Plt

Function: These commands graph functions.

Syntax:

DrawTG-Con

DrawTG-Plt

Description:

- These commands graph functions in accordance with conditions defined within the program.
- 2. DrawTG-Con produces a connect type graph, while DrawTG-Plt produces a plot type graph.

Input/Output Commands (I/O)

Receive (

Function: This command receives data from an external device. Syntax: Receive (<data>) (...ex. Receive (List 1)) Description:

- 1. This command receives data from an external device.
- 2. The following types of data can be received by this command.
- Individual values assigned to variables
- List data (all values individual values cannot be specified)

Send (

Function: This command sends data to an external device.

Syntax: Send (<data>) (...ex. Send (List 1))

Description:

- 1. This command sends data to an external device.
- 2. The following types of data can be sent by this command.
- Individual values assigned to variables
- · List data (all values individual values cannot be specified)

Conditional Jump Relational Operators (REL)

=, ≠, >, <, ≥, ≤

Function: These relational operators are used in combination with the conditional jump command.

Syntax:

<left side> <relational operator> <right side> => <statement>

<statement> (With Jump Code)

Parameters:

left side/right side: variable (A to Z), numeric constant, variable expression (such as: $A \times 2$)

relational operator: =, \neq , >, <, \geq , \leq

Description:

P.152

 The following six relational operators can be used in the conditional jump command

<left side> = <right side> : true when <left side> equals <right side>

<left side> + <right side> : true when <left side> does not equal <right side>

<left side> > <right side> : true when <left side> is greater than <right side>

<left side> < <right side> : true when <left side> is less than <right side>

<left side> ≥ <right side> : true when <left side> is greater than or equal to <right side>

<left side> < <right side> : true when <left side> is less than or equal to <right side>

2. See " \Rightarrow (Jump Code)" for details on using the conditional jump.

Programming Chapter 8

11. Text Display

You can include text in a program by simply enclosing it between double quotation marks. Such text appears on the display during program execution, which means you can add labels to input prompts and results.

Program Display

$$"X ="? \rightarrow X \qquad X = ?$$

If the text is followed by a calculation formula, be sure to insert a display command (*A*) between the text and calculation.

 Inputting more than 13 characters causes the text to move down to the next line. The screen scrolls automatically if the text causes the screen to become full.

12. Using Calculator Functions in Programs

P.48

Using Graph Functions in a Program

You can incorporate graph functions into a program to draw complex graphs and to overlay graphs on top of each other. The following shows various types of syntax you need to use when programming with graph functions.

View Window

- View Window -5, 5, 1, -5, 5, 1 +
- · Graph function input

Y = Type - Specifies graph type.

```
"X<sup>2</sup> − 3" → Y1 \clubsuit
```


Graph draw operation

```
DrawGraph -
```

Example Program

```
    <sup>①</sup> ClrGraph →
    <sup>②</sup> View Window -10, 10, 2, -120, 150, 50 →
    <sup>③</sup> Y = Type →
    <sup>③</sup> X ^ 4 - X ^ 3 - 24X<sup>2</sup> + 4X + 80" → Y1 →
    <sup>⑤</sup> G SelOn 1 →
    <sup>⑥</sup> DrawGraph
```

^① SEF F3 F3 C1 CUT ^② SEF F3 F1 CUT ^③ F3 F3 F2 F1 CUT ^④ F3 F3 F2 F1 CUT ^⑤ F3 F3 F1 F1 ^⑥ SEF F1 F1 ^⑥ SEF F1 F1 ^⑥ SEF F1 F1 Executing this program produces the result shown here.





Using Table & Graph Functions in a Program


Table & Graph functions in a program can generate numeric tables and perform graphing operations. The following shows various types of syntax you need to use when programming with Table & Graph functions.

Table range setting

- 1 → F Start →
- $5 \rightarrow F End$
- 1 → F pitch ←
- Numeric table generation
 - DispTable 🖊
- Graph draw operation
 Connect type: DrawTG-Con
 Plot type: DrawTG-Plt

Example Program

ClrGraph -CirText -View Window 0, 6, 1, -2, 106, 20 -Y = Type 🚽 " $3X^2 - 2" \rightarrow Y1 \rightarrow$ ⁽¹⁾ F3 F4 F1 QUT 1 T SelOn 1 2 WARS > F3 F1 $0 \rightarrow {}^{\textcircled{0}}F$ Start ³ [F2] $6 \rightarrow {}^{3}F End \rightarrow$ 4 F3 QUIT $1 \rightarrow {}^{\textcircled{}}F$ pitch \checkmark ⁽⁵⁾ SHIFT (PRGM (>) F4 F3 F1 QUIT ⁽⁵⁾ DispTable 4 [©] SHIFT (PRGN) ▷ F4 F3 F2 QUIT [®] DrawTG-Con



Mark Type

The graph conditions that are required depends on the graph type. See "Changing Graph Parameters".

• The following is a typical graph condition specification for a scatter diagram or xy line graph.

S-Gph1 DrawOn, Scatter, List1, List2, 1, Square -

In the case of an *xy* line graph, replace "Scatter" in the above specification with "*xy*Line".

- The following is a typical graph condition specification for a stacked bar chart, bar graph, or line graph.

Stacked bar chart: S-Gph1 DrawOn, StackedBar, List1 +

- Bar graph: S-Gph1 DrawOn, Bar, List1 🗸
- Line graph: S-Gph1 DrawOn, LineG, List1 -
- The following is a typical graph condition specification for a superimposed bar and line graph.
 - S-Gph1 DrawOn, Both, List1 (bar graph list), List2 (line graph list), Sep. G(AutoWin setting) -
- The following is a typical graph condition specification for a single-variable graph. S-Gph1 DrawOn, Hist, List1, List2-J

The same format can be used for the following types of graphs, by simply replacing "Hist" in the above specification with the applicable graph type.

Histogram: Hist

Median Box: MedBox


Normal Distribution: N-Dist

- The following is a typical graph condition specification for a regression graph.
 - S-Gph1 DrawOn, Linear, List1, List2, List3 -

The same format can be used for the following types of graphs, by simply replacing "Linear" in the above specification with the applicable graph type.

Linear Regression: Linear

- Med-Med: Med-Med
- Quadratic Regression: ... Quad
 - Logarithmic Regression: . Log
 - Exponential Regression: Exp
 - Power Regression : Power



Chapter 0

Data Communications

This chapter tells you everything you need to know to transfer programs between the fx-7400G PLUS and certain CASIO Graphic Scientific Calculator models connected with an optionally available SB-62 cable. To transfer data between a unit and a personal computer, you will need to purchase the separately available CASIO Interface Unit.

This chapter also contains information on how to use the optional SB-62 cable to connect to a CASIO Label Printer to transfer screen data for printing.

- 1. Connecting Two Units
- 2. Connecting the Unit with a Personal Computer
- 3. Connecting the Unit with a CASIO Label Printer
- 4. Before Performing a Data Communication Operation
- 5. Performing a Data Transfer Operation
- 6. Screen Send Function
- 7. Data Communications Precautions




1. Connecting Two Units

The following procedure describes how to connect two units with an optional SB-62 connecting cable for transfer of programs between them.

To connect two units

- 1. Check to make sure that the power of both units is off.
- 2. Remove the covers from the connectors of the two units.
- Be sure you keep the connector covers in a safe place so you can replace them after you finish your data communications.

3. Connect the two units using the SB-62 cable.



SB-62 cable



Keep the connectors covered when you are not using them.


2. Connecting the Unit with a Personal Computer

To transfer data between the unit and a personal computer, you must connect them through a separately available CASIO Interface Unit.

For details on operation, the types of computer that can be connected, and hardware limitations, see the user's guide that comes with the Interface Unit.

Some types of data may not be able to be exchanged with a personal computer.

- •To connect the unit with a personal computer
- 1. Check to make sure that the power of the unit and the personal computer is off.
- 2. Connect the personal computer to the Interface Unit.
- 3. Remove the cover from the connector of the unit.
- Be sure you keep the connector cover in a safe place so you can replace it after you finish your data communications.
- 4. Connect the unit to the Interface Unit.
- 5. Turn on the power of the unit, followed by the personal computer.
- After you finish data communications, turn off power in the sequence: the unit first, and then the personal computer. Finally, disconnect the equipment.



164


3. Connecting the Unit with a CASIO Label Printer

After you connect the unit to a CASIO Label Printer with an optional SB-62 cable, you can use the Label Printer to print screen shot data from the unit. See the user's guide that comes with your Label Printer for details on how to perform this operation.

• The operation described above can be performed using the following Label Printer models: KL-2000, KL-2700, KL-8200, KL-8700 (as of February 1999).

To connect the unit with a Label Printer

- 1. Check to make sure that the power of the unit and the Label Printer is off.
- 2. Connect the optional SB-62 cable to the Label Printer.
- 3. Remove the cover from the connector of the unit.
- Be sure you keep the connector cover in a safe place so you can replace it after you finish your data communications.
- 4. Connect the other end of the SB-62 cable to the unit.
- 5. Turn on the power of the unit, followed by the Label Printer.



 After you finish data communications, turn off power in the sequence: the unit first, and then the Label Printer. Finally, disconnect the equipment.

4. Before Performing a Data Communication Operation

In the Main Menu, select the LINK icon and enter the LINK Mode. The following data communication main menu appears on the display.



期目的评

4

P.172

Image Set: Indicates the status of the graphic image send features.

Off: Graphic images not sent.

On: Pressing 🗐 sends graphic images.

F1 (TRAN) Menu of send settings

F2 (RECV) Menu of receive settings

F4 (IMGE) Menu of graphic image transfer settings

Communications parameters are fixed at the following settings.

- Speed (BPS): 9600 bits per second
- Parity (PARITY): NONE


5. Performing a Data Transfer Operation

Connect the two units and then perform the following procedures.

Receiving unit

To set up the calculator to receive data, press F2 (RECV) while the data communication main menu is displayed.

F2 (RECV)



The calculator enters a data receive standby mode and waits for data to arrive. Actual data receive starts as soon as data is sent from the sending unit.

Sending unit

To set up the calculator to send data, press F1 (TRAN) while the data communication main menu is displayed.

F1 (TRAN)

Select Trans F1:Select F4:Backup	Гуре
SE	BACIZ
FI	F4

Press the function key that corresponds to the type of data you want to send.


F1 (SEL) Selects data items and sends them

F4 (BACK) All memory contents, including mode settings

To send selected data items

Press F1 (SEL) to display a data item selection screen.

F1(SEL)



F1 (SEL) Selects data item where cursor is located.

F4 (TRAN) Sends selected data items.

Use the (a) and (cursor keys to move the cursor to the data item you want to select and press (F) (SEL) to select it. Currently selected data items are marked with " \blacktriangleright ". Pressing (IRAN) sends all the selected data items.

• To deselect a data item, move the cursor to it and press F1 (SEL) again.

Only items that contain data appear on the data item selection screen. If there are too many data items to fit on a single screen, the list scrolls when you move the cursor to the bottom line of the items on the screen.


The following are the types of data items that can be sent.

Data Item	Contents	Overwrite Check*1	Password Check* ²
Program	Program contents	Yes	Yes
List n	List memory (1 to 6) contents	Yes	
Y=Data	Graph expressions, graph write/ non-write status, View Window contents, zoom factors	No	
V-Win	View Window memory contents	No	
Variable	Variable assignments	No	

*1 No overwrite check: If the receiving unit already contains the same type of data, the existing data is overwritten with the new data.

With overwrite check: If the receiving unit already contains the same type of data, a message appears to ask if the existing data should be overwritten with the new data.


Chapter 9 **Data Communications**



Transmitting AC:Cancel

• You can interrupt a data operation at any time by pressing AC.

The following shows what the displays of the sending and receiving units look like after the data communication operation is complete.



Press AC to return to the data communication main menu.

•To send backup data


This operation allows you to send all memory contents, including mode settings. While the send data type selection menu is on the screen, press F4 (BACK), and the back up send menu shown below appears.

F4 (BACK)

Backup Trans F4:Transmit AC:Cancel TRAN F4

Press F4 (TRAN) to start the send operation.


F4 (TRAN)



The following shows what the displays of the sending and receiving units look like after the data communication operation is complete.

170

Chapter 9 Data Communications



Press AC to return to the data communication main menu.

Ð

Data can become corrupted, necessitating a RESET of the receiving unit, should the connecting cable become disconnected during data transfer. Make sure that the cable is securely connected to both units before performing any data communication operation.

6. Screen Send Function

The following procedure sends a bit mapped screen shot of the display to a connected computer.

To send the screen

- 1. Connect the unit to a personal computer or to a CASIO Label Printer.
- 2. In the data communication main menu, press [4] (IMGE), and the following display appears.

F4 (IMGE)



F1 (Off) Graphic images not sent

F2 (On) Bitmap

- 3. Display the screen you want to send.
- 4. Set up the personal computer or Label Printer to receive data. When the other unit is ready to receive, press to start the send operation.

- Data Communications Chapter 9
- You cannot send the following types of screens to a computer.
- The screen that appears while a data communication operation is in progress.
- A screen that appears while a calculation is in progress.
- The screen that appears following the reset operation.
- · The low battery message.
- The flashing cursor is not included in the screen image that is sent from the unit.
- If you send a screen shot of any of the screens that appear during the data send operation, you will not be able to then use the sent screen to proceed with the data send operation. You must exit the data send operation that produced the screen you sent and restart the send operation before you can send additional data.
- You cannot use 6mm wide tape to print a screen shot of a graph.

7. Data Communications Precautions

Note the following precautions whenever you perform data communications.

- An error occurs whenever you try to send data to a receiving unit that is not yet standing by to receive data. When this happens, press AC to clear the error and try again, after setting up the receiving unit to receive data.
- An error occurs whenever the receiving unit does not receive any data approximately six minutes after it is set up to receive data. When this happens, press are to clear the error.
- An error occurs during data communications if the cable becomes disconnected, if the parameters of the two units do not match, or if any other communications problem occurs. When this happens, press a to clear the error and correct the problem before trying data communications again. If data communications are interrupted by a key operation or an error, any data successfully received up the interruption will be in the memory of the receiving unit.
- An error occurs if the receiving unit memory becomes full during data communications. When this happens, press <u>AC</u> to clear the error and delete unneeded data from the receiving unit to make room for the new data, and then try again.
- To send picture (graph) memory data, the receiving unit need 1-kbytes of memory for use as a work area in addition to the data being received.



Program Library

- **1** Prime Factor Analysis
- 2 Greatest Common Measure
- 3 t-Test Value
- 4 Circle and Tangents
- 5 Rotating a Figure

Before using the Program Library

- Be sure to check how many bytes of unused memory is remaining before attempting to perform any programming.
- This Program Library is divided into two sections: a numeric calculation section and a graphics section. Programs in the numeric calculation section produce results only, while graphics programs use the entire display area for graphing. Also note that calculations within graphics programs do not use the multiplication sign (×) wherever it can be dropped (i.e. in front of open parenthesis).



Program for

Prime Factor Analysis

Description

Produces prime factors of arbitrary positive integers

For $1 < m < 10^{10}$

Prime numbers are produced from the lowest value first. "END" is displayed at the end of the program.

No.

1

(Overview)

m is divided by 2 and by all successive odd numbers (d = 3, 5, 7, 9, 11, 13,) to check for divisibility.

Where d is a prime factor, $m_i = m_{i-1}/d$ is assumed, and division is repeated until $\sqrt{m_i} + 1 \le d$.

Example [1]

```
119 = 7 × 17
[2]
440730 = 2 × 3 × 3 × 5 × 59 × 83
[3]
262701 = 3 × 3 × 17 × 17 × 101
```

Preparation and operation

• Store the program written on the next page.

• Execute the program as shown below.


Step	Key operation	Display	Step	Key operation	Display
1	F1(EXE)	M?	11	EXE	83
2	119 EXE	7	12	EXE	END
3	EXE	17	13	EXE	M?
4	EXE	END	14	262701 EXE	3
5	EXE	M?	15	EXE	3
6	440730 EXE	2	16	EXE	17
7	EXE	3	17	EXE	17
8	EXE	3	18	EXE	101
9	EXE	5	19	EXE	END
10	EXE	59	20		

Line									Pr	ogra	am								
File name	Р	R	М		F	Α		T							1				1
1	Lbl	0	:		М		?	\rightarrow	Α	1:	Goto	2	:		с. ⁶				1
2	Lbl	×1*	:	2	4	Α	÷	2	\rightarrow	A	::	Α	=	1	⇒	Goto	9	:	1
3	Lbl	2	:	Frac	(A	÷	2)	: =	0	⇒	Goto	1		3	\rightarrow	В	
4	Lbl	3	:		Α	+	1	\rightarrow	С	:									1
5	Lbl	4	:	В	\geq	C	\Rightarrow	Goto	8	:	Frac	(Α	÷	В)	=	0	:=
6	Goto	6	:							1									
7	Lbl	5	:	В	+	2	\rightarrow	В		Goto	4	:				1 1 1			1
8	Lbl	6	:	Α	÷	В	×	В	-	Α	=	0	⇒	Goto	7	:	Goto	5	1
9	Lbl	7	:	В		Α	÷	В	\rightarrow	A	:	Goto	3						-
10	Lbl	8	:	Α		-													
11	Lbl	9	:		Е	Ν	D	11	4	Goto	0								
12																			1
13										1.									-
14					, i • ,														1
15										1									l
16		1				1													
17																		н	
18						i i						1							1
19						1													
20			1 .							-								1997 - 1997 1997 - 1997 1997 - 1997	
21						1				1									1
22						1.5				1	· · ·	1							1
23						1							, <i>1</i>						-
24						1				-		1							;
25						1				1								- -	
26				1						1									1
27		1. N									F.								-
1.14	A		n	li		H				C)				V				
nts	В		0			1		·	1.14	F	2		· · · ·		W	/			
Memory Contents	С		√mi ·			J				0	2				X		1.1		
ပိ	D	1.1		·		K				F	2	•		-	Y				-
lory	Е					L	3.4		1	5	3				Z				
Men	F					М				1	Г			t pre					•
	G		1.1.1			N	1			ι	1		· · ·	-					

No.

1

Prog	ram for				= 2													ſ	NO.			2			
		ommon Measu	ure			Line									Pr	ogra	am								
Des	<u>cription</u>			방법 이 같은 것이 있었다.		File name	C	М	N		F	A	С	т					1						
	Euclidean general div a and b.	ision is used to deterr	nine the	greatest common mea	sure for two interers		LbI			. H	Α	<u> </u>	?	\rightarrow	Α		. 11	В		?		в		· · · · · · ·	<u></u>
		0º, positive values ar	e taken	as < 1010		1		A		A		Abs		\rightarrow						1	\rightarrow		•		<u> </u>
	(Overview) $n_0 = \max(a ,$	12.11				2	B	the second second			Goto		:	_						<u> </u>	<u> </u>				
	$n_0 = \max(a , n_1 = \min(a , n_1 = \max(a , n_1 = \min(a , n_1 = \min(a , n_1 = \max(a , n_1$					4	A	\rightarrow			B			:	С	\rightarrow	В	1 :							
	$n_k = n_{k-2} - \left\lceil \frac{n}{n} \right\rceil$					5		2		· (-)	المحمد معالم	Int		A	÷			×	B	-	Α		\rightarrow	С	
	a a ser e ser e ser i tra 🖓 🗮 🕯	<i>k</i> -1				6	C				Goto	·	<u> </u>												-
	k = 2, 3 If $n_k = 0$, then	the greatest common	n measu	re (<i>c</i>) will be <i>n_{k-1}.</i>		7		\rightarrow				\rightarrow		:	Goto	2	:				-				-
<u>i</u> pe						8	LbI			В		Goto						<u>.</u>	1						
Exa	mple [1]	[2]	[3]			9												1		1	1				-
	When $a = 23$ b = 37		= 52295 = 32081			10								() () ()	1		1	ł	İ.		1				-
	1	↓↓↓				11														1					1.
	<i>c</i> = 34	<i>c</i> = 1015 <i>c</i>	= 998			12												1							-
						13			19								1		1						i.
						14											1 .		1						
						15	1				1														
						16										1		-							-
						17			ан 11		1.1						1	1		-	-				1
Pre	paration and oper	ation				18		1 1																	1
	Store the program w		je.			19	1			1							1	1							-
	Execute the program	as shown below.				20					1		 					1	ļ	<u> </u>					
Step	Key operation	Display	Step	Key operation	Display	21							 		. 	····		<u> </u>			<u>.</u>	ļ			+
1	F1(EXE)	A?	11			22			1	1					<u> </u>		ļ				1				+
						23																			<u> </u>
2	238 🖭	B?	12			24				-		ļ				į				<u> </u>			<u> </u>		+
3	374 EXE	34	13			25		<u> </u>		-			<u> </u>			<u> </u>		+						<u> </u>	÷
4	EXE	A?	14			26		<u> </u>			1												<u> </u>		+-
5	23345 EXE	B?	15			27	1		!	 	1	<u></u>			<u> </u>	<u>i</u>	<u></u>		.i	<u> </u>	<u> </u>		<u> </u>	<u> </u>	1
6	9135 🖭	1015	16				A			n_0		Н					0								
7		A?	17			Memory Contents	В		<i>b</i> ,	<i>n</i> ₁							P				N X				
	EXE					onte	C	1	r	1 _k		J									Y				
8	522952 EXE	B?	18			Ŭ Z	D					K					R				Z				
•	3208137866 EXE	998	19			Q	E					LI					S				_ <u></u>	:-			
9		the second second second second second second second second second second second second second second second se	11			-	F		1			M					т					(



Preparation and operation

180

Store the program written on the next page.
Execute the program as shown below.

55, 53, 53, 54, 52, is 53.

Perform a t-test with a level of significance of 5%.

Step	Key operation	Display	Step	Key operation	Display
1	F1(EXE)	M?	3		
2	53 EXE	T= 0.7533708035	4		

The above operation produces a *t*-test value of t(53) = 0.7533708035. According to the *t*-distribution table in the next page, a level of significance of 5% and a degree of freedom of 7 (n - 1 = 8 - 1 = 7) produce a two-sided *t*-test value of approximately 2.365. Since the calculated *t*-test value is lower than the table value, the hypothesis that population mean *m* equals 53 is accepted.

														, stat		3			
Line									Pr	ogra	am								
File name	T		Т	Е	s	Т	1												
1	{	5	5	; , [,]	5	4	, . , .	5	1.	; , .	5	5		5	3	· , ·	5	3	1 1 1 1
2	5	4	,	5	2	}	\rightarrow	List	. 1	L.									
3	I-Var	List	1		1	-	la se si la se si		-		1							1	
4	Lbl	0		11	М	"	?	\rightarrow	М	L.									
5	-(x.		M)	÷	(<i>x</i> σ _{n-1}	÷	$\sqrt{-}$	n		$ \rightarrow$	Т	4				1
6		T	=	. 11	:	Т				1			1						
7	Goto	0			1.1						1		1						1
			1			1													1
	Α		- de			Η	1.2			(D		ст.,		V				
nts	В					1		1997 - 1997 -			>				W				
onte	С			19 12		J					ב ב	<u>.</u>			X				
ŭ	D					K					R				Y				
Memory Contents	E					L					S				Z				
Men	F	1. 1. 1. 1. 1. 1. 1. 1. 1. 1. 1. 1. 1. 1				М		т		•	T		t						
	G	11	ta pi	8 . T.		Ν					ו						1.15	1. ¹ .	· · ·

No.


2

t-distribution table

The values in the top row of the table show the probability (two-sided probability) that the absolute value of t is greater than the table values for a given degree of freedom.



		-t	Ö i	t i
P (Probability) Degree of Freedom	0.2	0.1	0.05	0.01
1	3.078	6.314	12.706	63.657
2	1.886	2.920	4.303	9.925
3	1.638	2.353	3.182	5.841
4	1.533	2.132	2.776	4.604
5	1.476	2.015	2.571	4.032
6	1.440	1.943	2.447	3.707
7	1.415	1.895	2.365	3.499
8	1.397	1.860	2.306	3.355
9	1.383	1.833	2.262	3.250
10	1.372	1.812	2.228	3.169
15	1.341	1.753	2.131	2.947
20	1.325	1.725	2.086	2.845
25	1.316	1.708	2.060	2.787
30	1.310	1.697	2.042	2.750
35	1.306	1.690	2.030	2.724
40	1.303	1.684	2.021	2.704
45	1.301	1.679	2.014	2.690
50	1.299	1.676	2.009	2.678
60	1.296	1.671	2.000	2.660
80	1.292	1.664	1.990	2.639
120	1.289	1.658	1.980	2.617
240	1.285	1.651	1.970	2.596
∞	1.282	1.645	1.960	2.576



With this program, slope m and intercept b (= y' - mx') are obtained for lines drawn from point A (x', y') and are tangent to a circle with a radius of r. The trace function is used to read out the coordinates at the points of tangency, and factor zoom is used to enlarge the graph.

Example

To determine m and b for the following values:

r = 1

x'=3

y'=2

Notes

• The point plotted for A cannot be moved. Even if it is moved on the graph, the calculation is performed using the original value.

• An error (Ma ERROR) occurs when r = x'.

• Be sure to always perform a trace operation whenever you select trace and the message TRACE is on the display.

÷.,

Preparation and operation

• Store the program written on the next page.


• Execute the program as shown below.


	Α	 Н		0	V	
ents	В	1		Ρ	W	
Contents	С	J		Q	X	
	D	K	se di si se di digi se se	R	Y	
Memory	Е	L		S	Ζ	
Me	F	М		Т		
	G	Ν		U		


Line									Dro	gra	m								
										yıa	···· ·	<u></u>	<u> </u>	<u></u> ,	<u> </u>				·. ·.
File name	Т	A	N	G	E	N	T												
1	Prog	."	W		N	D	0	W		L			į						
2	n,	X	<i>x</i> ²	+	Y	<i>x</i> ²	=	R	x ²	-									
3	R	=	H	?	\rightarrow	R	الب												
4	Prog		C	1	R	C	L	E											
5		(X	,	Y).	4												
6	X	=		?	\rightarrow	Α	4												
7	H I	Y	=	."	?	\rightarrow	В	ل م											<u> </u>
8	Plot	Α	,	В															
9	R	x ²	(A	x ²	+	В	<i>x</i> ²	-	R	<i>x</i> ²)	\rightarrow		4				
10	(Ρ		Α	В)	· ()	R	<i>x</i> ²	-	A	<i>x</i> ²)	x-1	\rightarrow	М	-	
11	Lbl	6	4	1													- 1 		
12	Graph Y=	М	- (X	-	Α)	+	В	4			21						2
13	u	Μ	=			М													
14	18	В	=	a	:	В	-	М	A	4					-				
15	Lbl	0	الب																
16	II	Т	R	A	С	E	?	₽							r r				
17	Y	Е	S	⇒	1	₽													
18	N	0	\Rightarrow	0		:	?	\rightarrow	Ζ	4									
19	1	\rightarrow	S		Ζ	=	1	⇒	Goto	1	₽								
20	Z	=	0	⇒	Goto	2		Goto	0	4					ļ			<u> </u>	
21	Lbl	2	-		1								ļ.			ļ		<u> </u>	Ļ
22	(()	Α	В	-		Ρ).	(R	<i>x</i> ²	-	Α	<i>x</i> ²)	x-1	\rightarrow	N	-
23	Graph Y=	N	(Х		Α)	+	В				-		ļ				
24	8.	M	=		:	N													-
25	"	В	=		:	В	_	N	A	4			1						
26	Lbl	5	L.															<u>.</u>	
27	"	T	R	Α	C	E	?	4				ļ	1						}
28	Y	E	S	⇒	1	الب ا		1			1			<u> </u>				<u>.</u>	
29	N	0	⇒	0	H	:	?	\rightarrow	Z	L.				<u> </u>		1.			-
30	2	\rightarrow	S	.:	Z	=	1	⇒	Goto	1	لم ا	1.		1	<u> </u>				
31	Z	=	0	\Rightarrow	Got	3	:	Goto	5	L.		-	-		<u>.</u>		<u> </u>		-
32	Lb	1 1	-	1	1						-]	<u>.</u>					-
33	"	T	R	A	C	E	1 1		1					:					
34	н	Facto	<u></u>	 :	N	=		?	\rightarrow	F	:	Facto	F	L.					

No


													No.			4			
Line									P	rogr	am								
35	Prog	"	С	1.	R	С	L	E		:	S	=	1	⇒	Goto	9	-	-	
36	S	=	2	\Rightarrow	Graph Y=	Μ	(X	-	A)	+	B	-					
37	Graph Y=	N) (Х		Α)	+	В									-	
38	Goto	3	4		-								1.					.	
39	Lbl	9	لې ا									÷.,						-	
40	Graph Y=		(Х)	+	В	4								-	
41	Prog		W		Ν	D	0	W	, II	:	Prog	н	С	1	R	С	L	E	
42		Goto	6	4							8 8								
43	Lbl		.							1						1			
44	н,	E	N	D						1									
								1											
File name	W	1		D		W							1				· · ·		
1	View Window	()		· .	9	,	3		9	,	1	,	(-)	2	•	3	,	2	
2	3	,	1																
						1.1													
File name	С	1	R		L	E			1			• •			*				
1	Graph Y=		(R	<i>x</i> ²			<i>x</i> ²)	Ъ.									
2	Graph Y=	(-)		(R	<i>x</i> ²		Х	<i>x</i> ²)									
				-			-												- 24
	·					_								1 1 1 1					
												1							
					-										<u> </u>				1
																			:::
									а. 										
										-						<u></u>			<u> </u>
		i																	
											<u> </u>								
	·									. : · [·				








Progra	^{m for} Circle and Tangents	No. 4
Step	Key Operation	Display
16	EXE	NO⇒0 ? TRACE Factor N:N=?
17	4 🕮	
18	EE	TRACE Factor N:N=? 4 Done END





Formula for coordinate transfo tion: $(x, y) \rightarrow (x', y')$ $x' = x \cos \theta - y \sin \theta$ $y' = x \sin \theta + y \cos \theta$

Graphing of rotation of any geometric figure by θ degrees.

Example

To rotate by 30° the triangle defined by points A (2, 0.5), B (6, 0.5), and C (5, 1.5)

Notes


- Use the cursor keys to move the pointer around the display.
- To interrupt program execution, press AC while the graphic screen is on the display.
- The triangle cannot be drawn if the result of the coordinate transformation operation exceeds
 View Window parameters.


Preparation and operation

Store the program written on the next page.Execute the program as shown below.

	Α	<i>x</i> 1	Н	y'1	0		۷	
Ś	В	y 1	1	x'2	Ρ		W	
Contents	С	<i>x</i> 2	J	y'2	Q	θ	X	
- UC	D	У2	K	<i>x</i> ′3	R		Y	
ory	Ε	<i>x</i> 3	L	y'3	S		Ζ	
Memory	F	Уз	М		Т			
Z	G	<i>x</i> ′ ₁	N		U			

												N	lo.			5			
Line									Pre	ogra	m								
File name	R	0	Т	Α	Т	E								19				1999 1997	-
1	View Window	(-)	0	•	4	,	7	•	4	,	1	· ,	()	0		8	,	3	<u> </u> .
2	8	,	1	:	Deg	-								8 ¹					
3		(X	1	· , ,	Y	1)	÷.										<u> </u>
4	X	1	=	U,	?	\rightarrow	Α	4											<u>.</u>
5		Y	1	=	11	?	\rightarrow	B	÷1										
6	Plot	Α	,	В								1.11		1					<u> </u>
7	X	\rightarrow	Α	:	Y	\rightarrow	В	H			н. <u>ј</u>			1.1					-
8	H	(X	2	,	Y	2)	L										1
9	X	2	=		?	\rightarrow	С	₽											
10	. 11	Y	2	=	11	?	\rightarrow	D	لب										-
11	Plot	С	,	D			-												
12	X	\rightarrow	С	:	Y	\rightarrow	D	┢											
13		- (X	3	,	Y	3)	₽										
14	X	3	=	u.	?	\rightarrow	Е	. 4											_
15		Υ	3	=		?	\rightarrow	F	لب						*				<u> .</u>
16	Plot	Е	,	F			1												<u> </u>
17	X	\rightarrow	Е	:	Y	\rightarrow	F	┢			1.1			·		а	<u></u>		1
18	Lbl	1	لب	•	1 L 1		- 				19			-				1	
19	Line	:	Plot	Α	,	В	:	Line		Plot	С	,	D	:	Line	4			1
20		Α	Ν	G	L	Е	:	Deg	. 11	?	\rightarrow	Q	.						-
21	Α	cos	Q	-	В	sin	Q	\rightarrow	G	┢							 		
22	A	sin	Q	+	В	cos	Q	$ \rightarrow $	Н								t t t		
23	Plot	G	,	Η	L.				, je						1				1
24	C	cos	Q	-	D	sin	Q	\rightarrow	I	┢								-	-
25	С	sin	Q	+	D	cos	Q	\rightarrow	J	┢					1			<u> </u>	<u> </u>
26	Plot	1	,	J	:	Line	· • •					ļ		1.0	<u> </u>			-	+
27	E	cos	Q	-	F	sin	Q	\rightarrow	κ	┢					ļ			ļ	-
28	Ε	sin	Q	+	F	cos	Q	\rightarrow	L	لب							1		-
29	Plot	κ	,	L	:	Line	لہ										<u> </u>	<u> .</u>	1.
30	Plot	G	,	н	:	Line	4					i . 	1					<u> </u>	1
31	Cls	:	Plot	С	:,	D	:	Plot	Ε	1,	F		Goto	1	1		1		1
32																			
33			1				1. 									-	<u> </u>		-
34																	1		





Appendix

Appendix AResetting the CalculatorAppendix BPower SupplyAppendix CError Message TableAppendix DInput RangesAppendix ESpecifications

Continue, repeating from step 8.

10 C

Appendix A Resetting the Calculator

Warning!

The procedure described here clears all memory contents. Never perform this operation unless you want to totally clear the memory of the calculator. If you need the data currently stored in memory, be sure to write it down somewhere before performing the RESET operation.

•To reset the calculator

1. Press MENU to display the main menu.

GRAPH	

2. Highlight the MEM icon and press EE, or press 9.

Memory Nemory Reset	Usase
Select: Set	

3. Use (to move the highlighting down to "Reset" and then press EE.

ALL	RESET MEMORIES?
***	*****
CF1 YES] [F4] RESET ALL NO
F1	F4

4. Press F1 (YES) to reset the calculator or F4 (NO) to abort the operation without resetting anything.

akakakakakakakakakakak
MEM CLEARED!
************* PRESS[MENU]


. If the display appears to dark or dim after you reset the calculator, adjust contrast.

Resetting the calculator initializes it to the following settings.

item	Initial Setting		
lcon	RUN		
Angle Unit	Rad		
Exponent Display Range	Norm 1		
Fraction Reduction	Automatic		
Mixed Fraction	Display		
Graph Type	Rectangular coordinate (Y=)		
Statistical Graph	Automatic		
Variable Memory	Clear		
Answer Memory (Ans)	Clear		
Graphic Display/Text Display	Clear		
View Window	Clear (initialized)		
View Window Memory	Clear		
Graph Function	Clear		
Enlargement/Reduction Factor	Clear (initialized)		
Table & Graph Data	Clear		
List Data	Clear		
Statistical Calculation/Graph Memory	Clear		
Program	Clear		
Input Buffer/AC Replay	Clear		



• Performing the RESET operation while an internal calculation is being performed will cause all data in memory to be deleted. Make sure that no calculation be being performed before starting a RESET operation.



 If the calculator stops operating correctly for some reason, use a thin, pointed object to press the P button on the back of the calculator. This should make the RESET confirmation screen appear on the display. Perform the procedure to complete the RESET operation.

Appendix B Power Supply

This unit is powered by two AAA-size (LR03 (AM4) or R03 (UM-4)) batteries. In addition, it uses a single CR2032 lithium battery as a back up power supply for the memory.

If the following message appears on the display, immediately stop using the calculator and replace batteries.

	Low battery!
1.1.1	

If you try to continue using the calculator, it will automatically switch power off, in order to protect memory contents. You will not be able to switch power back on until you replace batteries.

Be sure to replace the main batteries at least once every two years, no matter how much you use the calculator during that time.



Warning!

If you remove both the main power supply and the memory back up batteries at the same time, all memory contents will be erased. If you do remove both batteries, correctly reload them and then perform the reset operation.

The batteries that come with this unit discharge slightly during shipment and storage. Because of this, they may require replacement sooner than the normal expected battery life.


Replacing Batteries

Precautions:

Incorrectly using batteries can cause them to burst or leak, possibly damaging the interior of the unit. Note the following precautions:

- Be sure that the positive (+) and negative (-) poles of each battery are facing in the proper directions.
- · Never mix batteries of different types.
- Never mix old batteries and new ones.
- Never leave dead batteries in the battery compartment.
- Remove the batteries if you do not plan to use the unit for long periods.
- Never try to recharge the batteries supplied with the unit.
- Do not expose batteries to direct heat, let them become shorted, or try to take them apart.






(Should a battery leak, clean out the battery compartment of the unit immediately, taking care to avoid letting the battery fluid come into direct contact with your skin.)

Keep batteries out of the reach of small children. If swallowed, consult with a physician immediately.

To replace the main power supply batteries

- * Never remove the main power supply and the memory back up batteries from the unit at the same time.
- Be sure to switch the unit off before replacing batteries. Replacing batteries with power on will cause data in memory to be deleted.
- * Never replace the back cover or switch the calculator on while the main power supply batteries are removed from the calculator or not loaded correctly. Doing so can cause memory data to be deleted and malfunction of the calculator. If mishandling of batteries causes such problems, correctly load batteries and then perform the RESET operation to resume normal operation.
- * Be sure to replace all two batteries with new ones.
- 1. Press SHIFT OFF to turn the calculator off.
- Making sure that you do not accidently press the Keen key, slide the case onto the calculator and then turn the calculator over.




- Remove the back cover from the unit by pulling with your finger at the point marked ☆.
- 3. Remove the two old batteries.

(75)

P.11

- Load a new set of two batteries, making sure that their positive (+) and negative (-) ends are facing in the proper directions.
- Replace the back cover and press ICM to turn power on. The memory back-up battery provides power to the memory while the main batteries are removed, so memory data is not lost.



- Power will not switch on if you press KR while the back cover is open.
- Do not leave the unit without main power supply batteries loaded for long periods.
 Doing so can cause deletion of data stored in memory.
- If the figures on the display appear too light and hard to see after you turn on power, adjust the contrast.

(Tr)D

To replace the memory back up battery

- Before replacing the memory back up battery, switch on the unit and check to see if the "Low battery!" message appears on the display. If it does, replace the main power supply batteries before replacing the back up power supply battery.
- * Never remove the main power supply and the memory back up batteries from the unit at the same time.
- * Be sure to switch the unit off before replacing battery. Replacing battery with power on will cause data in memory to be deleted.
- * Be sure to replace the back up power supply battery at least once 2 years, regardless of how much you use the unit during that time. Failure to do so can cause data in memory to be deleted.
- 1. Press SHFT OFF to turn the calculator off.
- Making sure that you do not accidently press the ICM key, slide the case onto the calculator and then turn the calculator over.
- Remove the back cover from the unit by pulling with your finger at the point marked ☆.
- 3. Remove screw (a) on the back of the calculator, and remove the back up battery holder.
- 4. Remove the old battery.
- 5. Wipe off the surfaces of a new battery with a soft, dry cloth. Load it into the calculator so that its positive (+) side is facing up.
- 6. Pressing down on the battery with the battery holder, replace the screw that secures the holder in place.
- 7. Replace the back cover and press *ICP* to turn power on. The main batteries provide power to the memory while the back-up battery is removed, so memory data is not lost.


About the Auto Power Off Function


The calculator switches power off automatically if you do not perform any key operation for about 6 minutes. To restore power, press [67].

The calculator automatically turns off it is left for about 60 minutes with a calculation stopped by an output command (\checkmark), which is indicated by the "–Disp–" message on the display.

Appendix C Error Message Table

Message	Meaning	Countermeasure
Syn ERROR	 Calculation formula contains an error. Formula in a program contains an error. 	 Use or to display the point where the error was generated and correct it. Use or to display the point where the error was generated and then correct the program.
Ma ERROR	 Calculation result exceeds calculation range. Calculation is outside the input range of a function. Illogical operation (division by zero, etc.) Poor precision in differential calculation results. 	123 Check the input numeric value and correct it. When using memories, check that the numeric values stored in memories are correct. Try using a smaller value for Δx (x increment/decrement).
Go ERROR	 No corresponding Lbl n for Goto n. No program stored in program area Prog "file name". 	 Correctly input a Lbl n to correspond to the Goto n, or delete the Goto n if not required. Store a program in program area Prog "file name", or delete the Prog "file name" if not required.
	③ No corresponding "Next" for "For", no corresponding "LpWhile" for "Do", or no corresponding "WhileEnd" for "While".	Correctly match "Next" with "For", "LpWhile" with "Do", or "WhileEnd" with "While".
Ne ERROR	Nesting of subroutines exceeds 10 levels.	 Ensure that Prog "file name" is not used to return from subroutines to main routine. If used, delete any unnecessary Prog "file name". Trace the subroutine jump destinations and ensure that no jumps are made back to the original program area. Ensure that returns are made correctly.





Appendix

1

Message	Meaning	Countermeasure
Stk ERROR	Execution of calculations that exceed the capacity of the stack for numeric values or stack for commands.	 Simplify the formulas to keep stacks within 10 levels for the numeric values and 26 levels for the commands. Divide the formula into two or more parts.
Mem ERROR	 Not enough memory to hold function input in the Graph Mode for graph drawing. Not enough memory to hold function input in the TABLE Mode. Not enough memory to store data in list function. 	 ①②③ Keep the number of variables you use for the operation within the number of variables currently available. Simplify the data you are trying to store to keep it within the available memory capacity. Delete no longer needed data to make room for the new data.
Arg ERROR	 Incorrect argument specification for a command that requires an argument. 	 Correct the argument. Fix n, Sci n : n = integer from 0 through 9. Lbl n, Goto n : n = integer from 0 through 9.
Dim ERROR	Illegal dimension used during list calculations.	Check list dimension.
Com ERROR	Problem with cable connection or parameter setting during program data communications.	Check cable connection.
Transmit ERROR!	Problem with cable connection or parameter setting during data communications.	Check cable connection.
Receive ERROR!	Problem with cable connection or parameter setting during data communications.	Check cable connection.
Memory Full!	Memory of receiving unit became full during program data communications.	Delete some data stored in the receiving unit and try again.

Appendix D Input Ranges

Function	Input ranges	Internal digits	Precision	Notes
sin <i>x</i> cos <i>x</i> tan <i>x</i>	(DEG) $ x < 9 \times 10^{9\circ}$ (RAD) $ x < 5 \times 10^{7}\pi rad$ (GRA) $ x < 1 \times 10^{10} grad$	15 digits	As a rule, precision is ±1 at the 10th digit.	However, for tan x: $ x \neq 90(2n+1)$:DEG $ x \neq \pi/2(2n+1)$:RAD $ x \neq 100(2n+1)$:GRA
sin⁻¹x cos⁻¹x	$ x \leq 1$			
tan ⁻¹ x	$ x < 1 \times 10^{100}$			
log <i>x</i> Inx	$1 \times 10^{-99} \le x < 1 \times 10^{100}$	n an an an an an an an an an an an an an	n	
10 ^x	$-1 \times 10^{100} < x < 100$			
er	-1×10^{100} < $x \le 230.2585092$			
\sqrt{x}	$0 \leq x < 1 \times 10^{100}$			
<i>X</i> ²	<i>x</i> <1 × 10 ⁵⁰			
1/x	$ x < 1 \times 10^{100}, x \neq 0$			
$^{3}\sqrt{x}$	$ x < 1 \times 10^{100}$			
x!	$0 \le x \le 69$ (x is an integer)	U		
nPr nCr	Result < 1×10^{100} n, r (n and r are integers) $0 \le r \le n,$ $n < 1 \times 10^{10}$	B		
Pol (x, y)	$\sqrt{x^2 + y^2} < 1 \times 10^{100}$			
Rec (<i>r</i> , θ)	$\begin{aligned} r < 1 \times 10^{100} \\ (\text{DEG}) \theta < 9 \times 10^{9^{\circ}} \\ (\text{RAD}) \theta < 5 \times 10^{7}\pi \text{ rad} \\ (\text{GRA}) \theta < 1 \times 10^{10} \text{grad} \end{aligned}$			However, for tan θ : $ \theta \neq 90(2n+1)$:DEG $ \theta \neq \pi/2(2n+1)$:RAD $ \theta \neq 100(2n+1)$:GRA

Appendix

Function	Input ranges	Internal digits	Precision	Notes
0,,,,	$ a , b, c < 1 \times 10^{100}$ $0 \le b, c$		As a rule, precision is	
<u></u>	l <i>x</i> l < 1 × 10 ¹⁰⁰ Sexagesimal display: l <i>x</i> l < 1 × 10 ⁷	15 digits	±1 at the 10th digit.	
^(x ^y)	x > 0: $-1 \times 10^{100} < y \log x < 100$ x = 0 : y > 0 x < 0 : 1			
	$y = n, \frac{1}{2n+1} (n \text{ is an integer})$ However; $-1 \times 10^{100} < \frac{1}{y} \log x < 100$			
*√Ӯ	$\begin{array}{l} y > 0: x \neq 0 \\ -1 \times 10^{100} < \frac{1}{x} \log y < 100 \\ y = 0: x > 0 \\ y < 0: x = 2n + 1, \frac{1}{n} \\ (n \neq 0, n \text{ is an integer}) \\ \text{However;} \\ -1 \times 10^{100} < \frac{1}{x} \log y < 100 \end{array}$			
a ^b /c	Total of integer, numerator and denominator must be within 10 digits (includes di- vision marks).	•		
STAT	$\begin{aligned} x < 1 \times 10^{50} \\ y < 1 \times 10^{50} \\ n < 1 \times 10^{100} \\ x\sigma_n, y\sigma_n, \overline{x}, \overline{y}, a, b, c, r : \\ n \neq 0 \\ x\sigma_{n-1}, y\sigma_{n-1}; n \neq 0, 1 \end{aligned}$			

* Errors may be cumulative with internal continuous calculations such as (x^y) , $\sqrt[x]{y}$, x/, $\sqrt[3]{x}$, sometimes affecting precision.

Appendix

Appendix E Specifications

Variables: 26

Calculation range:

 $\pm1\times10^{-99}$ to $\pm9.9999999999\times10^{99}$ and 0. Internal operations use 15-digit mantissa.

 Exponential display range:
 Norm 1:
 $10^{-2} > |x|, |x| \ge 10^{10}$

 Norm 2:
 $10^{-9} > |x|, |x| \ge 10^{10}$

Program capacity: 20,000 bytes (max.)

Power supply: Main: Two AAA-size batteries (LR03 (AM4) or R03 (UM-4)) Back-up: One CR2032 lithium battery

Power consumption: 0.05W

Battery life

Main:

LR03 (AM4): Approximately 1,500 hours (continuous display of main menu) Approximately 700 hours (continuous operation)

R03 (UM-4): Approximately 900 hours (continuous display of main menu) Approximately 400 hours (continuous operation)

Back-up: Approximately 2 years (when main batteries are not supplying power)

Auto power off:

Power is automatically turned off approximately six minutes after last operation. The calculator automatically turns off if it is left for about 60 minutes with a calculation stopped by an output command (\checkmark), which is indicated by the "–Disp–" message on the display.

Ambient temperature range: 0°C to 40°C

Dimensions: 19.3 mm (H) × 81.5 mm (W) × 163 mm (D) ${}^{3}/{}^{4"}$ (H) × 3" (W) × 6 ${}^{1}/{}^{4"}$ (D)

Weight: 160g (including batteries)

A CONTRACTOR OF THE REAL

*E

ti

Program Mode Command List


Data Communications


Functions:

Program contents and file names; function memory data; list data; variable data; Table & Graph data; graph functions

Method: Start-stop (asynchronous), half-duplex

Transmission speed (BPS): 9600 bits/second Parity: none Bit length: 8 bits Stop bit: Send: 2 bits Receive: 1 bit





This file has been downloaded from:

www.UsersManualGuide.com

User Manual and User Guide for many equipments like mobile phones, photo cameras, monther board, monitors, software, tv, dvd, and othes...

Manual users, user manuals, user guide manual, owners manual, instruction manual, manual owner, manual owner's, manual guide, manual operation, operating manual, user's manual, operating instructions, manual operators, manual operator, manual product, documentation manual, user maintenance, brochure, user reference, pdf manual