


SHARP SERVICE MANUAL

CODE: 00ZPC1280SM/E



POCKET COMPUTER MODEL PC-1280



Top View of PC-1280

Bottom View of PC-1280

1. INTRODUCTION

PC-1280 was designed to close with a tight fit to protect its LCD screen and keyboard, and has the facility for double-precision calculations.

2. Specifications

Model:

PC-1280 Pocket Computer

Processor:

8-bit CMOS CPU

Programming Language:

BASIC

System ROM:

136K Bytes

Memory Capacity:

System internal	1.6K Bytes Approx.
Data area	208 Bytes
Program/Data Area	6558 Bytes
Reserve Area	144 Bytes

(Memory expandable to 40KB using RAM cards)

Stack:

Sub-routine: 10 stacks
 Function: 16 stacks
 FOR-NEXT: 5 stacks
 Data: 8 stacks

Operators:

Addition, subtraction, multiplication, division, trigonometric, and inverse trigonometric functions, logarithmic and exponential functions, angle conversion, square and square root, sign, absolute, integer, relational operators, logical operators etc.

Numeric Precision:

10 digits (single-precision mode) / 20 digits (double-precision mode) (mantissa) + 2 digits (exponent).

Editing Features:

Cursor left and right, line up and down, character insert, character delete.

Memory Protection:

CMOS Battery backup.

Interface Capability:

11 pin (For cassette interface, disk, printer, etc.)

Ram Card Slot:

Cards of 2KB, 4KB, 8KB, 16KB, or 32KB.

Display:

2-line 24-digit liquid crystal display with 5×7 dot characters.

Keys:

72 keys. Alphabetic, numeric, special symbols, and functions. Numeric pad. User defined keys.

Power Supply:

6.0V DC: Lithium cells.
type: CR-2032×2

Backup Battery:

Built-in memory backup cell.
type: CR-2032

Power Consumption:

6.0V DC @ 0.03W

Approximately 120 hours of continuous operation under normal conditions (based on 10 minutes of operation or program execution and 50 minutes of display per hour at a temperature of 20°C). The time may vary slightly depending on usage and the type of battery used.

Operating Temperature:

0°~40°C (32°~140°F)

Dimensions:

135(W)×70.5(D)×19.2(H)mm (closed)
5.31(W)×2.76(D)×0.76(H) inches
135(W)×141(D)×9.6(H) mm (open)
5.31(W)×5.55(D)×0.38(H) inches

Weight:


Approximately 180g (0.4 lbs.) (with cells)

Accessories:

Lithium cells (built in) and operation manual.

Options:

Plug-in RAM cards 2KB (CE-210M), 4KB (CE-211M), 8KB (CE-212M), 16KB (CE-2H16M), 32KB (CE-2H32M)
Cassette Tape Recorder (CE-152)
Printer/Cassette Interface (CE-126P)
Pocket Disk Drive (CE-140F)



3. Operating Battery Life and Consumption Power

PC-1280 battery	Lithium battery: CR-2032×2pcs	Capacity: 170mAH	Terminal voltage: 6.0V
-----------------	----------------------------------	---------------------	---------------------------

Consumption current


PC-1280 When OFF:	45μA, max.
PC-1280 When ON:	400μA, max.

The above is at the room temperature of 20°C and may vary depending on conditions.

4. Battery Replacement

Replacing the operating cells


1. Turn the power OFF.
2. Close the computer and turn it over. Follow the diagrams on the slot cover to remove the cover.
3. Remove the RAM card if present.
4. Slide the Memory Protect Switch to position B.
THIS IS IMPORTANT and must be done before removing the operating cells or data and programs in memory will be lost.



Replacing Operating Cells

5. Press the tab (1) and slide open the cell-compartment cover (2). Remove the two lithium cells (3).
6. Replace the two cells, taking care that they are inserted with the correct polarity, as shown in the diagram.
7. Replace the cell compartment cover (4).
8. Press the ALL RESET button.
THIS IS IMPORTANT AND MUST BE DONE TO PRESERVE PROGRAMS AND DATA.
9. Replace the slot cover and slide the switch to the Lock position.


10. Open the computer, switch on the power and look at the display. If it looks like the following with an * displayed, Press the ALL RESET button.



11. Turn OFF the power, remove the slot cover, and slide the Memory Protect Switch to position A.
12. Replace the RAM card, if used.
13. Replace the slot cover and slide the switch back to the LOCK position.

Replacing memory backup cell

The memory backup cell in your PC-1280 has an effective life of about five years under normal operating conditions. Note that temperature extremes can shorten cell life and cause memory losses. When the memory backup cell was installed at the factory, a label was attached above the memory protect switch, showing the date of installation and a control code.




Replacing Memory Backup Cell

DO NOT REPLACE THE MEMORY BACKUP CELL WHEN OPERATING CELLS ARE REMOVED OR WEAK (BATT DISPLAYED WITH POWER ON): MEMORY CONTENTS WILL BE LOST.

1. Turn OFF the power, close the computer and turn it over.
2. Remove the slot cover and RAM card if present.
3. Slide the Memory Protect Switch to position B.
4. Release the screw (1) retaining the cover of the Backup Cell compartment and remove the cover (2).
5. Replace the cell (3), making sure that the new cell is inserted with the correct polarity (positive pole down).
6. Slide the Memory Protect Switch back to position A.
7. Replace the slot cover.

5. Memory Map



6. Low Battery Detect Circuit


Discussed next is about the low battery detect circuit which is incorporated in the PC-1280.

As shown in the figure BELOW, when the input voltage VIN goes above the detect voltage level VD, its output turns to high level. On the contrary, when VIN goes below VD, the output turns to low level. Two levels of caution and stop are detected by a single IC (LB iC = MN1280).


The input voltage added to the input pin (No.2) is divided by R1 and R2, and R2 is turned on/off by the CAU signal of G.A. As shown in Fig.3, when the supply voltage drops below the caution level, the BATT symbol comes to activate. When it further drops down below the stop level, the symbol goes out.

To sense the caution level, the CAU line of the G.A. is set active (low) and the state on LB of the G.A. is checked. If LB is at a low, the symbol activates. When the caution label is sensed, the CAU line is set off (high impedance). With this, the voltage increases on the LB iC pin 2 because there is no more voltage division by resistors, so that the output changes from low to high level. As the LB line of the G.A. is sensed again, the stop level is detected.

During standby, F01 of the CPU and CAU of the G.A. are set at high impedance and Di1 is inserted to correct the battery drop during standby and operation. The ON/BRK and RESET switch became inoperative after the stop level has been detected.



[Fig. 1]



[Fig. 2]

[Fig. 3]

Memory mapping according to RAM card combination.

2 K	4 K	8 K	16 K	32 K
<p>D800 E000</p> <p>SLOT 1</p> <p>Internal RAM</p> <p>FFFF</p>	<p>D000</p> <p>SLOT 1</p> <p>Internal RAM</p> <p>FFFF</p>	<p>C000</p> <p>SLOT 1</p> <p>Internal RAM</p> <p>FFFF</p>	<p>A000</p> <p>SLOT 1</p> <p>Internal RAM</p> <p>FFFF</p>	<p>8000</p> <p>Internal RAM</p> <p>9FFF</p> <p>SLOT 1</p> <p>FFFF</p>
D800~FFFF 10K	D000~FFFF 12K	C000~FFFF 16K	A000~FFFF 24K	8000~FFFF 40K 8000~9FFF 40K


7. LSI Description

7-1. CPU (SC61860A38) signal description

Pin No	Signal name	In/Out	Description (Standby = power off)
1	AO1	Out	Address bus A0, high during standby
2	R/W	Out	Write clock, normally high
3	øAL	Out	Address latch. Clock used to latch the address of the LCD driver.
4	TES	In	Test pin, normally low.
5	ø1	In	Oscillator input
6	ø0	Out	Oscillator output
7	RES	In	Reset input, reset with a high state of signal.
8	XIN	In	Cassette signal input
9	XON	In	ON/BRK key input, normally pulled down to low level.
10	XOUT	Out	Cassette signal and buzzer signal output
11	DIS	Out	LCD driver control signal, high during displaying.
12	HA	Out	LCD driver sync clock
13	IA8	In/Out	Key input/key strobe
14	IA7	In/Out	Key input/key strobe
15	IA6	In/Out	Key input/key strobe
16	IA5	In/Out	Key input/key strobe
17	IA4	In/Out	Key input/key strobe
18	IA3	In/Out	Key input/key strobe
19	IA2	In/Out	Key input/key strobe
20	IA1	In/Out	Key input/key strobe, low during standby.
21	IB8	-	Not used.
22	IB7	-	Not used.
23	IB6	-	Not used.
24	IB5	In	11-pin ACK (acknowledge on 11-pin interface)
25	IB4	In	11-pin DIN (data input on 11-pin interface)
26	IB3	In	11-pin DOUT (data output on 11-pin interface)
27	IB2	In	11-pin IO2 (data input on 11-pin interface)
28	IB1	In	11-pin IO1 (data input on 11-pin interface)
29	VM	In	LCD drive power
30	VA	In	LCD drive power
31	GND	In	(+) supply
32	H1	Out	LCD backplate signal, 4-level pulse during displaying (1/14 duty)
33	H2	Out	LCD backplate signal, 4-level pulse during displaying (1/14 duty)
34	H3	Out	LCD backplate signal, 4-level pulse during displaying (1/14 duty)
35	H4	Out	LCD backplate signal, 4-level pulse during displaying (1/14 duty)
36-47	H15-H16	-	Not used (because of 1/14 duty)
48	VB	In	LCD drive power, high during standby
49	VDIS	In	LCD drive power, high during standby
50	VCC	In	LCD drive power, high during standby
51	VDC	Out	LCD drive power, high during standby
52	VGG	In	(-) supply
53	O8	In/Out	Data bus, D7, normally high impedance
54	O7	In/Out	Data bus, D7, normally high impedance
55	O6	In/Out	Data bus, D7, normally high impedance
56	O5	In/Out	Data bus, D7, normally high impedance
57	O4	In/Out	Data bus, D7, normally high impedance
58	O3	In/Out	Data bus, D7, normally high impedance
59	O2	In/Out	Data bus, D7, normally high impedance
60	O1	In/Out	Data bus, D0, normally high impedance
61	FO5	Out	Gate array chip enable (CE)
62	FO4	Out	ROM chip enable
63	FO3	Out	RAM card bank select ($\bar{B}A$)
64	FO2	-	Not used.
65	FO1	Out	Low battery detect, high impedance during standby.
66	BO8	Out	Address bus A15, high during standby.
67	BO7	Out	Address bus A15, high during standby.
68	BO6	Out	Address bus A15, high during standby.
69	BO5	Out	Address bus A15, high during standby.
70	BO4	Out	Address bus A15, high during standby.
71	BO3	Out	Address bus A15, high during standby.
72	BO2	Out	Address bus A15, high during standby.
73	BO1	Out	Address bus A15, high during standby.
74	AO8	Out	Address bus A1, high during standby.
75	AO7	Out	Address bus A1, high during standby.
76	AO6	Out	Address bus A1, high during standby.
77	AO5	Out	Address bus A1, high during standby.
78	AO4	Out	Address bus A1, high during standby.
79	AO3	Out	Address bus A1, high during standby.
80	AO2	Out	Address bus A1, high during standby.

7-2. Gate array (LZ92K38) signal description

Pin No	Signal name	In/Out	Description
1	\overline{BA}	In	Bank select
2	CE	In	Chip enable
3	DO0	In	Data bus
4	}	}	}
6	DO3	In	Data bus
7	GND	In	(-) supply
8	PO1	Out	11-pin IO1 (P-channel open output)
9	PO2	Out	11-pin IO2 (P-channel open output)
10	PO3	Out	11-pin DOUT (P-channel open output)
11	PO4	Out	11-pin DIN (P-channel open output)
12	PO5	Out	11-pin BUSY (P-channel open output)
13	NC	-	Not used.
14	SLTB	Out	Not used.
15	AS3B	Out	Not used.
16	AS1	Out	System ROM 14 and RAM A11
17	AS2	Out	System ROM 15 and RAM A12
18	AS3	Out	System ROM 16 and RAM A13
19	AF15	Out	RAM card slot A15
20	AF16	Out	RAM card A16
21	SLT1	Out	RAM card slot chip enable
22	SLT2	Out	Internal RAM chip enable
23	DSP1	Out	DISPCHIP1 chip enable
24	DSP2	Out	DISPCHIP2 chip enable
25	RESO	Out	Reset output to CPU RESET line, normally low.
26	KON	Out	ON/BRK output to CPU KON line, normally low.
27	LB	In	Low battery detect, low at battery low.
28	RESI	In	Reset input, normally pulled down.
29	BRK	In	ON/BRK key input, normally pulled down.
30	VDD	In	(+) supply
31	GND	In	(-) supply
32	\overline{CAU}	Out	Low battery symbol activating voltage detect line, high impedance after the activation of the symbol.
33	KS1	Out	Key strobe (P-channel open output)
34	}	}	}
40	KS8	Out	Key strobe (P-channel open output)
41	R/W	In	Write clock
42	A9	In	Address bus
43	}	}	}
48	A15	In	Address bus



Mount the memory PWB unit in Fig. 2 and insert only the FPC terminal onto the CAB-B guide pin.

NOTE: Do not insert the memory PWB onto the CAB-D guide pin.

Insert the mask sheet and fixing rubber (Fig. 3) and fold back a part of the FPC and insert it onto the CAB-B guide pin.

Match the angle to the CAB-B guide pin and fasten it with four screws.

NOTE: Tighten two screws in the center first, then two more adjacent to it.



8-5. Replacement of the static tape

The static tape must be replaced with a new one once after has it been used for a long time. The replacement procedure is as follows:

- Engage the latch B shown in Fig. 2.
- Engage the latch C shown in Fig. 2 in a manner as shown with in Fig. 1.

8-6. Ground continuity check

Make sure that the resistance between the RAM card and the panel is not more than 5Ω.

8-7. Internal RAM capacity and power off functional checks

The contents of the memory will be cleared when the following is conducted.

- Depress the ALL-RESET switch.
- The following will be displayed:


```
MEM - 2-MEM
MEMORY ALL CLEAR OK?
```
- As shown in the figure, insert your nail in the position between CAB-A and CAB-B and push the narrow pin into the display area (Fig. 2) at two locations. CAB-C must be engaged.
- Push the [ON] key to bring the display message in ③ above.

8. Service Precautions


Each cabinet is called as follows:

Display side bottom cabinet: CAB-A

Display side top cabinet: CAB-B


keyboard side bottom cabinet: CAB-C

Keyboard side top cabinet: CAB-D




8-1. Removal and installation of CAB-A

Procedure to mate CAB-A to CAB-B.




(Fig.1)



(Fig.2)

1. Engage the latch A shown in Fig.2 in a manner as shown with ① in Fig.1.
2. Engage the latch B shown in Fig.2.
3. Engage the latch C shown in Fig.2 in a manner as shown with ② in Fig.1.

Procedure to remove CAB-A




1. As shown in the figure, insert your nail in a clearance between CAB-A and CAB-C and push it in the arrow direction to disengage the latch C (Fig.2) at two locations. CAB-C must be disengaged first to achieve easier removal.

2. Do the reverse sequence of the above to assemble.

NOTE: When removing CAB-A, be careful not to separate the static tape.

8-2. Installation of CAB-C


- * Make sure that the pin is properly engaged into the hole.
- * When mating CAB-C to CAB-D, push CAB-C all the way in the arrowhead A to achieve firm engagement. Tighten the screw with the unit placed on the special table.



*The pin must be properly and firmly engaged into the hole.

8-3. Installation of the contact to the LOCK switch knob



- * Two contacts may be attached to the knob, but it has to be installed on the location shown in the figure. After installing the contact, it has to be caulked to fix it secure.



8-4. Installation of PWB, keysheet, etc.



- ① Assemble the blind sheet and the main PWB unit onto CAB-B.
- ② Insert rubber keys in CAB-D, then insert upper half of the key sheet. Match the guide pins and key sheet holding pins in their positions.
- ③ Match the key spacer with the guide pin and insert.
- ④ Fold back the lower half of the key sheet and insert only the terminal onto the guide pin.

NOTE: Leave the lower side key sheet uninserted onto CAB-D guide pin and holding pin and the folded area loose (Fig.1).





- ⑤ Mount the memory PWB unit in Fig.2 and insert only the FPC terminal onto the CAB-B guide pin.
- ⑥ Insert the mask sheet and fixing rubber (Fig.3) and fold back a part of the FPC and insert it onto the CAB-B guide pin.
- ⑦ Match the angle to the CAB-B guide pin and fasten it with four screws.

NOTE: Tighten two screws in the center first, then two more adjacent to it.



- ⑧ Bring the display side bottom cabinet (CAB-A). Solder the buzzer leads first (Fig.4) and fasten the terminal lug of the static tape using two tapping screw.
- ⑨ Mate CAB-A with CAB-B.
- ⑩ Close the unit halfway and mount the lower half of the key sheet and the memory PWB on CAB-D.
- ⑪ Mate CAB-C.



8-5. Replacement of the static tape

The static tape must be replaced with a new one once after it has been removed from the aluminum panel. Wipe away residual glue after bonding. Check ground continuity after the installation, in reference to 8-6.

8-6. Ground continuity check

Make sure that the resistance between the display side cosmetic panel and the RAM card lid is not more than 5Ω.


8-7. Internal RAM capacity and auto-power off functional checks

The contents of the memory will be erased after the following is conducted.


- ① Depress the ALL RESET switch.
The following will be displayed.
MEM\$="2"
MEMORY ALL CLEAR OK?
- ② Push the [Y] key.
- ③ Type [M] and [ENTER]. "6558" will come displayed.
- ④ Leave it in the above state for more than 14 minutes, then make sure that power has been turned off.
- ⑤ Push the [ON] key to bring the display message in ③ above.

8-8. Precautions


- All components must be closely attached to the PWB and soldered.
- When the LSI is replaced, use KR19RAM to solder with (see Service Information PS-009).
- The 0.1 μ F ceramic capacitor (RC-KZ1054CCZZ) inserted across the KON pin of GA (pin 26) and the VGG side of the 0.033 μ F must be handled in the following manner:




- The capacitor must be inserted to the 11-pin connector in the following manner:



- The resistor (100k Ω) must be inserted in the following manner:




- The diode must be inserted in the following manner:



- See the table below for the size of jumper wire.

	Size
J1	140
J2	40
J3	105

- The capacitor (RC-K1E104HCZZ) \times 2 pieces must be inserted in the following manner:



8-9. Display side cabinet and keyboard side cabinet

The above two cabinets are mated together with the spring pin in use. To replace one of the cabinets, it is possible to remove the spring pin by scraping off the cabinet body using such as wire cutter, but the spring pin once removed may not be used again.

9. Check-Out with the Test Program

A test program is contained in the ROM.

• Check item

- (1) RAM card read after write test
- (2) 11-pin connector I/O line tests
- (3) 15-pin connector I/O line tests

NOTE: The above item (3) is not used by the PC-1280.

• Tools required

The PC-1360 special tool UKOGC3020CSZZ (price rank: BC) is used for (2) and (3).

• Description

The RAM contents must be saved on such as tape before conducting the above test item (1), because the program and data are destroyed during the test.

Power OFF

Turn power on with the following four keys depressed at the same time.

PC-1280.....**[Y]****[X]****[T]****[B]**

PC-1475.....**[Y]****[X]****[T]****[B]**

<MENU>

1:RAM 2:11PIN 3:15PIN

Type **[1]**

(1) RAM test

Type **[2]**

(2) 11-pin check

Type **[3]**

(3) 15-pin check
(Not necessary for the PC-1280)

POWER switch


Power OFF

NOTE-1: Power can be turned off while the above message is on display.

NOTE-2: If the test program fails to start, check keys first.

● Details of check items

(1) RAM test




NOTE-3: The RAM corresponds to the slot in the following way.

	PC1280	PC1475
RAM1	SLOT	SLOT1
RAM2	8KB internal RAM	SLOT2


NOTE-4: The contents of the RAM are destroyed during the test. To preserve the RAM contents, type the [P] key to pass the test.

(2) 11-pin test

Set the 11-pin connector of the test tool with the 11-pin connector of the unit with the parts side facing up.



NOTE-1: See the following for the sequence of the test vs. the test pin.



- ① XOUT→XIN
- ② IO1→IO2
- ③ IO2→IO1
- ④ DOUT→DIN
- ⑤ DIN→DOUT
- ⑥ BUSY→ACK

NOTE-2: Error will not be caused, if signal lines were to short within the unit.

10. LCD Matrix Circuit


11-pin connector

11. Circuit Diagram

of the test vs. the

XOUT→XIN
 IO1→IO2
 IO2→IO1
 DOUT→DIN
 DIN→DOUT
 BUSY→ACK

es were to short




11. Circuit Diagram

10.LCD Matrix Circuit

1-pin connector

- 1) The resistor with no comment is 1/8W, J (±5%)
- 2) The capacitor with no comment is 25WV, (F)




10. LCD Matrix Circuit

(S) T-11 niq-11

Set the 11-pin connector of the test tool with the 11-pin connector to the unit with the parts side facing up.

PC-121

* Details of check items
(1) RAM test



E


F

G


H

12. Parts & Signal Description

Main PWB bottom side




Memory PWB bottom side



I Extiors(外装)

Main PWB upper side



J JAPAN:OPEN
 Except JAPAN:CLOSE
 (1.2mm height MAX)

Memory PWB upper side




No foil pattern

NO.	PARTS CODE	DESCRIPTION	QTY	UNIT	REMARK
100	TA82C01	TA82C01	1	PC	TA82C01
101	TA82C02	TA82C02	1	PC	TA82C02
102	TA82C03	TA82C03	1	PC	TA82C03
103	TA82C04	TA82C04	1	PC	TA82C04
104	TA82C05	TA82C05	1	PC	TA82C05
105	TA82C06	TA82C06	1	PC	TA82C06
106	TA82C07	TA82C07	1	PC	TA82C07
107	TA82C08	TA82C08	1	PC	TA82C08
108	TA82C09	TA82C09	1	PC	TA82C09
109	TA82C10	TA82C10	1	PC	TA82C10
110	TA82C11	TA82C11	1	PC	TA82C11
111	TA82C12	TA82C12	1	PC	TA82C12
112	TA82C13	TA82C13	1	PC	TA82C13
113	TA82C14	TA82C14	1	PC	TA82C14
114	TA82C15	TA82C15	1	PC	TA82C15
115	TA82C16	TA82C16	1	PC	TA82C16
116	TA82C17	TA82C17	1	PC	TA82C17
117	TA82C18	TA82C18	1	PC	TA82C18
118	TA82C19	TA82C19	1	PC	TA82C19
119	TA82C20	TA82C20	1	PC	TA82C20
120	TA82C21	TA82C21	1	PC	TA82C21
121	TA82C22	TA82C22	1	PC	TA82C22
122	TA82C23	TA82C23	1	PC	TA82C23
123	TA82C24	TA82C24	1	PC	TA82C24
124	TA82C25	TA82C25	1	PC	TA82C25
125	TA82C26	TA82C26	1	PC	TA82C26
126	TA82C27	TA82C27	1	PC	TA82C27
127	TA82C28	TA82C28	1	PC	TA82C28
128	TA82C29	TA82C29	1	PC	TA82C29
129	TA82C30	TA82C30	1	PC	TA82C30
130	TA82C31	TA82C31	1	PC	TA82C31
131	TA82C32	TA82C32	1	PC	TA82C32
132	TA82C33	TA82C33	1	PC	TA82C33
133	TA82C34	TA82C34	1	PC	TA82C34
134	TA82C35	TA82C35	1	PC	TA82C35
135	TA82C36	TA82C36	1	PC	TA82C36
136	TA82C37	TA82C37	1	PC	TA82C37
137	TA82C38	TA82C38	1	PC	TA82C38
138	TA82C39	TA82C39	1	PC	TA82C39
139	TA82C40	TA82C40	1	PC	TA82C40
140	TA82C41	TA82C41	1	PC	TA82C41
141	TA82C42	TA82C42	1	PC	TA82C42
142	TA82C43	TA82C43	1	PC	TA82C43
143	TA82C44	TA82C44	1	PC	TA82C44
144	TA82C45	TA82C45	1	PC	TA82C45
145	TA82C46	TA82C46	1	PC	TA82C46
146	TA82C47	TA82C47	1	PC	TA82C47
147	TA82C48	TA82C48	1	PC	TA82C48
148	TA82C49	TA82C49	1	PC	TA82C49
149	TA82C50	TA82C50	1	PC	TA82C50
150	TA82C51	TA82C51	1	PC	TA82C51
151	TA82C52	TA82C52	1	PC	TA82C52
152	TA82C53	TA82C53	1	PC	TA82C53
153	TA82C54	TA82C54	1	PC	TA82C54
154	TA82C55	TA82C55	1	PC	TA82C55
155	TA82C56	TA82C56	1	PC	TA82C56
156	TA82C57	TA82C57	1	PC	TA82C57
157	TA82C58	TA82C58	1	PC	TA82C58
158	TA82C59	TA82C59	1	PC	TA82C59
159	TA82C60	TA82C60	1	PC	TA82C60
160	TA82C61	TA82C61	1	PC	TA82C61
161	TA82C62	TA82C62	1	PC	TA82C62
162	TA82C63	TA82C63	1	PC	TA82C63
163	TA82C64	TA82C64	1	PC	TA82C64
164	TA82C65	TA82C65	1	PC	TA82C65
165	TA82C66	TA82C66	1	PC	TA82C66
166	TA82C67	TA82C67	1	PC	TA82C67
167	TA82C68	TA82C68	1	PC	TA82C68
168	TA82C69	TA82C69	1	PC	TA82C69
169	TA82C70	TA82C70	1	PC	TA82C70
170	TA82C71	TA82C71	1	PC	TA82C71
171	TA82C72	TA82C72	1	PC	TA82C72
172	TA82C73	TA82C73	1	PC	TA82C73
173	TA82C74	TA82C74	1	PC	TA82C74
174	TA82C75	TA82C75	1	PC	TA82C75
175	TA82C76	TA82C76	1	PC	TA82C76
176	TA82C77	TA82C77	1	PC	TA82C77
177	TA82C78	TA82C78	1	PC	TA82C78
178	TA82C79	TA82C79	1	PC	TA82C79
179	TA82C80	TA82C80	1	PC	TA82C80
180	TA82C81	TA82C81	1	PC	TA82C81
181	TA82C82	TA82C82	1	PC	TA82C82
182	TA82C83	TA82C83	1	PC	TA82C83
183	TA82C84	TA82C84	1	PC	TA82C84
184	TA82C85	TA82C85	1	PC	TA82C85
185	TA82C86	TA82C86	1	PC	TA82C86
186	TA82C87	TA82C87	1	PC	TA82C87
187	TA82C88	TA82C88	1	PC	TA82C88
188	TA82C89	TA82C89	1	PC	TA82C89
189	TA82C90	TA82C90	1	PC	TA82C90
190	TA82C91	TA82C91	1	PC	TA82C91
191	TA82C92	TA82C92	1	PC	TA82C92
192	TA82C93	TA82C93	1	PC	TA82C93
193	TA82C94	TA82C94	1	PC	TA82C94
194	TA82C95	TA82C95	1	PC	TA82C95
195	TA82C96	TA82C96	1	PC	TA82C96
196	TA82C97	TA82C97	1	PC	TA82C97
197	TA82C98	TA82C98	1	PC	TA82C98
198	TA82C99	TA82C99	1	PC	TA82C99
199	TA82C100	TA82C100	1	PC	TA82C100

13. PARTS LIST & GUIDE

1 Exteriors(外装)

NO.	PARTS CODE	PRICE RANK		NEW MARK	PART RANK	DESCRIPTION
		Ex	Ja			
1	DUNTG1226ECZZ		EM	N	D	Display cabinet unit (Top) (Japan) ヒョウジキャビネット ユニット
	DUNTG1229ECZZ	AP		N	D	Display cabinet unit (Top) (except Japan) ヒョウジキャビネット ユニット
2	PFI1W1009ECZZ	AD	DF	N	C	Polarized filter ヘンコウフィルター
3	PSHEZ1019ECZZ	AB	DC	N	C	Mask sheet カクシシート
4	DUNTK1227ECZZ	EV	FM	N	B	LCD unit LCDユニット
7	PGUMS1017ECZZ	AB	DC	N	C	Rubber connector ゴムコネクタ
8	CPWBF1052EC01	BS	NF	N	E	Main PWB unit (Include No9) メインキバン ユニット
9	QCNCW1306CC1B	AK	DY		C	Connector (12pin) コネクター
10	LX-BZ1155CCZZ	AA	DA		C	Screw (2×8) ビス
11	RALMB1030CCZZ	AD	DF		B	Buzzer ブザー
12	PTPEH1213CCZZ	AB	DB		C	Tape ハツオンタイ コテイテープ
13	PTPEH1026ECZZ	AE	DJ	N	C	static tape セイデンテープ
14	DUNT-1230ECZZ	AK	DY	N	B	Key sheet キーシート
15	PGUMM1015ECZZ	AB	DC	N	C	Fixing rubber アッチャクゴム
16	LANGT1011ECZZ	AC	DE	N	C	Fixing angle アッチャクアングル
17	LX-BZ1200CCZZ	AA	DA		C	Screw ビス
18	DUNTG1268ECZZ	AP	EM	N	D	Display cabinet unit (Bottom) ヒョウジキャビネット ユニット
19	GFTAS1282CC01	AB	DB		D	Connector cover コネクター フタ
20	DUNTG1225ECZZ		EM	N	D	Key cabinet unit (Top) (Japan) キーキャビネット ユニット
	DUNTG1228ECZZ	AP		N	D	Key cabinet unit (Top) (except Japan) キーキャビネット ユニット
21	LPINS1002ECZZ	AA	DA	N	C	Spring pin スプリングピン
22	PGUMM1013ECZZ		EC	N	B	Key rubber (Japan) ゴムキー
	PGUMM1013ECSA	AL		N	C	Key rubber (except Japan) ゴムキー
23	PZETL1024ECZZ	AA	DA	N	C	Key spacer キースペーサ
24	CPWBF1053EC01	AX	FU	N	E	Memory PWB unit メモリーキバン ユニット
25	MSPRC1011ECZZ	AA	DA	N	C	Earth spring セイデン スプリング
26	MSPRC1001ECZZ	AB	DB		C	PS spring for RAM card RAMカードヨウ PSスプリング
27	QCNTM1042CCZZ	AA	DA		C	Slide switch terminal スライドスイッチヨウ セッテン
28	MSLIP1003ECZZ	AB	DC	N	C	Slide switch knob スライドスイッチ ツマミ
29	PGUMM1594CCZZ	AB	DB		C	Reset spring rubber リセットスプリングゴム
30	PGUMS1608CCZZ	AE	DJ		C	Rubber connector for RAM card RAMカードヨウ ゴムコネクター
31	PZETL1564CCZZ	AB	DC		C	Insulator sheet ゼツエンシート
32	QTANZ1503CCZZ	AB	DB		C	Battery terminal A バッテリータンシ A
33	QCNTM1056CC01	AA	DA		C	Contact for slide switch スライドスイッチヨウ セッテン
34	JKNBZ1747CCZZ	AA	DB		C	PS switch knob PSスイッチ ツマミ
35	GCABA1030ECZZ	AE	DK	N	D	Key cabinet unit (Bottom) キーキャビネット ユニット
36	QTANZ1504CCZZ	AB	DB		C	Battery terminal B バッテリータンシ B
37	LFI-X-1190CCSC	AB	DC	N	C	Card stopper カードストッパー
38	TLABH1127ECZZ		DA	N	C	Battery caution label (Japan) デンチチュウイ ラベル
	TLABH1143ECZZ	AA		N	C	Battery caution label (except Japan) デンチチュウイ ラベル
39	GFTAU1012ECZZ	AE	DM	N	D	Lid for card カードフタ
40	QTANZ1406CCZZ	AB	DC		C	Battery terminal (+)(-) バッテリータンシ
41	LX-BZ1018ECZZ	AA	DA		C	Screw ビス
42	LX-BZ1147CCZZ	AA	DA		C	Screw (2×4.5) ビス
43	LX-BZ1116CCN1	AA	DA		C	Screw ビス
44	PSPAP1001ECZZ	AA	DA		C	Reset spacer リセットスペーサー
45	TLABH1160ECZZ		DA	N	C	Caution label(Battery replacement) (Japan) デンチコウカン チュウイ ラベル
	TLABH1161ECZZ	AA		N	C	Caution label(Battery replacement) (except Japan) デンチコウカン チュウイ ラベル
46	PZETL1029ECZZ	AB	DB	N	C	Insulator sheet マイラーシート
101	TLABZ1008ECZZ	AA	DA		C	Caution label チュウイラベル
102	TLABS1078ECZZ		DA		D	VCCI label 3 (Japan) VCCIラベル 3
103	TLABH1956CCZZ	AB	DB		C	Protector label ユソウジ ホゴラベル



2 Main PWB unit(メイン基板ユニット)

NO.	PARTS CODE	PRICE RANK		NEW MARK	PART RANK	DESCRIPTION			
		Ex	Ja						
1	QCNCW1306CC1B	A	K	D	Y	C	Connector (11pin)	コネクタ	
2	RC-CZD105ECZZ	A	C	D	D	C	Capacitor (1 μ F)	コンデンサー	
3	RC-CZ1047CCZZ	A	B	D	B	C	Capacitor (0.033 μ F)	コンデンサー	
4	RC-EZ335BEC0J	A	B	D	C	C	Capacitor (6.3WV 3.3 μ F)	コンデンサー	
5	RC-KZ1054CCZZ	A	B	D	C	C	Capacitor (50WV 0.1 μ F)	コンデンサー	
6	RC-ZZ1006CCZZ	A	B	D	B	C	Capacitor (0.1 μ F)	コンデンサー	
7	RCSRZ1063CCZZ	A	F	D	M	B	Crystal (768KHz)	クリスタル	
8	RH-DZ1001ECN1	A	D	D	F	B	Diode (1SR148)	ダイオード	
9	RVR-Z2400QCZZ	A	F	D	N	B	Variable resistor (20K Ω)	ポリウム	
10	VCCCTP1HH101J	A	A	D	A	C	Capacitor (50WV 100PF)	コンデンサー	
11	VCCCTP1HH151J	A	A	D	A	N	C	Capacitor (50WV 150PF)	コンデンサー
12	VCKYTP1EF104Z	A	A	D	A	C	Capacitor (25WV 0.10 μ F)	コンデンサー	
13	VCKYTP1HB821K	A	A	D	A	N	C	Capacitor (50WV 820PF)	コンデンサー
14	VHDDAN202K/-1	A	B	D	B	B	Diode (DAN202K)	ダイオード	
15	VHDDA204K//--1	A	C	D	C	B	Diode (DA204K)	ダイオード	
16	VHDDSS133//--1	A	A	D	A	B	Diode (DSS133)	ダイオード	
17	VHID4364G15LN	B	D	G	U	B	IC (D4364G15LN)	IC	
18	VHILH5310X7-1	A	W	F	R	B	IC (LH5310X7)	IC	
19	VHILZ92K38/-1	A	N	E	K	B	IC (LZ92K38)	IC	
20	VHIMN1280Q/-1	A	E	D	H	B	IC (MN1280Q)	IC	
21	VHISC43536/-1	A	X	F	U	B	IC (SC43536)	IC	
22	VHISC61860A38	A	X	F	U	B	IC (SC61860A38)	IC	
23	VRS-TP2BD100J	A	A	D	A	C	Resistor (1/8W 10 Ω \pm 5%)	テイクウ	
24	VRS-TP2BD103J	A	A	D	A	C	Resistor (1/8W 10K Ω \pm 5%)	テイクウ	
25	VRS-TP2BD104J	A	A	D	A	C	Resistor (1/8W 100K Ω \pm 5%)	テイクウ	
26	VRS-TP2BD105J	A	A	D	A	C	Resistor (1/8W 1.0M Ω \pm 5%)	テイクウ	
27	VRS-TP2BD203J	A	A	D	A	C	Resistor (1/8W 20K Ω \pm 5%)	テイクウ	
28	VRS-TP2BD393G	A	A	D	A	C	Resistor (1/8W 39K Ω \pm 2%)	テイクウ	
29	VRS-TP2BD472J	A	A	D	A	C	Resistor (1/8W 4.7K Ω \pm 5%)	テイクウ	
30	VRS-TP2BD562G	A	A	D	A	C	Resistor (1/8W 5.6K Ω \pm 2%)	テイクウ	
31	VRS-TP2BD563J	A	A	D	A	C	Resistor (1/8W 56K Ω \pm 5%)	テイクウ	
32	VSDTA144EK/-1	A	C	D	C	B	Transistor (DTA144EK)	トランジスター	
33	VSDTC144EK/-1	A	C	D	C	B	Transistor (DTC144EK)	トランジスター	
34	VS2SC2412K/-1	A	B	D	B	B	Transistor (SC2412K)	トランジスター	
35	RC-K1E104HCZZ	A	B	D	C	C	Capacitor (25WV 0.1 μ F)	コンデンサー	
36	VRD-HT2EY104J	A	A	D	A	C	Resistor (1/4W 100K Ω \pm 5%)	テイクウ	
	ユニット (Unit)								
901	CPWBF1052EC01	B	S	N	F	N	E	Main PWB unit	メイン基板 ユニット

3 Packing material & Accessories(梱包と付属品)

NO.	PARTS CODE	PRICE RANK		NEW MARK	PART RANK	DESCRIPTION			
		Ex	Ja						
1	LPLTP1007ECZZ	A	C	D	D	Template	テンプレート		
2	TiNSJ1118ECZZ			F	X	N	D	Instruction book (Japan)	トリアツカイセツメイショ
	TiNSE1122ECZZ	A	X			N	D	Instruction book (except Japan,Germany)	トリアツカイセツメイショ
	TiNSG1123ECZZ	A	X			N	D	Instruction book (Germany)	トリアツカイセツメイショ
3	SPAKC0276ECZZ			D	N	N	D	Packing case (Japan)	パッキングケース
	SPAKC0279ECZZ	A	F			N	D	Packing case (except Japan)	パッキングケース
4	TLSTS1015CCZZ					D	A	Service list (Japan)	サービスリスト
5	SPAKA0278ECZZ	A	D	D	F	N	D	Packing cushion for set	セットヨウ パッキングクッション
6	PHOG-1001ECZZ	A	A	D	A	N	D	Protector sheet	ユソウジホゴケース

SHARP

COPYRIGHT © 1987 BY SHARP CORPORATION

All rights reserved.

Printed in Japan.

No part of this publication may be reproduced,
stored in a retrieval system, or transmitted,
in any form or by any means,
electronic, mechanical, photocopying, recording, or otherwise,
without prior written permission of the publisher.

SHARP CORPORATION
Information Systems Group
Quality & Reliability Control Center
Yamatokoriyama, Nara 639-11, Japan

1987 March Printed in Japan ©