


SHARP SERVICE MANUAL

CODE: 00ZPCE500SSME



MODEL PC-E500S

1. GENERAL

The PC-E500S is a modified version of the PC-E500, having the easy-to-read FSTN LCD. The major changes lie in the resin key-top and the hard cover installation method.

2. SPECIFICATIONS

- Model : PC-E500S
- Display : 40 digits x 4 lines (5 x 7 dot matrix LCD display)
- Arithmetic capacity : Single precision; 10 digits (mantissa) + 2 digits (exponent)
Double precision; 20 digits (mantissa) + 2 digits (exponent)
Calculation, however, is performed in the single precision under the CAL mode, the MATRIX mode, and the STAT mode.
- Arithmetic method : According to the formula (with the priority discrimination function)
- Programming language : BASIC
- CPU : CMOS 8 bit CPU
- System ROM : 512K byte
- Memory capacity : System area About 3.8K byte
Fixed variable (A - Z) area 312 byte
Program data area 28,600 byte
- Stacks : Total 145 byte
Subroutine 4 byte for one step
FOR-NEXT 21 byte for one step
REPEAT-UNTIL 7 byte for one step
WHILE-WEND 8 byte for one step
SWITCH-CASE-DEFAULT-ENDSWITCH 9 byte for one step
- Basic arithmetic functions : Basic functions;
Four arithmetic rules
Functional;
Trigonometric, inverse trigonometric, hyperbolic, inverse hyperbolic, logarithmic, exponential, angular transformation, power raising, power root, coordinate transformation, square root, ratio of integers, absolute value, signed function, ratio of the circumference, and others.

- Editing functions : Horizontal cursor control (◀, ▶)
Insertion (INS)
Deletion (DEL, BS)
Line up and down (↑, ↓)

Serial I/O


- Communication mode : Advance sync (asynchronous) system, half-duplex/full-duplex mode
- Communication speed : 300, 600, 1200, 2400, 4800, 9600 bps
- Parity bit : Even, odd, none
- Word length : 7, 8 bits
- Stop bit : 1, 2 bits
- Connector : 15-pin connector (from connection with an external device)
- Output signal level : C-MOS level (4 ~ 6V)
- Interface signal : Input RD, CS, CD
Output SD, RS, RR, ER
Others SG, FG, VC
- Memory protection : Battery backup (The program and data in memory are protected when the power is off.)
- Operating temperatures : 0 °C ~ 40 °C
- Power source : Operating; 6V --- (DC), Alkaline battery (UM4) x 4
Memory protection; 3V --- (DC), Lithium battery (CR2016) x 1
- Battery life : Approx. 70 hours under continuous, normal use. (10 minutes of operation or program execution per hour under temperature of 20 °C with 50 minutes of displaying.)
The battery life depends on the operating conditions and usage.
- Power consumption : 0.09W
- External dimensions : 220mm (W) x 202.5mm (D) x 14mm (H) (with the hard cover opened)
220mm (W) x 104.5mm (D) x 19mm (H) (with the hard cover closed)
- Weight : 340 g (including the batteries)
- Accessories : UM4 battery x 4 pcs., Instruction manual, CR2016 battery x 1 pcs., screwdriver (for replacing the memory backup battery)

Parts marked with "△" is important for maintaining the safety of the set. Be sure to replace these parts with specified ones for maintaining the safety and performance of the set.


SHARP CORPORATION

This document has been published to be used for after sales service only.
The contents are subject to change without notice.

3. System composition



4. PC-E500S system block diagram



Pin No.	Signal name	I/O	Signal description
55	KO13	O	SIO RR (Can be received in the main body.)
56	KO12	O	SIO RS (Main body send request)
57	KO11	O	} Key strobe signal
58	KO10	O	
59	IRQ	I	Low battery detection input pin
60	ϕ OUT	—	} (Reserved)
61	CE7	—	
62	CE6	O	ROM card chip select signal (Active HIGH), 10000~1FFFF
63	CE5	O	Display chip select signal (Active HIGH), 00000~03FFF and 08000~0BFFF
64	CE4	—	} (Reserved)
65	CE3	—	
66	CE2	O	Internal ROM chip enable signal, C0000~FFFFFF
67	CE1	O	RAM card chip enable signal, 40000~7FFFF
68	CE0	O	Internal RAM chip enable signal, 80000~BFFFF
69	ϕ A	—	} (Reserved)
70	DIS	—	
71	HA	—	
72	RD	—	
73	KO9	O	} Key strobe signal
?	?	?	
82	KO0	O	
83	RXD	I	SIO RD (Receive data)
84	TXD	O	SIO SD (Send data)
85	E15	I	} CE-140F data input pin
86	E14	I	
87	E13	I	
88	E12	I	
89	E11	O	11 pin DIN, P-ch open output
90	E10	O	11 pin DOUT, P-ch open output
91	E9	O	11 pin IO2, P-ch open output
92	E8	O	11 pin IO1, P-ch open output
93	E7	I	11 pin ACK
94	E6	O	11 pin BUSY, P-ch open output
95	E5	—	(Reserved)
96	E4	O	Display power (convertor) control signal
97	E3	O	Low battery voltage control signal
98	E2	I	SIO CS (Remote station transmission enable)
99	E1	I	SIO CD (Remote station send request)
100	E0	I	SIO PAK (Reserved)

7. Low battery detection circuit

This model is equipped with the low battery detection circuit, the operations of which are described below. (Location Nos. of the parts are different from the actual ones.)


As shown in the figure below, the output of the voltage detecting IC [LBIC (RH5VA39A)] turns HIGH when input voltage V_{IN} exceeds detecting voltage V_D . When, on the contrary, V_{IN} falls below V_D , the output turns LOW.

The LBIC (RH5VA39A) detects two levels; the CAU level and the STOP level. For that reason, a voltage applied to the input pin (2 pin) is divided by R_1 and R_2 , and R_2 is turned on/off by the CAU signal of G.A.


When the power voltage falls below the CAU level, as shown in Fig. 3, the BATT symbol lights up. When it falls further below the STOP level, the BATT symbol goes off.

To detect the CAU level, the CPU E3 is turned on (LOW) and the CPU IRQ pin state is checked. (If the IRQ pin is at LOW, the symbol lights up.)


When the CAU level is detected, the CAU pin is turned off (HIGH). (When the CAU E3 is turned off, resistance is not divided, rising the potential at BIC 2 pin and turning the output from LOW to HIGH.) Then the CPU IRQ pin is checked again to check the STOP level. After detecting the STOP level, ON key and RESET key are made invalid.



[Fig. 1]



[Fig. 2]



[Fig. 3]

Low battery detection circuit check
 CAU level VCC-GND: 4.2V - 4.6V
 STOP level VCC-GND: 3.8V - 4.2V

8. Current consumption check

Power source: 11-pin connector, +5V - 0V applied to VCC (2 pin) - GND (3 pin)


Current: At ON (BASIC mode with ">" displayed), 3.29 mA or less.
 At OFF (Power OFF), 22.8 uA or less.

Reference

	operation	display	off	back-up
CPU	4.2mA	220μA	3μA	
ROM	6.12mA	139μA	2μA	
RAM	5.98mA	2μA	2μA	1μA
HD61203	1mA	←		
HD61202	500μA	100μA	15μA	

	operation	display	off	back-up
DC-DC converter	1.5mA	1.5mA		
VDD	0.75mA	←		
RH5VA39A	3.9μA	←	←	
TC4S81F	1μA	←	←	
TC3W01F	2μA	←	←	1μA
TC4S66F	0.25μA	←	←	0.13μA
TC7S08F	1μA	←	←	
TC7S02F	1μA	←	←	0.25μA
TC4S11F	0.25μA	←	←	


8-1. Current consumption and low battery voltage detection



	Operating procedure	Check item
1	<ul style="list-style-type: none"> Turn on the main DC power (+6.3V ±0.1V). While pressing ON key, press RESET key. Press Y key to initialize the internal RAM. 	
2	<ul style="list-style-type: none"> Press PF1 key to go into the BASIC mode. 	<ul style="list-style-type: none"> Check ">" display and check the current value. (The current should be 3.77 mA or less.)
3	<ul style="list-style-type: none"> Set the DC power to +4.1 ±0.05V. 	<ul style="list-style-type: none"> Check that the BATT symbol lights up.
4	<ul style="list-style-type: none"> Set the DC power to +3.7V ± 0.1V. 	<ul style="list-style-type: none"> Check that the display is out
5	<ul style="list-style-type: none"> Return the DC power to +6.3V ± 0.1V. 	<ul style="list-style-type: none"> Check that the display is out and check the current. (The current should be 22.8μA.)
6	<ul style="list-style-type: none"> Disconnect the 11-pin connector. Short 2 pin and 3 pin of the 11-pin connector with a 3.9KΩ resistor for 6 sec. 	

Note: If there are any data or program, save them in advance to this check.


8-2. Backup current detection



	Operating procedure	Check item
1	• Set the DC power to +3.0V ±0.1V.	
2	• Apply a probe to the backup battery terminal of the set. (Be careful not to mistake the DC power polarity. The positive (+) terminal should be brought into contact with the battery terminal from the side, not from the above, and the negative (-) terminal should be connected with the soldered section.)	• Check the current value. (0.1 µA ~ 2.38 µA)
3	• Disconnect the probe.	

8-3. Built-in RAM memory protection function check

- ① Release the RAM card cover lock switch and turn off the power.
- ② Set the built-in RAM memory protection switch to B and remove one UM4 battery.
- ③ Connect 2 pin and 3 pin of the 11-pin connector with a 3.9KΩ resistor for 6 sec.



Connecting time: 6 sec

- ④ Install the UM4 battery which was previously removed to the original position, set the RAM card lock switch to the lock position, and press RESET key.
- ⑤ Check that "NO MEMORY" is displayed. (Check of the memory protection switch function)
- ⑥ Set the built-in RAM memory protection switch to A and press ON key.
- ⑦ Check that "MAIN MENU" is displayed. (Check of the memory protection function)

9. Diag


Entering the diag mode: Turn of the power, keep pressing **SHIFT** key and **[]** key, press **RESET** key.
Release **RESET** key, then release **SHI** key and **[]** key.

Diag Menu		
1:diag	2:LB	3:aging 1
4:aging2	5:RAM	6:FCC
7:ESD	8:diag(menu)	


- | | |
|-------------|----------------------------|
| 1 key input | (1) Diag check |
| 2 key input | (2) LB check |
| 3 key input | (3) Aging 1 |
| 4 key input | (4) Aging 2 |
| 5 key input | (5) RAM check |
| 6 key input | (6) FCC check |
| 7 key input | (7) ESD check |
| 8 key input | (8) Diag check (many form) |

(1) Diag check


- Main menu
↓ 1 key
① LCD check
Cross-stitch display 1 (LCD left upper corner lights up.)
↓ ENTER key
Cross-stitch display 2 (Inverted cross-stitch display 1)
↓ ENTER key
Slanted line display 1
↓ ENTER key
Slanted line display 2 (Inverted slanted-line display 1)
↓ ENTER key
Rain drop display (Lower half of the screen)
↓ ENTER key
② ROM check




③ RAM check




④ 11 pin check




⑤ 15 pin check




⑥ Card RAM check




⑦ KEY check




(2) LB check




(3) Aging 1




(4) Aging 2




(5) RAM check





(6) FCC check




(7) ESD check

ESD menu


ESD Menu	
1:write MAIN RAM	2:write CARD RAM
3:read MAIN RAM	4:read CARD RAM
5:write/read MAIN	6:write/read CARD

- 1 key input ① write MAIN RAM
- 2 key input ② write CARD RAM
- 3 key input ③ read MAIN RAM
- 4 key input ④ read CARD RAM
- 5 key input ⑤ write/read MAIN RAM
- 6 key input ⑥ write/read CARD RAM


① write MAIN RAM




② write CARD RAM




③ read MAIN RAM




④ read CARD RAM



⑤ write/read MAIN RAM



⑥ write/read CARD RAM



(8) Diag check (menu form)



Perform each check of (1) diag check individually.

Diag menu


```
* check list 2 *
1: LCD check      2: ROM check
3: RAM check     4: KEY check
5: 11pin check   6: 15pin check
```

- 1 key input (1) LCD check of (1) diag.
- 2 key input (2) ROM check of (1) diag.
- 3 key input (3) RAM check of (1) diag.
- 4 key input (7) KEY check of (1) diag.
- 5 key input (4) 11 pin check of (1) diag.
- 6 key input (5) 15 pin check of (1) diag.

After completion of each check, the control returns to the diag menu.




• RAM card address map



• The address check is performed from the lower address to the higher. The error address which is found first is displayed.

• Details of the error code

(Example) In 11-pin check error:



Refer to the 11-pin check code table.

No.	Output port					Input port					Normal data	
	BUSY	Din	Dout	IO2	IO1	ACK	Din	Dout	IO2	IO1		
0	0	0	0	0	0	1	1	0	0	1	1	13

In the above table, if the output port signal is "000001," the input port signal "10011" is normal. ("10011" in the binary system is "13" in the hexadecimal system.)

If 11-pin check error code is "1 13 01," the input port signal should be "13 (10011)", and "01(00001)" means it is an error.

That is, data at ACK and IO2 are errors.

• 11 pin check code table

No.	Output port					Input port					Normal data	
	BUSY	Din	Dout	IO2	IO1	ACK	Din	Dout	IO2	IO1		
0	0	0	0	0	0	0	0	0	0	0	0	08
1	0	0	0	0	0	1	1	0	0	1	1	19
2	0	0	0	0	1	0	1	0	0	1	1	08
3	0	0	0	0	1	1	1	0	0	1	1	1B
4	0	0	1	0	0	1	1	1	0	0	0	00
5	0	0	1	0	1	1	1	1	1	1	1	15
6	0	0	1	1	0	1	1	1	1	1	1	00
7	0	0	1	1	1	1	1	1	1	1	1	17
8	0	1	0	0	0	1	1	1	0	0	0	08
9	0	1	0	0	1	1	1	1	1	1	1	19
A	0	1	0	1	0	1	1	1	1	1	1	08
B	0	1	0	1	1	1	1	1	1	1	1	1B
C	0	1	1	0	0	1	1	1	0	0	0	08
D	0	1	1	0	1	1	1	1	1	1	1	1D
E	0	1	1	1	0	1	1	1	1	1	1	08
F	0	1	1	1	1	1	1	1	1	1	1	1F
10	1	0	0	0	0	0	1	0	0	0	0	1A
11	1	0	0	0	1	1	0	0	1	1	1	19
12	1	0	0	1	0	1	0	0	1	1	1	1A
13	1	0	0	1	1	1	0	0	1	1	1	1B
14	1	0	1	0	0	1	1	1	0	0	0	16
15	1	0	1	0	1	1	1	1	1	1	1	15
16	1	0	1	1	0	1	1	1	1	1	1	16
17	1	0	1	1	1	1	1	1	1	1	1	17
18	1	1	0	0	0	0	1	1	0	0	0	1A


No.	Output port					Input port					Normal data	
	BUSY	Din	Dout	IO2	IO1	ACK	Din	Dout	IO2	IO1		
19	1	1	0	0	1	1	1	1	1	1	1	19
1A	1	1	0	1	0	1	1	1	1	1	1	1A
1B	1	1	0	1	1	1	1	1	1	1	1	1B
1C	1	1	1	0	0	1	1	1	0	0	0	1E
1D	1	1	1	0	1	1	1	1	1	1	1	1D
1E	1	1	1	1	0	1	1	1	1	1	1	1E
1F	1	1	1	1	1	1	1	1	1	1	1	1F
20	X OUT					X IN					01	

• 15 pin check code table

No.	Output port					Input port				Normal data
	PRQ	ER	RR	RS	CS	CD	PAK			
0	0	0	0	0	0	0	0	0	0	00
1	0	0	0	1	1	0	0	0	0	04
2	0	0	1	0	0	1	0	0	0	02
3	0	0	1	1	1	1	0	0	0	06
4	0	1	0	0	0	0	1	0	0	01
5	0	1	0	1	1	0	1	0	0	05
6	0	1	1	0	0	1	1	0	0	03
7	0	1	1	1	1	1	1	0	0	07
8	1	0	0	0	0	0	0	1	0	01
9	1	0	0	1	1	0	1	0	0	05
A	1	0	1	0	0	1	1	0	0	03
B	1	0	1	1	1	1	1	0	0	07
C	1	1	0	0	0	0	1	0	0	01
D	1	1	0	1	1	0	1	0	0	05
E	1	1	1	0	0	1	1	0	0	03
F	1	1	1	1	1	1	1	0	0	07
20	SD				RD				01	


10. Note for servicing

1. Electrostatic sheet attachment




2. Nut holding tape attachment reference

After inserting the nut, attach according to the reference shown below:




3. Battery holding cushion attachment reference




4. Buzzer attachment


① Remove the separation sheet from the buzzer spacer, and attach the buzzer to the spacer.




② Attach the assembly over the HD61203 on the PWB.



③ Solder the lead wire and fix with tape.




5. PWB fixing screw attachment position



6. Note for handling PWB

① Jumper wire process




	J1	J2
Dimension a	1~2	1~2
Dimension b	115	70

② Electrostatic capacitor process and soldering


C12: 220 uF

- Be careful to the polarities.
- When soldering, bring the capacitor into close contact with the PWB.
- For soldering position, refer to the parts arrangement view.




③ Contrast VR solderin

- Attach duplex tape so that it does not cover the VR attachment hole and does not extend from the PWB edge and the FG pattern.
- Solder form above the duplex tape.
- * Do not apply the soldering iron for more than 3 sec. (This is to prevent deformation of the VR.)
- * Be careful not to deform the VR.
- * Put the VR closely to the PWB and solder it.




④ 11-pin, 15-pin connectors soldering

- * 11-pin connector soldering
- Attach the spacer to the 11-pin connector.
- Insert the 11-pin connector to the PWB. Solder the inserted lead wires (x 2) first, then solder the 11-pin lead wire.
- Attach the connector closely to the PWB and solder it.




• 15-pin connector soldering

- Attach two electrostatic SP to the 15-pin connector lead wire.
- Insert the 15-pin connector to the PWB. Solder the inserted lead wires (x 2) first, then solder the 15-pin lead wire.
- * Attach the connector closely to the PWB and solder it.



⑤ Card cover SP soldering


- Insert the card cover SP into the PWB, and solder it.
- * Solder perpendicularly to the PWB.
- * Take care when handling after soldering.



⑥ Insulation sheet attachment


Insulation sheet attachment

- Fit the insulation sheet hole with the PWB screw hole and attach it.
- For the attachment position, refer to the parts arrangement view.




• Battery terminal insulation sheet attachment


- Fit the upper edge of the battery terminal insulation sheet to the PWB edge and fit the left edge to the marking pattern, and attach it.
- Attach so that it does not extend from the PWB edges.




- Backup battery terminal insulation sheet attachment
 - Fit the backup battery terminal insulation sheet to the resist ring (reference mark), and attach it from above the backup battery terminal (-).



11. LCD wiring diagram





12. CIRCUIT DIAGRAM



K010	P)	↕	CA	STO	RCL	I	Y	R	W	◀▶	K10
K09	2nd F	FSE	tan	cos	sin	hyp	O	U	T	E	O	K11
K08	PF5	1/x	log	In	-DEG	-HEX	K	H	F	S	MENU	K12
K07	PF4	(x ²	√	y ²	EXP	L	J	G	D	A	K13
K06	PF3	DEL	÷	9	8	7	,	N	V	X	BASIC	K14
K05	PF2	BS	x	6	5	4	;	M	B	C	Z	K15
K04	PF1	INS	-	3	2	1	▶	↑	SPACE	CAPS	SHIFT	K16
K03		=	+	.	+/-	0	◀	↓	↵	↵	CTRL	K17


Note 1: Unless otherwise specified, diodes are as shown below: RB40
 Note 2: Unless otherwise specified, the accuracy of resistance is +5%.

FSTN-LCD (LF77660)
LC1



low: \leftarrow RB400D, \leftarrow DAN202K
 stance is +5%.

13. PWB LAYOUT




* Solder the electrolytic capacitor (220µF/10V) along this line.

* Arrange the jumper wire (J1) so that it is placed 1mm or more inside of the PWB edge and that it does not cross over the parts. Solder the card cover SP side quickly not to remove the card cover SP solder.

☆ Different parts in different models are shown below:

	ROM(IC2)	R25	R26	IC11
PC-E500S	VH i L H 5 3 4 H F 9 - 1	○	×	×
PC-E650	VH i L H 5 3 4 H F B - 1	×	○	○
PC-U6000	VH i L H 5 3 4 H F 7 - 1	×	○	○

○ Provided. × Not provided.



is placed 1mm or more
older the card cover SP side
P solder.

* Jumper wire fixing tape. Do not extend it from the PWB.

*ROM
PC-U6000...VHILH534HF7-1
PC-E500S...VHILH534HF9-1
PC-E650...VHILH534HFB-1

*R25 (0 Ohm) is provided in the
PC-E500S only.
R26 (0 Ohm) and IC11
(ATT7C256BF12L) are provided in
the PC-E650 and PC-U6000 only.

* Do not put solder to section 
* Solder the jumper wire (J2) so that it does not cross
over the 11-pin connector body.

* Solder to the pad at the
corner of the PWB.

* Do not solder to this pad.

14. PARTS GUIDE

1 Exteriors

NO.	PARTS CODE	PRICE RANK	NEW MARK	PART RANK	DESCRIPTION
1	GFTAU1006EC03	AK	N	D	Card lid
2	TLABH1267ECZZ	AC		D	Battery replacement label B
3	LX-BZ1036ECZZ	AA		C	Screw
4	GFTAG1306CCZZ	AD		D	Battery cover
5	PZETL1046ECZZ	AA		C	Insulation sheet for battery
6	TCAUK1242CCZZ	AA		D	Caution label
7	LX-BZ1034ECZZ	AC		C	Screw
8	GFTAB1023EC01	AE	N	D	Battery lid
9	PCUSS1026ECZZ	AB		C	Cushion(for battery fix)
10	TLABH1313ECZZ	AB		D	Battery direction caution label
11	TLABH1314ECZZ	AD	N	D	Battery replacement label
12	TLABM1316ECZZ	AC	N	D	Name plate [Germany]
	TLABM1321ECZZ	AC	N	D	Name plate [U.S.A.]
	TLABM1315ECZZ	AC	N	D	Name plate [except Germany,U.S.A.]
13	LX-BZ1263CCZZ	AA		C	Screw (2×8.5)
14	GFTAS1025EC01	AC	N	D	Connector lid B
15	PGUMS1549CCZZ	AE		C	PWB card connector
16	PTPEH1059ECZZ	AF		D	Shield tape A
17	MSLIP1031CC09	AC	N	C	Slide switch slider
18	JKNBZ1225CC02	AA		C	Slide switch knob
19	PTPEH1061ECZZ	AA		D	Nut fixing tape
20	XNESD20-16000	AA		C	Nut (2mm)
21	GFTAS1024EC01	AC	N	D	Connector lid A
22	GCABA1062EC01	AK	N	D	Bottom cabinet
23	QTANB1029ECZZ	AB		C	Battery terminal B ⊖
24	QTANB1027ECZZ	AB		C	Battery terminal B ⊕
25	QTANB1026ECZZ	AB		C	Battery terminal A ⊕
26	QTANB1031ECZZ	AB	N	C	Battery terminal ⊖
27	LX-BZ1109CCZZ	AA		C	Screw (2×4.5)
28	DUNTK1564ECZZ	BV	N	E	PWB unit (include No.53~56)
29	PGUMM1042ECZZ	AH		C	Key rubber A
30	PGUMM1043ECZZ	AK		C	Key rubber B
31	PSHEZ1039ECZZ	AC		C	Noise sheet
32	JKNBZ1031EC01	AK	N	C	Key frame A-1
33	JKNBZ1032EC01	AH	N	C	Key frame A-2
34	JKNBZ1033EC01	AH	N	C	Key frame B-1
35	JKNBZ1034EC01	AN	N	C	Key frame B-2
36	PSLDP1036ECZZ	AE	N	C	Display mask
37	PFLW1018ECZZ	AF		D	Acryl filter
38	MSPRC1018ECZZ	AA		C	Hinge slide spring
39	NSFTZ1005EC01	AC	N	C	Hinge shaft A
40	GCABB1061EC01	AS	N	D	Top cabinet
41	JKNBZ1030EC01	AC	N	C	Lock knob
42	LX-NZ1020CCZZ	AA		C	Nut
43	MSPRC1019ECZZ	AA		C	Hinge lock spring
44	LPINS1004EC01	AC	N	C	Lock pin
45	NSFTZ1006EC01	AC	N	C	Hinge shaft B
46	LFX-1190CCB2	AC	N	C	Card stopper
47	PZETL1070ECZZ	AB		C	Insulation sheet
48	QCNTM1023CCZZ	AB		C	Slide switch terminal
49	PZETL1068ECZZ	AB		C	Battery terminal insulation sheet
50	PZETL1825CCZZ	AA		C	Battery terminal insulation sheet(for back up)
51	TLABZ1317ECZZ	AG	N	D	Command list label
52	GCASP1009EC01	AM	N	D	Hard case
53	QTANZ1030ECZZ	AC		C	Terminal for back up battery ⊕
54	QTANZ1583CC07	AB		C	Battery terminal ⊖
55	PZETL1069ECZZ	AB		C	PWB insulation sheet
56	PZETL1851CCZZ	AA		C	Insulation sheet

2 Packing material & Accessories


NO.	PARTS CODE	PRICE RANK	NEW MARK	PART RANK	DESCRIPTION
1	TINSG1223ECZZ	AW	N	D	Instruction book [Germany]
	TINSE1221ECZZ	AY	N	D	Instruction book [U.S.A.]
	TINSE1222ECZZ	AY	N	D	Instruction book [except Germany,U.S.A.]
2	SPAKC0531ECZZ	AK	N	D	Packing case [except U.S.A.Canada]
	SPAKC0529ECZZ	AK	N	D	Packing case [U.S.A.]
	SPAKC0530ECZZ	AK	N	D	Packing case [Canada]
3	SPAKA881ECZZ	AG		D	Packing cushion for set
4	SPAK-0525ECZZ	AC		D	Viney bag
5	SSAKA0006UCZZ	AA		D	Vinyl bag (50mm×60mm)
6	TCADZ1016ECZZ	AB		D	Driver illustration
7	TGANE1113CCZZ	AC		D	Guaranty [Australia]
	TGANE1002CSZZ	AB		D	Guaranty [Canada]
8	TCADZ1808CCZZ	AA		D	Noise card [Canada]
9	TCAUZ1341CCZZ	AA		D	Card [Germany]

Germany
[U.S.A]
ny,U.S.A

53~56)

Germany
[U.S.A]
ny,U.S.A
Canada
[U.S.A]
Canada

Australia
Canada
Canada
Germany



CCP00007

2 Packing material & Accessories

NO.	PARTS CODE	PRICE RANK	NEW MARK	PART RANK	DESCRIPTION
10	UKOGD1009CCZZ	AC		S	Driver +

3 PWB unit

NO.	PARTS CODE	PRICE RANK	NEW MARK	PART RANK	DESCRIPTION
1	DUNT-1541ECZZ	BD		E	LCD unit
2	MSPRC1020ECZZ	AB		C	Card lid spring
3	MSPRC1277CCZZ	AA		C	Connector spring (for 15pin connector)
4	PGUMS1044ECZZ	AB		C	Rubber connector
5	PSPAP1024ECZZ	AC		C	Spacer for buzzer
6	PSPAP1289CCZZ	AA		C	Spacer for 11pin connector
7	PTPEH1062ECZZ	AA		D	Tape (7×7)
8	PZETL1069ECZZ	AB		C	PWB insulation sheet
9	PZETL1851CCZZ	AA		C	Insulation sheet
10	QCNCW1001EC1A	AG		C	Connector (11pin) [CN1]
11	QCNCW1368CC1E	AM		C	Connector (15pin) [CN2]
12	QTANZ1030ECZZ	AC		C	Terminal for back up battery (+)
13	QTANZ1478CCSA	AC		C	Power terminal
14	QTANZ1583CC07	AB		C	Battery terminal -
15	RALMB1030CC01	AD		B	Buzzer [BZ]
16	RC-CZ1093CCZZ	AB		C	Capacitor (0.1μF) [C5,6,7,8,9,10]
17	RC-EZ227DCC1A	AB		C	Capacitor (10WV 220μF) [C12]
18	RCRM-1017CCZZ	AE		B	Crystal (2.3M) [X1]
19	RMPTQ4104QCJJ	AB		B	Block resistor (100KΩ×4 ±5%) [BR1]
20	RTRNH1004ECZZ	AE		B	Converter transformer [T1]
21	RVR-Z5450QCZZ	AF		B	Variable resistor (50KΩ) [VR]
22	VCCCCY1HH121J	AA		C	Capacitor (50WV 120PF) [C22]
23	VCCCCY1HH151J	AA		C	Capacitor (50WV 150PF) [C11]
24	VCCCCY1HH470J	AA		C	Capacitor (50WV 47PF) [C15,16]
25	VCEAPE1CW335M	AC		C	Capacitor (16WV 3.3μF) [C13]
26	VCEAPE1EW335M	AC		C	Capacitor (25WV 3.3μF) [C14]
27	VCKYCY1EF103Z	AA		C	Capacitor (25WV 0.010μF) [C32]
28	VCKYCY1EF104Z	AA		C	Capacitor (25WV 0.10μF) [C1~4,18,20,21,23~26,28,30,31,34]
29	VCKYCY1HB472K	AA		C	Capacitor (50WV 4700PF) [C17]
30	VHDDAN202K/-1	AB		B	Diode (DAN202K) [D1,2,3,4,5,6,8,10,13]
31	VHDDAN202U/-1	AB		B	Diode (DAN202U) [D14,15]
32	VHDB4000/-1	AC		B	Diode (RB4000) [D9,11,12]
33	VHERD9.1MB2-1	AC		B	Zener diode (HZ9C1) [D7]
34	VHIAT256BF12L	AY		B	IC (AT256BF12L) [IC3]
35	VHHD61202/-1	AS		B	IC (HD61202) [IC5,6]
36	VHHD61203/-1	AX		B	IC (HD61203) [IC4]
37	VHLH534HF9-1	AW	N	B	IC (LH534HF9) [IC2]
38	VHRH5VA39A-1	AE		B	IC (RH5VA39A) [IC7]
39	VHISC62015C01	AZ		B	IC (SC62015C01) [IC1]
40	VHITC3W01F/-1	AD		B	IC (TC3W01F) [IC12]
41	VHITC4S11F/-1	AC		B	IC (TC4S11F) [IC14]
42	VHITC4S66F/-1	AC		B	IC (TC4S66F) [IC10]
43	VHITC4S81FTPR	AC		B	IC (TC4S81FTPR) [IC8]
44	VHITC7S02F/-1	AC		B	IC (TC7S02F) [IC9]
45	VHITC7S08F/-1	AC		B	IC (TC7S08) [IC13]
46	VRS-TS2AD000J	AA		C	Resistor (1/4W 0Ω ±5%) [R22,25]
47	VRS-TS2AD102J	AA		C	Resistor (1/10W 1KΩ ±5%) [R1]
48	VRS-TS2AD104J	AA		C	Resistor (1/10W 100KΩ ±5%) [R2,3,16,17,21,24]
49	VRS-TS2AD184J	AA		C	Resistor (1/10W 180KΩ ±5%) [R4]
50	VRS-TS2AD243G	AA		C	Resistor (1/10W 24KΩ ±2%) [R5]
51	VRS-TS2AD334J	AA		C	Resistor (1/10W 330KΩ ±5%) [R18]
52	VRS-TS2AD392G	AA		C	Resistor (1/10W 3.9KΩ ±2%) [R6]
53	VRS-TS2AD393G	AA		C	Resistor (1/10W 39KΩ ±2%) [R7]
54	VRS-TS2AD4R7J	AA		C	Resistor (1/10W 4.7Ω ±5%) [R8]
55	VRS-TS2AD472J	AA		C	Resistor (1/10W 4.7KΩ ±5%) [R9]
56	VRS-TS2AD474J	AA		C	Resistor (1/10W 470KΩ ±5%) [R19]
57	VRS-TS2AD563J	AA		C	Resistor (1/10W 56KΩ ±5%) [R10]
58	VRS-TS2AD681J	AA		C	Resistor (1/10W 680Ω ±5%) [R11]
59	VRS-TS2AD822G	AA		C	Resistor (1/10W 8.2KΩ ±2%) [R12,13,14,15]
60	VSDTA114YK/-1	AC		B	Transistor (DTA114YK) [Q3]
61	VSDTA144EU/-1	AB		B	Transistor (DTA144EU) [Q4,5,6]
62	VSDTC144EU/-1	AB		B	Transistor (DTC144EU) [Q7]
63	VS2SC2412K/-1	AB		B	Transistor (2SC2412K) [Q2]
64	VS2SC2412KS-1	AB		B	Transistor (2SC2412KS) [Q1]
	(Unit)				
901	DUNTK1564ECZZ	BV	N	E	PWB unit

CAUTION FOR BATTERY REPLACEMENT

- (Danish) ADVARSEL !
Lithiumbatteri – Eksplosionsfare ved fejlagtig håndtering.
Udskiftning må kun ske med batteri
af samme fabrikat og type.
Levér det brugte batteri tilbage til leverandoren.
- (English) Caution !
Danger of explosion if battery is incorrectly replaced.
Replace only with the same or equivalent type
recommended by the equipment manufacturer.
Discard used batteries according to manufacturer's instructions.
- (Finnish) VAROITUS
Paristo voi räjähtää, jos se on virheellisesti asennettu.
Vaihda paristo ainoastaan laitevalmistajan suosittelemaan
tyyppiin. Hävitä käytetty paristo valmistajan ohjeiden
mukaisesti.
- (French) ATTENTION
Il y a danger d'explosion s' il y a remplacement incorrect
de la batterie. Remplacer uniquement avec une batterie du
même type ou d'un type recommandé par le constructeur.
Mettre au rebut les batteries usagées conformément aux
instructions du fabricant.
- (Swedish) VARNING
Explosionsfare vid felaktigt batteribyte.
Använd samma batterityp eller en ekvivalent
typ som rekommenderas av apparattillverkaren.
Kassera använt batteri enligt fabrikantens
instruktion.

COPYRIGHT © 1993 BY SHARP CORPORATION

All rights reserved.

Printed in Japan.

No part of this publication may be reproduced,
stored in a retrieval system, or transmitted,
in any form or by any means,
electronic, mechanical, photocopying, recording, or otherwise,
without prior written permission of the publisher.

SHARP CORPORATION
Information Systems Group
Quality & Reliability Control Center
Yamatokoriyama, Nara 639-11, Japan

1993 May Printed in Japan ©